


EZIO READERS User Guide



How to use the EZIO card readers

If at any time you enter your card PIN incorrectly three times into the card reader, **your PIN will lock and you won't be able to use your card.**



Authentication

To generate a Code:

1. Insert your card into the card reader
2. Press the **Identify** button on the card reader
3. Follow the prompts on the card reader:
 - Enter your card PIN for the card into the card reader. Now press the ENTER button on the card reader.
 - An eight-digit CODE will appear on the card reader (eg 1234 5678)



ENTER PIN:

PRESS ENTER?

YOUR CODE IS

0000 0000

Simplified Signature

To generate a simplified Challenge / Response signature code:

1. Insert your card into the card reader
2. Press the **Respond** button on the card reader
3. Follow the prompts on the card reader:
 - Enter your card PIN for the card into the card reader. Now press the ENTER button on the card reader
 - Enter NUMBER and press the ENTER button
 - An eight-digit CODE will appear on the card reader (eg 1234 5678)



ENTER PIN:



PRESS ENTER?



ENTER NUMBER
12345678

YOUR CODE IS
0000 0000

Transaction Signature

To make a payment or a standing order to someone new:

1. Insert the card into the card reader
2. Press the **Sign** button on the card reader
3. Follow the prompts on the card reader:
 - Enter your card PIN for the card into the card reader. Now press the ENTER button on the card reader
 - Enter REF number and press the ENTER button
 - Enter the AMOUNT you wish to pay and press ENTER
4. An eight -digit CODE will appear on the card reader (eg 1234 5678)




ENTER PIN:



PRESS ENTER?



ENTER REF:
12345678



ENTER AMOUNT
100.00

YOUR CODE IS
0000 0000

Zoom function

When the CODE is displayed, you can press the '0' button to display the code over two lines – for a larger view.



YOUR CODE IS
0000 0000

0000 0000