

-
- 7) It shall be the absolute discretion of the company to a)effect the repairs or replacement of parts whether at the site of installation or at any service and b)have the job attended to either by the company's service personnel or its authorized dealer.
- 8) The AC is designed to operate at a range (230 +/- 10%).Any failure due to operation of the machine beyond these limits will not be covered by the above warranty
- 9) The purchaser should preserve the original invoice for necessary verification and produce it, as and when required.
- 10) Warranty null and void if,
- The product is not purchased from an authorized dealer of the company.
 - Any damage is caused by accident, mishandling, tampering with installation , or negligence in following instructions of the user manual issued by the company.
 - Any damage is caused by improper electrical circuit outside the unit or by any defective electrical supply.
 - At any time, if any part of the unit is tampered with, altered, repaired or serviced by any unauthorized person, not being the authorized representative of the company.
- 11)None of the employees and/or Authorized Dealers of the Company have any authority to vary the terms and conditions of this warranty.
- 12)Our company reserves the final right of interpretation of the product. For any problem related to the product, please contact our technical support team or your dealer.
- 13) Please read the user manual carefully before installation and operation.

Wireless Video Door Phone

User Manual



Contents

Introduction.....	3
Features.....	4
Outdoor Camera.....	5
Indoor Monitor.....	6
Display show	8
Operationinstructions.....	10
Installation instructions.....	11
Part of power adapter.....	13
Part of the battery.....	13
Specifications and parameters.....	14
Working Environment.....	15
Maintenance of devices.....	15
Matters need to be noticed.....	15
Failure diagnosis.....	16
Accessories.....	17
Technology support and service.....	18

【Remark】this is a public manual, the pictures in the cover include all the models, All the pictures and screen display shown in this manual are somewhat different from actual product for advanced version of our product and different production ,as a result , this manual is only for presenting the operation of our product in detail. Please take actual devices as standard product .

WARRANTY TERMS & CONDITIONS

Our company warrants this Video Door Phone To The Original Purchaser To Be Free From Defects In Materials And Workmanship Within Six Months From The Date Of Purchase As Provided In The Warranty Card.

This warranty is subject to terms and conditions as mentioned below:

- 1) This warranty shall be valid only for the said period of 6 months as specified above.
- 2) The warranty period specified above shall include time taken for repairs, replacement, break-downs transit time etc. No notice of expired of warranty will be given by the company.
- 3) This warranty shall stand automatically terminated in the event of the said unit being serviced, repaired, installed, de-installed, re-installed or otherwise attended to by any person or organization or agency or by the said purchaser himself other than the authorized representative of the company.
- 4) Parts of the unit replaced or repaired under the terms of this warranty are warranted only for the remaining period of the original warranty period.
- 5) (For attending any service call under this warranty, all expenses incurred by the authorized representative / dealer in collecting the said unit or any part thereof from any location and its return to the original location shall be borne by the purchaser.
- 6) (Any loss of product caused due to sabotage, improper handling or treatment, carelessness, accident, fire, flood earthquake or any natural calamity shall not be covered under this warranty.

Technical support and services

①We insist tracking service through fore sale ,sale and post sale , please carefully read the user manual before installation;

②Please follow the user manual for correct installation and testing, if there is any doubt please call our tech-supporting and customer service center.

【 Remark 】 (1)Our company applies ourselves to reformation and innovation of our products . No extra informing for any change. The illustration shown here only used for reference , if there is any difference please take the actual product as standard product.

(2) Our company reserves the final right of interpretation of the production ,any problem of the quality , please feel free to return it to us !

No company and individual has the right to tear up the label of this product without permission.

Or you should be responsible for your action.

Introduction :

This product adopts 2.4GHz digital audio and video wireless transmission principle, outdoor unite takes pictures and indoor screen display , bilateral intercom. The monitor has the remote unlock function and can monitor the outdoor situation at any time , the advanced infrared-assisted lighting features , so you can identify the night-visitors. With fashionable and fresh appearance , clear viewing, easy to install , adding one more scientific protection for your family , this is absolutely an ideal security product for modern families.

For better taking advantage of the prior functions please carefully read our instruction for correct installation and operation.

【 Remark 】 :This manual is suit for the kit with one camera matching one monitor instead of one camera matching multiple monitors.

Features



① 2.4GHz launch frequency , barrier-free remote control distance is between 200-400m;



② With micro-processing technology, auto-remote control , excellent performance and high reliability;




③ The TFT3.5" digital color LCD for monitor;

④ CMOS 300,000 pixel for camera;

⑤ Clear night-viewing; 24 hours monitoring , calling , speaking and unlocking remote controlling etc;



⑥ One cameras can support 6 PCS monitors at most further information, please contact the salesman;



⑦The mini USB data output for monitor built-in high capacity rechargeable Lithium battery;

⑧The monitor can take/save/view more than 100 PCS of photos automatically;



signal image		barrier case)
	If there is other strong magnetic space bother?	Put the indoor device out of the strong magnetic space

13. Accessories

☐ Indoor Monitor 1PCS ☐ Outdoor Camera 1PCS
☐ 12V/1A Power 1PCS ☐ 5V/1A Power 1PCS

☐ Electric wire for E-lock 1PCS


【Remark】 The E-lock isn't the accessory

fault repair, please contact the distributor or the company's technology department.

12. Failure diagnosis

Defect	Judgement	Operation
Unable to start the product	If turn the switch to the "ON"?	Turn the switch to the ON
	If the power of Li-ion batteries is not enough?	To charge the li-ion batteries
	If connect the power adaptor?	To connect the power adaptor
Unable to charge	If the plug of power adaptor correctly plug into the charging slot?	Re-connect the devices and power adaptor
	If the power adapter has been connected to the 110-240V AC?	Re-insert the plug so that power supply connected to AC power adapter
Speaking state no voice	If the volume is adjusted to be the least?	To adjust the volume to be suitable
The image is flashing or noise	If the indoor device is close to TV set , fluorescent lamps , mobile phone , which has electromagnetic wave?	Keep the devices off these things which has electromagnetic wave
The indoor video phone shows no	If the outdoor phone doesn't connect the power?	To connect the outdoor device power
	If the outdoor phone is far away from the indoor phone?	Keep the distance within 60 meters (with multi-wall

1. Outdoor camera



All parts and button instruction

- ① camera(getting images of outdoor and visitor)
- ② night-viewing light (Use for getting the clear images of visitor, will light off by itself after 90s)
- ③ The indicator light(the outdoor camera with battery, light on means charging state, light off means charged over, flashing means talking state)
- ④ Speaker(through speaker, can listen host's voice)
- ⑤ Call(call the indoor phone and auto start the camera)
- ⑥ The socket of rain-proof flat cover

2. Indoor monitor



9. working environment

- ①Working temperature -25°C—+50°C
- ②Working humidity range: less than 85%

10. Maintenance of devices

- ①Keep the clearance of the surface and use the soft dry cloth to clean the dust of the product,
- ②Please turn off the power of indoor unit when clean the indoor device,
- ③If there is hard dirty which cannot be cleaned with dry cloth, please use the soft towel dipped in the neutral diluted detergent to clean the machine and then clean it with dry cloth,
- ④Do not use benzene, thinner or organic solvents such as gasoline to clean, these solvents may cause damage to the machine casing or the surface of the machine and change colors.

11. Matters need to be noticed

- ①The product should be placed where is stable , windy , air-dry, non-sunshine ,non strong magnetic and non-dusty;
- ②Don't clean the surface with chemicals but with soft and clean dry cloth;
- ③Don't press several buttons at the same time;
- ④The outdoor and indoor unit must be matched with appointed specified models and cannot match with others that are not our products.
- ⑤Do not disassemble the machine without authorization, if the need for

8. Specifications and parameters

Outdoor extension		Indoor extension	
Power Supply	Input: AC 100-240V 50/60Hz Output: DC 12V 1A	Power Supply	Input: AC 100-240V 50/60Hz Output: DC 5V 1A
Camera	CMOS 300,000 pixels	Screen specifications	3.5" TFT 320×240
Light Source	6 LED lights	Battery	3.7V 1200mAh Li-Ion Battery
Power consumption	Standby: 0.2W Unlock: 12W	Power consumption	Standby: 0.1W Work: 2W
Modulation	GFSK	Modulation	GFSK
Frequency	2.4GHz	Frequency	2.4GHz
Transmitting power	17dBm	Transmitting power	17dBm
Channel number	64	Channel number	64
Size(mm)	125×93×33mm	Size(mm)	135×115×13mm
		Charging time	3 hours
		Standby time	6 days

All parts and button instruction:

- ① TFT LCD display (to show the image of visitor)
- ② Speaker (to hear the Dingdong calling and the voice of the visitor)
- ③ Antenna (to transfer the signal of voice, unlock to the camera, at the same time receive the signal of voice, image and call from the camera)
- ④ Micro-phone (to convey the visitor's voice to the camera)
- ⑤ Indoor power switch.
- ⑥ Unlock (to control the camera and release the E-lock)
- ⑦ Monitor: (to start monitor and monitor the outdoor circumstance)
- ⑧ Brightness+: (to enforce the brightness of images)
- ⑨ Volume-: (turn down the volume)
- ⑩ Brightness-: (turn down the brightness of images)
- ⑪ Volume+: (turn on the volume)
- ⑫ Talk: (talk to the outdoor unit)
- ⑬ Picture: (press the "picture" key to take picture)

3. Display show:



1. Image of starting

Turn the power switch to ON and the screen display this image for 2 seconds ,.. When goes into standby state, the system automatically turn off the screen image of monitor up



2. The picture of time adjustment

In working state, press “unlock” to enter time adjustment screen, press the left/right/ up/down key on the panel to adjust the time freely,



3. Image of brightness adjustment

In monitoring state or taking stare ,press up/down key on the panel to adjust brightness. adjusting range: 0-9

Among them:



- (1) Battery Installation.
- (2) The power socket.
- (3) The socket of switch signal-control lock.
- (4) The socket of voltage signal-control lock.
- (5) rain-proof flat cover

6. Part of power adapter

- ①The outdoor unit power supply: 12V/1A(DC transformer)
- ②The indoor unit power supply: 5V/1A(DC transformer)
- ③Please use the appointed or same specification (same rate voltage and current) power adaptor ,the non-specified power adaptor may damage the circuits and components inside;


7. Part of the battery

- ①The monitor built-in high capacity rechargeable Lithium battery, the indoor unit should be placed in a well-ventilated, cool and place without direct sunlight;
- ②The battery is easily-consumed product with limited life , if repeatedly charging or discharging in working state will shorten its life;
- ③New product should be charged for 2-3 hours each time.




4. Image of volume adjusting

In talking state, Press left/right key on the panel to adjust volume. adjusting range: 0-9



5. Taking photographs

In working state. press "picture" key to display "P" enter into take picture standby, can taking picture feel like now and save to view(100 pcs pictures saveable)



6. Monitoring

In working state, press the monitor key to show "little eye" picture for enter into 24 hours monitor outside, outdoor camera can't get voice from indoor, support check anytime, no video recording function

