



USB Spy Camcorder Pen	How to make video taping:	Specifications:
<p>Thank you for purchasing USB spy Camcorder pen. It is small enough to conceal almost anywhere.</p> 	<ul style="list-style-type: none"> ■ Be sure the Slide switch "F" in "Video record" mode. ■ Press the button "A", it powers on and the LED will be orange. Then the LED will automatically turns to blue and it is video taping. ■ To press the button "A" again to stop, it begins to save data and switch it to standby mode and the LED is orange. ■ If you need to make video recording again, press the button "A" once more, then it comes back video taping and the light will turn to blue again. ■ To press and hold the button "A" about 5 seconds, the device will power off. ■ It will turn off itself about 60 seconds when the device is in standby mode without using. ■ It will turn off when run out of battery. And it will save the video taping files before automatically shutting down. 	<ul style="list-style-type: none"> ■ Video compression: AVI video format, 640 x 480 ■ Voice recording: Yes ■ Video playback on PC. ■ Adaptor type: USB adapter charging cable. ■ Battery type: 220mAh Polymer Lithium-ion. ■ Battery use time for continuing Video Taping: about 90 minutes according to illumination. With more bright, the recording time is shorter. ■ Supports WinMe/2000/XP/Vista/LINUX2.4 ■ DSC: 1.3M ■ VGA: 640 x 480 <p>Connect to PC with USB cable:</p> <ul style="list-style-type: none"> ■ Connect the device to computer with USB cable for data storage. It is also charging the battery. ■ playback the video files via the computer. <p>Notice:</p> <ul style="list-style-type: none"> ■ If the battery uses off suddenly, it will store the recording video files before it turns off. ■ In case the situation of system halted happen, please use "RESET" button. It will work again. ■ Do not push "RESET" button when the device is recording in case of data lost. ■ Please use form "FAT" to re-format for 1GB and 2GB. Use form "FAT32" for 4GB.
<p>Features:</p> <ul style="list-style-type: none"> ■ USB Spy Camcorder pen (up to 4GB) ■ Dimension: 150(L) x 14(diameter) mm ■ Weight: 30g ■ It's great for use as a hidden cam. ■ Real time recording in AVI video format. <p>How to change clock:</p> <p>There is a folder of "How to change the clock" in pen. Please read the file of "how to change the clock.txt" to change the settings for year/date/time.</p>	<p>How to charge the battery:</p> <ul style="list-style-type: none"> ■ It build-in 220mAh Polymer Lithium-ion battery. ■ Plug it into your computer for battery charging. ■ Use adapter for battery. ■ The orange LED will flashing while battery charging. As soon the orange stop flashing, it means the battery is full. ■ Charging time: at least 2-3 hours. 	<p>How to change the refill:</p>  <p>CE FC RoHS Compliant Made in Taiwan</p>