



# PC01T USER MANUAL



- PRESET : To set the preset position
- CALL : To call the preset position
- NUMBER KEY : 0~9
- RESET : Clear input data
- ENTER : To confirm
- ZOOM IN : Turn to a telescopic range
- ZOOM OUT : To a wide angle
- IRIS ON : Open IRIS
- IRIS OFF : Close IRIS
- FOCUS+ : To make focus far manually
- FOCUS- : To make focus near manually
- S1~S3 : Switch 1 to 3 control
- ON : Switch on the setting of function
- OFF : Switch off the setting of function



操作方法：

1. PAN/TILT：按下數字鍵(以下稱位址)後按方向鍵即可。  
 位址 → 方向鍵  
 例: 12 → 方向鍵 或 3 → 方向鍵
2. AUTO PAN：位址 → AUTO → ON AUTO PAN ON。  
 位址 → AUTO → OFF AUTO PAN OFF。
3. ZOOM：位址 → ZOOM IN 或 位址 → ZOOM OUT
4. IRIS：位址 → IRIS ON 或 位址 → IRIS OFF
5. FOCUS：位址 → FOCUS + 或 位址 → FOCUS -
6. PRESET：SPEED DOME CAMERA 位置記憶，可記憶 9 個位置  
 位址 → P → 1~9
7. CALL：取出 SPEED DOME CAMERA 位置記憶  
 位址 → C → 1~9
8. SWITCH ON/OFF：此功能須配合本公司 SC 系列產品方能使用  
 位址 → S2 → ON SWITCH 2 ON  
 位址 → S1 → OFF SWITCH 1 OFF
9. 清除輸入：按下 R 即可清除上一步輸入，並將位址清除為 0。
10. 發送位址：按下 E 則只送出位址，無其他動作。