


SA026Z4 motor installation manual

Step1 : Newly purchased lamp



Step2



Step3



Step4 : Original lamp



1-1、Use tool to screw the lid off。

1-2、Turn the mount clockwise (LH) / counterclockwise (RH)。

2、Screw the dummy motor mount off counterclockwise.

3、Turn the screw to loosen it and take it out.

4、Open the lid on the original lamp. Turn the motor clockwise (LH) / counetr-clockwise (RH) to loosen it.


Step5



Step6 : Newly purchased lamp



Step7



5、Take the motor out from the original lamp。

6、Install the motor on the newly purchased lamp. Doing Step3 reversly (The front pellet of the motor must be installed on the skid properly).

Step8



7-1、Finished as shown in the picture.

7-2、Put on the lid and turn the screw tight.

SA026Z4 電動馬達拆裝說明

步驟一：拆購置件




- 1-1、使用工具將護蓋螺絲卸下並打開。
1-2、將固定座左邊順時針 / 右邊逆時
針旋開。

步驟五：



- 5、將原車燈組馬達取出。

步驟二：



- 2、螺絲逆時針將假馬達固定座
螺絲取出。

步驟六：裝購置件



- 6、將原車燈組馬達裝入購置燈具，
依步驟三逆向裝入燈組內(馬達球
頭須確實裝回固定於滑軌內)。

步驟三：



- 3、調整螺絲確定旋鬆後並取出。

步驟四:拆原車件



- 4、打開原車燈具護蓋，左邊順時針
/右邊逆轉將電動馬達旋鬆。

步驟八



- 7-1、完成示意圖。
7-2、將護蓋裝回並需將螺絲鎖緊。