# **BTH-300** User Manual

#### **FEATURES:**



Charging port 2. Power/Talk button with Status Indicator light 3. Volume + button
Microphone 5. Volume - button

#### CHARGING:

Connect the charger to AC power and then to your BTH-300. The red Status Indicator light will be steady on while charging and turn off when the BTH-300 is fully charged.

## POWER ON/OFF:

Press and hold the Power/Talk Button for two seconds (long press) to turn the BTH-300 On. When in Stand by, press and hold the Power/Talk Button for five seconds (long press) to turn the BTH-300 Off. The Status Indicator flashes blue when the BTH-300 is on. When the battery becomes low, the red Status Indicator will be on, and you hear the beep tones through the device.

## PAIRING and CONNECTING

- 1. Place the BTH-300 in pairing mode by pressing and holding the Power/Talk button for five seconds. Release the buttons when the Status Indicator light begins to flash red then blue.
- 2. Use your phone's menu to search for Bluetooth audio devices and select "BTH-300" when s appears on the display. Note: In some circumstances the pairing process can take up 2 minutes to complete.
- 3. When then phone display asks for a passkey, enter: 0000. The Status Indicator flashes blue twice quickly, once the BTH-300 is successfully paired and connected. If pairing fails, try again following the steps.

## **USING YOUR BTH-300**

To answer or end a call, short press the Power/Talk button. (Less than 1 sec.)

To place a call using voice dialing, press the Power button once, you will hear a tone. If you are on a call using your phone handset, you can transfer the call to your **BTH-300** by a long press of the Power/Talk button.

The following additional features may be available if your phone supports the Handsfree Profile.

Call Transfer back to phone - To transfer a call from your BTH-300 back to your phone, press and hold the Power/Talk button. When you hear a tone, the transfer has been completed and you can release the button.

Call Reject - To reject a call without answering when the handset is ringing, press and hold the Power/Talk button. When you hear a tone, the call has been rejected and you can release the button.

Last Number redial - To redial the last number, double short press the Power/Talk button, until you hear a tone, the last number has been redialed.

During a call, press the Volume +/- button to adjust the volume.

During a call, simultaneously press the Volume +/- button once to mute the microphone. When muted, the red Status Indicator light will be on. To take the microphone off mute, simultaneously press the buttons again.