


User manual

General controls



Indicator light: the red light is power indicator light.

Recording

1. **Starts recording:** push the Rec-switch to the side “REC”; after 2 seconds, the Blue light illume. For a moment, the red light turn off, therewith starts recording.
2. **Stops recording:** push the Rec-switch to the side “STOP”; then stops recording.
3. **Play:** connect to computer, copy recording files to the computer, and play recording via the computer’s Windows Media Player.

Charge up

Connect to your computer, the red light flash, starts charging up automatically. When the battery is full, the red light stops flashing, and is red always.

Importance

1. **Connecting to computer:** if you want to connect to your computer using it only as USB flash drives, make sure the button kept “stop”.

, make sure the button kept “stops”.

2. **Low power state:** when the battery is at low power state, the red-power-light flash. Please stop recording and Save the recording file.

3. **Automatic voice saving:** at recording state, when the battery is exhausted, the product stops and saves recording files automatically.

4. **Do not interrupt recording:** when recording and the battery is at low power state, please connect it to your computer or Charger, recording will go on.

Notice: the status, you can only charge this device, can not find Udisk information in your computer.

5. **Troubleshooting tips:** the device can not work suddenly, do not worry, you only need to insert small sharp objects into the reset hole, and press the reset button, then this device can work again.

6. **Cannot record:** if memory is full, the product cannot record.

Note

Charge:

When using the charger, please use good quality charger. When charging up, do not place device on the bed, pillows and children likely to touch the location!

Waterproof:

This device is not waterproof, please keep dry! Once the water into the device, do not own dismantling, take device to factory repair!

Interference:

All devices may be subject to interference, please stay far away from sources of interference!

Security:

This device may contain small parts, do not put in the place that children easily touch!

File backup

When operational errors may result in lost files, please backup your files.

File transfer

When the equipment and computer file transfer, do not unplug the machine!

Otherwise the file will be lost!

Specifications

Specifications	
Size	70*21*9.4mm
Weight	14g
Recording format	(WAV)
Sample	48KHZ/ 192Kbps
Recording time	Memory 2G: 24 hours
	Memory 4G:48 hours
	Memory 8G: 96 hours
Computer system	Windows vista/xp/2000/7/8 ; Mac ; Linux
Power Supply	Recording: 15hours
Power	Lithium Battery, charge up: input DC5.0V