



## **User Guide**



10000mAh Power Bank Model No. PB50 7106505128 REV1.0.0


# How do I use the Power Bank to charge other portable devices?

Connect your device(s) via the charging cable to the Power Bank.



### Note:

- The 5V/2A USB port can automatically adjust its voltage to charge your 5V/1A devices.
- 2. One blinking LED indicates the battery level is less than 5%.



## 2


## How do I recharge the Power Bank?

Connect the Power Bank via a power adapter to an electrical power outlet.



#### Note:

- 1. The Power Bank is compatible with 5V DC adapters. For more efficiency, we suggest using a 5V/2A power adapter to charge the Power Bank.
- You can also charge the Power Bank via a computer's USB port, but it will take longer to charge.
- 3. The Power Bank cannot charge other devices while it is charging.



### Attention

- Keep this device away from water, fire, humidity or hot environments.
- Do not heavily drop or impact this device.
- Do not attempt to extrude or pierce this device, which may cause it to short-circuit.
- Do not attempt to disassemble, modify or repair this device by yourself.
- Do not use a damaged power adapter or USB cable to charge this device.
- If the product appears to be bulging or shows other undesirable phenomena, stop using the product immediately and contact us or your dealer.
- Please recycle this device at an appointed disposal location.
- This product is not suitable for those lacking relevant knowledge and experience, please use under the supervision and guidance of professionals.
- Please charge this device once every three months to avoid shortening its battery life.
- Please use the recommended power adapter to charge this device. Power adapter is not provided by TP-LINK.
- For more information, please visit: www.tp-link.com
- Contact our technical support if you have any questions related to this product: www.tp-link.com/en/support/contact

