THE BASE MUST BE ASSEMBLED BEFORE FIRST USE:



Screw stem onto threaded bolt on U Base. Turn by hand until tight. Always ensure stem is well tightened before fitting flag pole as below.

If required, small amount of nut lock compound or adhesive such as "superglue" or similar on thread will assist in maintaining a tight joint. This is not normally necessary.

Do not disassemble after set up.

USER GUIDE

ADJUSTING THE TELESCOPIC POLE:

The pole has 3 adjustable sections with simple "Twist Lock" action. The telescopic design allows extension to any length up to 3 meters.

TO LOCK - TURN CLOCKWISE

TO UNLOCK - TURN ANTI CLOCKWISE



Excessive force will damage mechanism, correctly used the pole turns/locks easily Ensure the pole is unlocked at set-up. Pole will jam if dented.



"U" BASE (CAR WHEEL BASE)

1. Place U-base flat next to car and slide around wheel, push firmly towards wheel (Don't drive over it) The U base works on all average sized production cars.

2. Larger end of pole fits snugly over upright stem - push down firmly.

3. Slip the thinner pole into sleeve at top of flag, starting at the selvedge side of the flag, (the side with the loops).

4. Fit loops over pole. Bottom loop first - top loop last. Place top (Elbow) on pole

5. Easily extend the pole - usually to maximum length.

LOCK & UNLOCK POLE AS DESCRIBED ABOVE "Adjusting Telescopic Pole"

DO NOT "LEVER" POLE SIDE TO SIDE TO REMOVE FROM OR PLACE ON BASE

6. Make sure that you have your listing pad readily available because neighbours will soon be rushing in to sign up Exclusives with you !



EARTH SPIKE

NB:

Use on lawn grass and similar where it is possible to drive spike into ground. Proceed from para. 2 in section on Car U Base above.

STAND ALONE (PLASTIC) BASE

Fill with water or sand. Fit pole to stem and proceed from para. 2 in section on Car U Base above.



NB: USING THE SYSTEM IS A MATTER OF COMMON SENSE. THE FLAG FUNCTIONS WELL IN A BREEZE. IF THE WIND IS TOO STRONG - DON'T USE. ENSURE ADHERENCE TO ALL LOCAL LAWS & REGULATIONS.

WASHING INSTRUCTIONS

Machine wash in warm (not hot) water - Standard / Mild laundry detergent - handle carefully to avoid ironing - dry in shade - cool iron if necessary - can be gently hand washed taking care not to wring. Can be Dry Cleaned.



PHONE: 0416 203 793 or 0417 608 565

Flags, Banners & Services to boost your business

www.globalbanner.com.au





