




SPOUSEBUSTERS

unlocking the truth

Ultra Mini GSM Bug User Manual (SBRGSMB)



CONTACT US

Phone: 1300 776 873 | Fax: (02) 8088 7328 | Web: www.spousebusters.com.au

Features

The Real Time GSM bug allows you to listen in to everything going on within an area, from anywhere in the world. Think of it like a mobile phone that does not need to be answered in order to be connected. You simply charge the device up, insert a SIM card, leave it in the area you wish to monitor, and then using any type of phone, from anywhere in the world, you can simply dial in and the unit automatically activates when you place a call to it.

Embedded with a specially designed microphone system, there is no software, or configuration required. Just insert a valid SIM card into the indicated SIM card slot, hide it in an inconspicuous location and you can listen in to its surroundings from wherever you are in the world.

User Guide

1. Insert the SIM card to the device. The red light will shine for 2 seconds and then go out automatically. Now, the device is activated and ready. Please ensure SIM card does NOT have message bank activated, PIN, or message to text activated.
2. You can dial the phone number of the SIM card that you inserted to the device from anywhere in the world. When the call connects, you can hear the voices around the device. (People talking nearby the device will not know they are being bugged by this device because the device does not make any sound when you dial the number to connect through to the device).
3. Take out the GSM card from the device to shut off.

Charging - Charge first time for at least 5 hours

Find the connecting cable and the charger for the device. Insert one end of the connecting cable to the "Charge" hole of the device and put the other end to the charger, then plug the charger to power supply. Now, charging is started.

When charging, the red light and green light on the chargers shine. When fully charged, red light comes on and green goes light out. (3-5 hours for charging time to be fully charged).

Technical Specifications

Super-sensitive audio surveillance	
GSM Frequency	900, 1800, 1900
Embed four condense microphone	
All GSM SIM card compatible	
Microphone range (Meter)	5~7(Radius), 4 levels
Receive sensitivity	-\+10K
Working temperature	-40~50'C
Responding frequency	1.2K~800 KHz
Standby time	5 days
Call in time	6 hours



SPOUSEBUSTERS
unlocking the truth

CONTACT US:

Phone: 1300 776 873 | Fax: (02) 8088 7328

Website: www.spousebusters.com.au

