

QNN SAFE AUSTRALIA PTY LTD

ABN 47 168 078 233

Unit 9 / 376 Newbridge Road, Moorebank NSW 2170

Web site: www.qnnsafe.com.au

Email: info@qnnsafe.com.au

Phone: 02-87982669

QNN® Safe

USER'S MANUAL FOR KL SERIES SAFE

Serial Number:



This package contents:

- User manual
- 1 External Battery Box
- 2 Bolt Down Screws 12mmx80mm
- 4 AA Batteries
- 2 Emergency back up Keys
- 1 Removable LED light
- 3 AAA Batteries

Please contact your retailer or Qnn Safe Australia P/L if any shortage occurred

For the first time use, it needs the external battery power support:

- Insert the supplied 4 AA batteries into the External Battery Box
- Connect the power to the front panel. The power inlet is located next to the QNN nameplate.

After the safe is opened, please replace the batteries into the internal battery box, which is located behind the door plate, please slid the box cover upward to open.

- After enter the right code, turn the handle knob clockwise, Safe is now unlocked.

This safe is operated by the personal digital code.

The factory setting for the digital code is: “1 2 3 4 5 6 “

QNN SAFE AUSTRALIA PTY LTD

ABN 47 168 078 233



Unit 9 / 376 Newbridge Road, Moorebank NSW 2170

Web site: www.qnnsafe.com.au

Email: info@qnnsafe.com.au

Phone: 02-87982669

Opening instructions:

- Touch the  on the front screen the system.
 - Enter the code, and then press . (Factory setting code “123456”)
 - **OPEN** displayed with 2 beeps
 - To pop up the handle, press the little button on the handle
 - Turn the handle clockwise, safe now is unlocked.
 - **E-CODE** Displayed with 3 beeps means it is a wrong code try. 3 continual wrong code tries will lead the loudly sound alarm activated for 60 seconds and the operations will be held for 5 minutes. **HOLD **** then displayed to indicate the remaining holding time in minutes
- Cautions: After the alarm is activated, there is no way to de-activate the alarm within the 60 seconds period. And also the operation is held for 5 minutes.**
- Any unexpected sharking and moving toward the safe body will lead the loudly sound alarm be activated for 60 seconds.


Closing instructions:

- Close the door
- Turn handle knob counter clockwise
- Press the handle down to set back the position

Changing Code:

Please keep the door at open position during the whole processing until fully ensure that the code is changed correctly.

For security reasons, please change to your own code after the first opening. Your code can be set up to 10 digits

- Open the safe door. Press the reset button which is located behind the door plate (Hinge side)
- “USER” then displayed
- Input your new own digital code (within 10 digits), then press 
- **DONE** then displayed with one beep, which indicate that the code is changed

QNN SAFE AUSTRALIA PTY LTD

ABN 47 168 078 233

Unit 9 / 376 Newbridge Road, Moorebank NSW 2170

Web site: www.qnnsafe.com.au

Email: info@qnnsafe.com.au

Phone: 02-87982669

successful

- Keep the door open, check and remember the code.




Emergency Backup

In an emergency saturation, safe can be opened by the Emergency key. (Override the digital lock). The key whole is located behind the QNN nameplate, to expose the key hole you need to peel off the name label.

Then turn the master key clockwise while holds the Emergency Key counter clockwise to unlock the safe.

Other features:

- **Code hidden function:**

To activate the function: Press  , then press  twice, then  again

To de-activate: Repeat the above steps

Cautions:

- **Do not store the Emergency Keys and the External Battery Box inside the safe**
- **When the “LO-BAY” display with 3 beeps, it means that the batteries need to be replaced. Please replace new batteries as soon as possible**