QNN®Safe

USER'S MANUAL FOR M-2045UZH SERIES WITH AUDIT TRAIL SYSTEM

This package contents:

- User manual
- 1 External Battery Box
- 2 Bolt Down Screws
- 4 AA Batteries
- 2 Emergency back up Keys

Please contact your retailer or Qnn Safe Australia P/L if any shortage occurred

For the first time use, it needs the external battery power support:

- Insert the supplied 4 AA batteries into the External Battery Box
- Connect the power to the front panel. The power inlet is located next to the QNN nameplate. Please slid the nameplate sideward to expose the hole

  After the safe is opened, please replace the batteries into the internal battery box, which is located behind the door plate, please slid the box cover sideward to open.

- After enter the right code, turn the handle knob clockwise, Safe is new unlocked.

This safe is operated by the digital code.

The factory setting for the digital code is: "1 2 3 4 5 6"

QNN SAFE AUSTRALIA PTY LTD

ABN 47 168 078 233

Unit 9 / 376 Newbridge Road, Moorebank NSW 2170

Web site: www.qnnsafe.com.au

Email: info@qnnsafe.com.au

Phone: 02-87982669

Opening instructions:

- Press the ▶ on the front screen to activate the system.

- Enter the code, and then press ▶. (Factory setting code "123456")

- **OPEN** displayed with 2 beeps

- **E-CODE** Displayed with 3 beeps means it is a wrong code try. 3 continual wrong code tries will be held for 15 minutes.

- **Cautions: After the Holding is activated, there is no way to de-activate the Holding within the 15 minutes period. HOLD★★ then displayed to indicate the remaining holding time in minutes**

Closing instructions:

- Push the drawer at closed position

- Press ▶ to activate the system, then press ▶ again until safe is automatic locked.

  Cautions: This will keep the code unchanged for next openings

Changing Code:

Please keep the drawer at open position during the whole processing until fully ensure that the code is changed correctly.

For security reasons, please change to your own code after the first opening. Your code can be set up from 4 to 6 digits

- Open the drawer and ensure that the lock is in unlocked position,

- Press the ▶ on the front screen to activate the system.

- Input your new own digital code (from 4 to 6 digits), then press ▶

- **CLOSED** Then displayed with 2 beeps and the locking bolts are driven to locking position. which indicate that the code is changed successful

- Using the New Code to unlock the bolts, and remember the code.

Emergency Backup

In an emergency saturation, safe can be opened by the Emergency key. (Override the digital lock). The key whole is located right hand side of the front panel, to expose the key hole you need to screw off the material plug.

Then turn the master key counter clockwise to unlock the drawer.

You need to reset a new code after open the safe using **Emergency Key**

To reset the code:

- Keep the Emergency key at counter clockwise position

- Press the on the front screen to activate the system.

- Input your new digital code (from 4 to 6 digits), then press

- **CLOSED** Then displayed with 2 beeps and then **LO-BAT** displayed. which indicate that the code is changed successful

- Keep the Drawer opened, turn the Emergency Key clockwise

- Using the New Code to unlock the bolts, and remember the code.

Other features:

- **Code hidden function:**

To activate the function: Press , then press ◀ **twice**, then again
To de-activate: Repeat the above steps

Cautions:

- **Do not store the Emergency Keys and the External Battery Box inside the safe.**
  When the "LO-BAY" display with 3 beeps, it means that the batteries need to be replaced. Please replace new batteries as soon as possible.

Function of safe:

QNN SAFE AUSTRALIA PTY LTD

Double code system, user code and master code

1) User code (4-6 digits), Factory setting：1234

2) Master code (6 digits), Manager code(6 digits), operate in CEU, factory setting: 123456
   (CEU operation, pls check the CEU instruction manual)

3) With code hidden function

4) Holde 5mins of keypad after 3 times wrong trying

Opening

First opening: install 4 AA batteries into the external battery case, plug in the outlet which behind the Brand position, level shift the Brand position from right to left.

Second: to pressing the Handle button,make handle up.

Third: Press ► on the panel to wake up the safe, back light on, you can see the number clearly. Input original code (1234) and ►, You will see "OPEN" if the code is correct. Then it will show "OPENED",Pull the handle to left (Clockwise direction), the door can be opened.

When you see the safe show "E-CODE", that means your code is wrong.

Remove the batteries from the external battery case to the battery case on the back of the door, you can use the safe without the external power supply now.

Close the door

Push the drawer to close position, press ► to wake up the safe, and input your code (4-6 digits), then press ► again, the panel shows "**CLOSE**" then "**CLOSED**", the drawer is closed automatically.

Code setting

（1）CHANGE MANAGER CODE:

Please refer to CEU user manual

（2）CHANGE PERSONAL CODE:

Under open situation, press the ►then input your new code (within 4-6 digits) and press ►again, to show "**CLOSED**". Now you will see your new code on the displayer, which means your operation succeeds.

Tips: After you change the code, please do not close the door or turn the handle at once. Follow the below steps at least 3 times to make sure your new code is work.

Press ►, the back light on, input your new code and ►. The safe will beep one time if the

QNN SAFE AUSTRALIA PTY LTD

ABN 47 168 078 233

Unit 9 / 376 Newbridge Road, Moorebank NSW 2170

Web site: www.qnnsafe.com.au

Email: info@qnnsafe.com.au

Phone: 02-87982669

---

code is correct, you can see "OPENED". That means the new code work now.

If the code is wrong, the safe show "E-CODE" and you will hear beep 3 times. Please follow the steps of "CODE SETTING" to change the code again.

Emergency opening

If you have forgotten your personal code or for other reasons the safe cannot be opened, you can use the emergency key or CEU to open the door.

Code hidden function

Press ► to wake up the safe, then input ◄ button two times and ► one time, you will hear beep two times. It comes into hidden code function. Repeat above steps, the code will be recovered. Code digits will be show as "□"

Cautions

（1）HOLD:

If you input an incorrect code 3 times, the keypad will be held for 15 minutes. During this period, there will be no response when pressing any key, and show **HOLD+Digit**, the digit is the holding time. After 15 minutes, it will recover its normal situation.

（2）LOW VOLTAGE:

When it lowers than 5V, whether the door is open or closed, it will show **LO-BAT** on the displayer.

（3）"◄" is also a deletion key; press one time will delete one digit input.