


Section Contents

PL 1 Base and PWBs	5-2
PL 2 Printer Assembly	5-4
PL 3 Covers and Supplies	5-6
Part Number Index	5-8

www MK-Electronic.de


PL 1: Base and PWBs



PL 1: Base and PWBs

Item	Part Number	Description
1	117E13660	Power Cord
2	162K32250	PC I/F IEEE 1284 Cable
3	101E13130	Main Chassis
4	019E36330	Ink Pad
5	105K16570	Power Supply
6	108E04580	Fuse 2A, 250V
7	--	Parallel Port Adapter PWB Cover
8	160K36850	Parallel Port Adapter PWB
9	--	Mylar Protective Sheet
10	--	Printer PWB Cover
11	160K36840	Printer PWB
12	--	Ground Wire

PL 2: Printer Assembly




PL 2: Printer Assembly

Item	Part Number	Description
1	050K35130	Print Out Tray
2	038K11210	Exit Guide
3	011E07340	Cartridge Latch Lever
4	--	Cartridge Latch Lever Cam Pin
5	015E59830	Blotter
6	--	Holder
7	127K22240	Pump
8	--	Pump Bracket
9	127E10810	Paper Feed Motor
10	--	Gear Assembly
11	--	Carriage Assembly Rod
12	007E52860	Toggle Gear
13	016E12390	Bushing
14	--	Ground Strap
15	127E10800	Carriage Motor
16	130K56600	Ink level sensor
17	130K56490	Paper path sensor
18	160K32290	Printer interface PWB
19	--	Printer Base
20	146K00490	Encoder
21	041K05310	Encoder/Tensioner Assembly
22	--	Ground Strap
23	023E14840	Timing Belt

Item	Part Number	Description
24	033E03510	Wiper
25	094K03590	Maintenance Station
26	019E35770	Retard pad (not shown)
27	22K53800	Exit roller assembly
28	050K35140	Paper Cassette
29	046K00300	Printer Assembly
30	041K05500	Carrier Assembly (Carriage)

PI 3: Covers and Supplies



PL 3: Covers and Supplies

Item	Part Number	Description
1	109K01070	Scanner Assembly
2	048K60240	Access Door Assembly
3	048K60250	Top Cover
4	610E30550	Scan Calibration Card
5	008R07659	Color Print Head
6	008R07660	Black Ink Cartridge
7	008R07661	Cyan Ink Cartridge
8	008R07662	Magenta Ink Cartridge
9	008R07663	Yellow Ink Cartridge
10	060K01011	Cartridge Storage Box
11	300K68200	HomeCentre CD-ROM Assembly
12	673K34300	PhotoEnhancer Kit
13	673K34310	Print Artist Kit
14	017E07850	Foot
15	610E30290	Quick Install Booklet
16	101K29650	Control Panel Assembly
17	062E08830	Lens Optics Window Cover

Spare Parts Index

Part Number	PL
007E52860	2
008R07659	3
008R07660	3
008R07661	3
008R07662	3
008R07663	3
011E07340	2
015E59830	2
016E12390	2
017E07850	3
019E35770	2
019E36330	1
22K53800	2
023E14840	2
033E03510	2
038K11210	2
041K05310	2
041K05500	2
046K00300	2
048K60240	3
048K60250	3
050K35130	2
050K35140	2

Part Number	PL
060K01011	3
062E08830	3
094K03590	2
101E13130	1
101K29650	3
105K16570	1
108E04580	1
109K01070	3
117E13660	1
127E10800	2
127E10810	2
127K22240	2
130K56490	2
130K56600	2
146K00490	2
160K32290	2
160K36840	1
160K36850	1
162K32250	1
300K68200	3
610E30290	3
610E30550	3
673K34300	3
673K34310	3