




User Guide

ice>Link Lite AV

ice>Link Lite AV provides a standard AV (Audio-Video) output for the 5th Generation (video) iPod's. This AV signal can be connected to virtually any video monitor converting iPod to an ideal component of car multimedia entertainment systems.

OPERATION

Playback can be controlled using the iPod's buttons on a usual way or with an Apple IR Remote Controller, model A1156 or compatible (not part of the package). See available functions below:

| Button | Function | |
|--|-----------------|-------------------|
| | Press | Press and hold |
|  | Next Track | FW |
|  | Previous Ttrack | RW |
|  | Play/Pause | Power OFF* |
| + | Cursor up | Next Playlist |
| - | Cursor down | Previous Playlist |
| MENU | Select | Menu |

*Press and hold for 3 seconds to activate

Ignition on will activate **ice>Link Lite AV** and start charging the iPod. Turning ignition off will switch off the iPod and stop charging it.

WARNING!

Do not allow the Apple iPod to distract you from driving! Only operate the unit when stationary or let passengers to operate.

Neither Dension Audio Systems, nor Apple Computer, Inc, its regional offices distributors or resellers accept any responsibility for any damage or injury as a result of using **ice>Link Lite AV** with the iPod!

Exercise good judgment and keep your eyes on the road at all times!

INSTALLATION

1. The best place to install the **ice>Link Lite AV** may be somewhere behind the car radio or close to the video screen.
2. Join the power cable leads to the radio harness or the video screen's power cable with the included ScotchLock, then plug the connector to the **ice>Link Lite AV**.
Black Ground
Red Constant +12V (Battery)
Purple Switched +12V (ACC)
3. Fix the **ice>Link Lite AV** with the supplied cable tie.
4. Connect the output signals to your entertainment system with a standard RCA extension cable. Watch colour codes when plugging the cables. Use a good quality cable to avoid accidental disconnection caused by vibration.

Next steps varies based upon the mounting options you purchased the package with.

Dock cable

1. The best place to install the **ice>Link Lite AV** may be somewhere close to the car radio.
2. Connect the 3,5mm Jack plug of the IR Eye to ice>Link Lite AV.
3. Remove the safety seal from the self adhesive back of the IR Eye and stick it to a flat surface at a convenience place.

Cradle

1. Assemble the base of the iPod Cradle with an optional vehicle specific adapter. An optional adapter is not required, however it is recommended for easy and damage-free installation.
2. Attach the base to the back with at least 2 screws.
3. Insert the front of the cradle to the base piece
4. Once set, the cradle should not be forced to a different position. To adjust, first loosen the screw, tilt and rotate to realign, and then fasten the screw again.
5. Install the distance adapter (space holder) if you are using a 30GB iPod model.

Note: Cradle has a built-in IR Eye, you do not need a separate one.

TECHNICAL DATA

| | |
|----------------------------------|---------------------------|
| Dimensions: | 104x30x30 mm |
| Power supply: | 9-16 V DC |
| Active / Standby current: | < 75 mA / 0 mA |
| Operating / Storage temperature: | -20 - +70 C / -40 - +90 C |