

USER GUIDE Rockaway

Bluetooth® stereo headset

BIG SOUND - NO CORDS

Rockaway is a Bluetooth stereo headset that lets you to listen to your favorite music in high quality audio and even take calls - without getting tangled up in cords. Just connect to any Bluetooth enabled music player, phone, PC, laptop or tablet and move to the beat!



To enjoy Rockaway with your phone, laptop or MP3 Player make sure your device supports these profiles:


- _ Bluetooth Handsfree
- _ Bluetooth Audio / Video Remote Control
- _ Bluetooth Advanced Audio / Video Distribution

HEADSET OVERVIEW





- _ exchangeable earpieces
- _ charging interface
- _ remote control
- _ MFB = Multi-function button
- _ volume up
- _ volume down
- _ LED

HOW TO WEAR





1. Choose best fitting earpiece with respect to comfort and noise reduction, start with smallest size
2. Attach the clip with cable to your shirt
3. Put the headset into your ears and enjoy

CHARGING



- _ Open the cap of your right earpiece to charge it via PC or Laptop
- _ Your headset will be fully charged after approximately 2.5 hours
- _ Note: your headset is always "off" when connected to the charger to speed up the charging process



LED

turning your headset on / off

- Blue - good battery level
- Red - low battery level

connection check

- Press volume up or down - continuous blue or red while pressing - you are connected
- Press volume up or down - quick flashing blue or red 5 times = not connected

incoming call

- Flashing blue - incoming call / battery full
- Flashing red - incoming call / battery low

pairing mode

- Flashing red / blue - start pairing from your phone

charging when connected to charger

- Steady red - charging is ongoing
- Steady blue - charging is ready

TONES

battery is low

Two tones to inform you that you need to charge your headset

voice dial

After a long press on the MFB you will hear first a tone from your headset and then from your mobile phone to confirm that voice dial is activated

connection loss / failure

You will hear two short tones

maximum / minimum volume:

You will hear a tone at the maximum or minimum volume

held call:

You will hear a tone every 5 seconds to remind you that someone is waiting

PAIRING

Before you can use your headset you need to pair it once with your device. After a successful pairing the headset will remember your device and will automatically reconnect to your headset as soon as it is turned on and is in range.

1. Turn on the Bluetooth function on your phone and select "add new Bluetooth device" or "search for Bluetooth devices"
2. Turn on your Rockaway with a long press of the Multi - function button in the middle. Now it will start to flash red / blue alternately.
3. Choose novero Rockaway out of the Bluetooth list on your phone and connect it. If it asks you for a PIN it is always "0000"
4. Allow Rockaway to permanently be connected
5. Rockaway can be paired with up to 8 devices.
6. If it doesn't start to flash red / blue automatically please power up again and hold the MFB for 4 seconds until it starts to flash red / blue. You can also press volume up and down simultaneously, when the headset is powered on, to enter the pairing mode.

TURN ON / OFF

to turn the headset on
Press the MFB for 1 second until the LED turns on

to turn the headset off
Press the MFB for 4 seconds

SLEEP MODE

Rockaway supports a low power sleep battery mode to optimize power consumption and which allows to have a quick startup if device is not switched off.

turning sleep mode on
When there is no activity Rockaway will automatically go to low power mode to save energy.

PHONE CALLS

to make a call
Dial the number from your phone or activate voice dial with a long press on the MFB

to answer a call
Short press of the MFB

to end a call
Short press of the MFB

to reject an incoming call
Long press of the MFB

to redial the last dialed number
Double press of the MFB

to mute your mic
Use this function directly on your phone

MUSIC LISTENING

to listen to music
Press the MFB shortly*

to pause the music
Press the MFB shortly

to skip to next / previous track
Long press on volume up / volume down

to change music volume
Short press on volume up / volume down

to make a call while listening to music
Press the MFB 1 second to activate voice dial or just enter your phone book on your device

*if this function is not supported by your player you have to start it manual

ADVANCED CALLS

to answer an incoming second call
Short press of MFB

to reject a second incoming call
Long press of MFB

to switch between two active calls
Long press of MFB

to end one call and to switch to the other
Short press of MFB

to activate a private call from phone
Press MFB to route audio to the headset

SPECIFICATION

headset weight: app. 10 grams

operating range: 10 meters (33 feet)

battery: Li-ion battery, built in, rechargeable

talk-time / play-time: up to 5,5 hours

stand-by time: approx. 250 hours

supported profiles: Bluetooth 2.1, Handsfree Profile 1.5, Headset Profile 1.1, A2DP 1.2, AVRCP 1.4

FAQ

no connection to phone
Check that your headset has a full battery and that your phone is Bluetooth enabled. Try the pairing procedure again and make sure your headset is not still paired with another device. Please press volume + and volume - for 10 seconds to do a factory reset.

voice dial does not work
Make sure your phone / device supports voice dialing; make sure you have already recorded your voice tags to your phone if needed

you can't hear music through your headset
Check that the headset is connected and that you chose the right gateway in your music player

automatic sleep mode
If you don't connect your phone with your headset it will go into sleep mode after some time

no LED reaction of Rockaway at all
Please try first to power it on, if that does not work,

please charge your headset over night

poor audio quality
Please check different earpieces to see if low frequency response changes significantly

no sound in your headset:
Check that the volume is adjusted correctly. Check that your headset is connected with your device. Check that your headset and device are turned on. You should then hear a sound from your headset. Check that your headset and device are charged.

if you cannot pair your headset:
Check that the headset is not already connected with your device. If not, then repeat the pairing procedure, or press the power button for a long period (4 sec.) to enter manual the pairing mode

if you hear static or noise in your headset:
Check that the headset is close to your mobile device. If not, move the headset closer to the device.

FACTORY RESET

to reset your headset:

Press the MFB until it flashes blue / red. Now press volume up and volume down at the same time for 10 - 15 seconds.

DELETE PAIRING LIST

to delete pairing list:

Press the MFB until it flashes blue / red. Now press volume up and volume down at the same time for 10 - 15 seconds to delete the pairing list.

* after a factory reset or after deleting the pairing list you will need to do the pairing of headset and phone again

CARE

Store Rockaway in off state and safely protected when not in use. Do not use Rockaway for sports as it is not water resistant. Store the headset **out of direct sunlight** and extreme temperatures (above 45°C / 113°F or below - 10°C / 14°F), as this may shorten the Li-ion battery life, affect the operation or degrade the performance of your headset.

Store the headset **away from magnetic strips** (e.g. on credit cards) and electronic medical devices.

Handle your headset with care. **Do not drop, knock or shake it, or expose it to heavy dust, dirt, moisture, rain or other liquids.**

Dispose of all product parts in accordance with local standards and regulations to spare the environment and promote sustainability.

Handle your clip with care. Do not use it on sensible clothes as all clips can leave marks on your clothes.

SAFETY & DISPOSAL

before using the headset:

Turn the volume down to its lowest level. Then put the headset on and slowly adjust the volume to a comfortable level.

To prevent possible hearing damage, do not listen at high volume levels for long periods.



radio frequency exposure

Your Bluetooth Stereo Headset is radio transmitter and receiver. When in operation, it communicates with Bluetooth equipped mobile devices by receiving and transmitting radio frequency (RF) electromagnetic fields in the frequency range around 2400 - 2483,5 MHz. The output power of the radio transmitter is low, app. 0.001 watt. Your Bluetooth stereo headset is designed to operate in compliance with the RF exposure guidelines and limits set by national authorities and international health agencies when used with any compatible Bluetooth device.

using Rockaway

Keep the volume at the lowest level possible and

avoid using the headset in noisy environments where you may be inclined to turn up the volume. – If you need to adjust the volume, do it slowly to avoid sudden, unintended loud sounds.

If you experience discomfort or ringing in your ears, stop using the headset immediately and consult a physician.

Continued use at high volumes may accustom your ears to the sound level and result in permanent damage to your hearing without any noticeable discomfort. Be cautious about wearing your headset while engaging in any activity that requires your full attention like driving for example. Remove and turn off your headset to keep you from being distracted and avoid accidents.

using your headset while operating

A motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and is illegal in some jurisdictions. Please respect local laws. If you use a pacemaker, hearing aid or other electronic medical device, please consult your physician before using the headset.

never try to dismantle the product yourself. None of the internal components can be replaced or repaired by users. Only authorized dealers or service centres may open the product. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, contact your dealer.

keep out of reach of children

Contains small parts - keep away from children. The plastic bags, which this product and its parts are wrapped in, are not toys for children. The bags themselves or the many small parts they contain may cause choking if ingested.

ACA TS028 – Ignition of flammable atmospheres

Do not use your headset in environments with risk of ignition of flammable gases.

disposing of Rockaway

Do not attempt to replace the built-in Li-ion battery in your headset. Dispose of all product parts in accordance with local regulations. If in doubt, please consult your local authorities.



The crossed - out wheeled bin means that within the European Union the product must be taken to a separate collection facility at the product's end - of - life. Do not dispose of these products as unsorted municipal waste.

Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of novero is prohibited. novero® is a registered trademark. Other product and company names mentioned herein may be trademarks or trade names of their respective owners.

novero products are trademarks or registered trademarks of novero GmbH & novero international. © 2011 novero. All rights reserved

For recycling companies only: To remove the Li-ion

battery for recycling, push the earpiece open by inserting a screwdriver into the USB port and breaking the plastics. More information on www.novero.com

WARRANTY

Rockaway has a limited one - year (1) warranty. novero warrants this product to be free from defects in materials and workmanship (subject to the terms set forth below) for a period of one (1) year from the date of purchase (“warranty period”). During the warranty period, novero will repair or replace this product or any defective parts at novero’s discretion (“warranty service”). If repair or replacement is not commercially practicable or cannot be completed in a timely manner, novero may choose to issue you a refund of the purchase price paid for the affected product. Repair or replacement under the terms of this warranty does not give the right to any extension or new beginning of the warranty period. The warranty does not cover normal wear and tear or defects caused by rough handling. Claims under the warranty: To obtain warranty ser

vice, please contact the novero dealer from whom you purchased this product or visit www.novero.com for further information about customer service. If you like to extend your warranty please visit www.novero.com. You will need

CERTIFICATION & SAFETY

to return this product to the place where you have bought it in either the original box or packaging affording an equal degree of protection. You will bear the cost of shipping the product to novero. If the product is covered by the warranty, novero will bear the cost of shipping the product back to you after completion of the warranty service. Return shipping will be charged to you for products not covered by the warranty or requiring no warranty service. For more support and further information, please go to www.novero.com

Declaration of Conformity

Hereby, novero, declares that this NBHS-4 product is in compliance with the essential requirements and other relevant provisions of Directive 1999 / 5 / EC.

A copy of the Declaration of Conformity can be found at www.novero.com/declaration_of_conformity

FCC/Industry Canada notice

This device complies with Part 15 of the FCC Rules and Industry Canada Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference; and
2. This device must accept any interference received, including interference that may cause undesired operation.



FCC ID: ZORNBHS-4 IC: 7847C-NBHS4

NOTE: FCC and Industry Canada Rules Radiation Exposure Statement: This equipment complies with FCC and Industry Canada Rules radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: Changes or modifications not expressly approved by novero could void the user's authority to operate the equipment. Bluetooth® is a registered trademark of Bluetooth SIG, Inc.

Sales Package text:

NBHS-4 Bluetooth Stereo Headset
Charging Cable
Carrying case
Clip & User Guide

- wireless music streaming
- make handsfree phone calls
- 5,5 h playtime, 250 h stand-by
- BT - headset, clip, charging cable earpieces, Quickguide included

only 10 gram weight

The availability of particular products may vary by region. Please check with the novero dealer nearest you.

Unauthorized changes or modifications to this device may void the user's authority to operate the equipment.

Export controls: This device may contain commodities, technology or software subject to export laws and regulations from the US and other countries. Diversion contrary to law is prohibited.

NOTES