

# WIRELESS LIGHTING

- SHOCK RESISTANT + UV RESISTANT + CHLORINE RESISTANT + SALTWATER RESISTANT
- WATERPROOF IP68
- RECHARGEABLE LI-POLYMER BATTERIES
- CHARGING BY INDUCTIVE CONTACTLESS CHARGER BASE
- LOW ENERGY LED LIGHTS (LIFETIME EXCEEDING 50.000 HOURS)
- 24 PRESET COLOURS INCLUDING 2 TYPES OF CANDLE EFFECT "FLICKERING YELLOW"
- SELF CHANGING SLOW MOTION MIX COLOUR MODE (160.000 COLOURS) + FIX A COLOUR
- 4 STEP BRIGHTNESS MODE
- RETRACTABLE METAL HANGER RING
- I/R REMOTE CONTROL

ENGLISH  
NEDERLANDS  
FRANCAIS  
DEUTSCH  
ESPAGNOL  
ITALIANO  
SUOMI  
русский

WIRELESS LED LAMP  
DRAADLOZE LED LAMP  
LAMPE A LED SANS FIL  
DRAHTLOSE LED-LAMPE  
LÁMPARA LED SIN CABLE  
LAMPADA LED SENZA FILI  
JOHDOTON LED-LAMPPU  
БЕСПРОВОДНАЯ СВЕТОДИОДНАЯ  
ЛАМПА

ENGLISH: Read the user instructions before use  
NEDERLANDS: Lees de gebruiksaanwijzing voor gebruik  
FRANCAIS: Lire impérativement les instructions avant emploi  
DEUTSCH: Vor der Benutzung unbedingt diese Bedienungsanleitung lesen  
ESPAGNOL: Lea las instrucciones de uso antes de utilizar  
ITALIANO: Prima dell'utilizzo leggere attentamente le istruzioni  
SUOMI: Lue käyttöohjeet ennen käyttöä  
РУССКИЙ: Перед использованием прочтите инструкцию по эксплуатации



## ENGLISH

Thank you for having selected an IMAGILIGHTS® lamp.

This multicolour ambiance LED lamp is rechargeable, waterproof and highly resistant to shock.

It may be used inside, outdoors, suspended or not, and in a swimming pool.

This lamp is resistant to UV radiation, chlorinated water, and saltwater.

### Pack contents

1. Lamp
2. Induction charger
3. Electrical adapter
4. Infrared remote control (not included with models 20, 20H, 21, 21H, 22, 22H, 30, 30H, 31, 31H, 32 & 32H )
5. User guide
6. Textile lanyard to hang the lamp (depending on the model)

### Usage precautions

Carefully read this guide before using the device and keep it handy for future use.

Use the lamp in conformity with the utilization precautions ; failure to do so will void any warranty.

IMAGILIGHTS® disclaims any responsibility for the incorrect use of the product or the transformer with another product which would be defective, dangerous or inappropriate.

### Charger

- Do not use it near a heat source or expose it to fire.
- Keep it outside the reach of young children.
- Do not touch the charger or the charger base while charging.
- Do not try to open the charger ; in case of faultiness, please return it to your vendor.
- Disconnect the charger after charging the lamp.
- Do not use outdoors and keep it in a dry area.

### Lamp

- Do not expose the lamp to fire or a heat source.
- Do not try to dismount or open the lamp to avoid any risk of electrical shock or altering its waterproofing ; failure to comply will automatically cancel your warranty.
- Do not connect the lamp's base to another device.
- Do not try to charge the lamp with a charger other than the one supplied in your pack.
- Although solid, bad handling could scratch the diffuser.
- Avoid extended periods in water, the pool or bright sunshine.

### First usage

Connect the charger.

Fully charge the lamp's battery by placing the lamp on the charger for at least 6 hours.

A RED charge indicator appears on the charger when loading.

The battery supplied with this pack does not have a charge accumulator and will require 5 or 6 complete charges/discharges before it is fully powered.

### Lamp charging

- Charging : a RED luminous indicator on the induction charger plate indicates to you that the lamp is charging.
- End of charging : a GREEN luminous indicator on the induction charger plate indicates to you that the lamp is fully charged.

Important: the light automatically turns off when placed on the induction charger plate. This is to protect the long life of the battery and to assure that charging and discharging is not done simultaneously.

**READ "IMPORTANT NOTICE" ON LAST PAGE OF THE ENGLISH VERSION!!!**

## Autonomy

To guarantee the maximum autonomy of your product, please conform to the «first usage» precautions.


LED MODULE	MODEL N° (see models on next pages)	WATT CONSUMPTION	BATTERY/M AH	CHARGING TIME/HOURS	HOURS OF LIGHT
12 LED	20, 20H, 21, 21H, 22, 22H, 30, 30H, 31, 31H, 32, 32H	2,04	1200	4-5	9 up to 32
27 LED	1, 6, 8	1,62	2000	6	13 up to 50
56 LED	2, 3, 4, 5, 7, 9, 10, 11, 12, 13, 14, 15, 18, 19, 33, 34, 35, 36	3,36	4000	12	14 up to 60
56 FLAT LED	16, 17	3,36	2800	9	8 up to 26

LED MODEL	TYPE	HOURS OF LIGHT	LED MODEL	TYPE	HOURS OF LIGHT
12 LED	High intensity in white color	9	56 LED	High intensity in white color	14
	Low intensity in white color	32		Low intensity in white color	60
	Color mix	9		Color mix	18
	Color fix	13		Color fix	37
	Candle effect	11		Candle effect	21
27 LED	High intensity in white color	13	56 FLAT LED	High intensity in white color	8
	Low intensity in white color	50		Low intensity in white color	26
	Color mix	15		Color mix	9
	Color fix	28		Color fix	12
	Candle effect	18		Candle effect	9

### Information:

- \* The colour "NATURAL WHITE" is the colour demanding the most power from the battery.
  - \* The colour "WARM WHITE" is the colour demanding the most power from the battery. (ONLY FOR THE SHAPE MODELS N° 20, 20H, 21, 21H, 22, 22H, 30, 30H, 31, 31H, 32, 32H)
- The life time depends on the indoor/outdoor temperature.

## Usage instructions of the buttons on the back of the lamp



## 1 + 2 : COLOURS (UP and DOWN)

These are the 24 pre-programmed colors.

## 3 : MIX /PAUSE

When this button is pressed, the unit will start a very progressive 160.000 color "scroll" that will take around 14 minutes, and will continue without interruption.

When this button is pressed again, then that chosen color will be fixed.


When again pressed, then the cycle of 160.000 colors will continue.

4 : BRIGHTNESS: This is the intensity of the light that can be set in 4 steps.

5 : RETRACTABLE METAL HANGER RING: This is to hang the unit.

6 : The UP button will function as an ON/OFF command when held for 2 seconds.

### Usage instructions of the buttons on the remote controller



**A** : ON/OFF

**B** : MIX/PAUSE

When this button is pressed, the unit will start a very progressive 160.000 color "scroll" that will take around 14 minutes, and will continue its cycle without interruption.

When this button is again pressed, then that chosen color will be fixed.

When again pressed, then the cycle of 160.000 colors will continue.

**C + D** : SELECT COLOURS with the words "UP and DOWN"

These are the 24 pre-programmed colors, up and down.

**E** : BRIGHTNESS (4 steps)

This is the intensity of the light that can be set in 4 steps.

**F** : CANDLE MODE (2 steps)

The candle effect in 2 different modes = yellow and orange.

The remote operates on one Lithium battery CR2025 3V

### The colors and the intensity of the light (=brightness)


- 24 pre-programmed colors including 2 different types of candle effect
- Self changing slow motion mix color mode (160.000 colors) + with the possibility to fix a color
- The intensity (brightness) of the light in 4 steps

The pre-programmed colours :

1	NATURAL WHITE	9	YELLOW	17	DARK BLUE
2	GALACTIC WHITE	10	WHITE/GREEN	18	PINK LIGHT
3	CANDLE MODE LIGHT	11	LIGHT GREEN	19	PINK MEDIUM
4	CANDLE MODE DARK	12	DARK GREEN	20	PINK DARK
5	DARK RED	13	TURQUOISE LIGHT	21	SALMON
6	LIGHT RED	14	BLUE/TURQUOISE	22	PURPLE LIGHT
7	ORANGE LIGHT	15	BLUE/GREEN	23	PURPLE DARK
8	ORANGE DARK	16	PURPLE/BLUE	24	PINK/PURPLE

Important : the 1<sup>st</sup> colour used FOR MODELS N° 20, 21, 22, 30, 31, 32, 20H, 21H, 22H, 30H, 31H, 32H is WARM WHITE

## CHARGER MODELS



OPTIONAL STACKABLE MULTI INDUCTION CHARGER PLATE ONLY FOR MODELS N° 20, 21, 22, 30, 31, 32 AND MODELS 20H, 21H, 22H, 30H, 31H, 32H (PROFESSIONAL USE) CODE: INDU 8 MULTI CHARGER



## MODELS

MOD N°	MODEL NAME	MODEL SIZE	MOD N°	MODEL NAME	MODEL SIZE
001	BALL 25	Ø 25	019	SAMOA SEAT	Ø 56 x (H)47,6
002	BALL 35	Ø 35	020	BULLIT	Ø 10x(H)15
003	BALL 50	Ø 50	020H	BULLIT (HORECA)	Ø 10x(H)15
004	BYBLOS	(W)31x(H)32	021	CYLINDRO	Ø 10x(H)15
005	TEARDROP	(W)28,5x(H)30,5	021H	CYLINDRO (HORECA)	Ø 10x(H)15
006	CONE	(W)21,5x(H)24,5	022	CUBIC	Ø 10x(H)15
007	FLAT BALL	(W)35x(H)27	022H	CUBIC (HORECA)	Ø 10x(H)15
008	EGG SMALL	(W)15,5x(H)21	023	INDU 8 MULTI CHARGER	(L)45x(W)26,8x(H)3,8
009	EGG BIG	(W)29x(H)40	030	MATROUSHKA	Ø 10x(H)15
010	CUBE 40	SQUARE 40	030H	MATROUSHKA (HORECA)	Ø 10x(H)15
011	LANTERN	(W)29x(H)40	031	GHERKIN	Ø 10x(H)15
012	CHAMPAGNE	(L)63,793x(W)27.3x(H)29,2	031H	GHERKIN ( HORECA)	Ø 10x(H)15
013	HALF BALL 35	Ø 35x(H)17,5	032	SHADOW	Ø 10x(H)15
014	HALF BALL 50	Ø 50x(H)25	032H	SHADOW (HORECA)	Ø 10x(H)15
015	TUBE	(Ø low)19x(Ø up)14,1x(H)70	033	TEARDROP BIG	(W)50x(H)51
016	TRON ROUND	Ø 40,48x(H)4,8	034	DIAMOND	(W)27,3x(H)40,2
017	TRON RECTANGULAR	(W)35,48x(L)56,48x(H)4,8	035	BARELO	Ø 47,5x(H)43
018	VIGGO	(W)24,98x(D)34x(H)35,18	036	MIGHT-E	(L)106,9x(W)39,9x(H)29,6

Please visit our website for more models: [WWW.IMAGILIGHTS.COM](http://WWW.IMAGILIGHTS.COM)

### Technical data

- 12 or 27 or 56 or 56 flat led (depending the shape) high intensity white and color LED's offering 160 000 colors.
  - Waterproof module : Class IP 68.
  - Charger : Input 100-240V AC~50/60Hz – Output DC 7.5V 1.5A.
  - Battery : Li-Polymer 1200 or 2000 or 4000 or 2800 mAh. (depending the shape of the lamp)
  - Polyethylene plastic diffuser, resistant to UV and shocks.
  - Lamp's ideal operating temperature range : 10°C to 45°C.
  - Manufacturer's warranty : 1 year ; certifications : see last page of the user guide.
- !!! Important: Charger INDU 8 (only operates with the following adapter): Input 100-240V AC~50/60Hz – output DC 7.5V 5A.

### Recycling

You should not throw this device away in your household garbage.

Contact the appropriate service in your community to learn what is the best way to dispose of this device.

In fact, electrical and electronic products contain substances harmful to human health and the environment and must be adequately recycled.

### Information

IMAGILIGHTS®

The components of this lamp are not replaceable.

If any part is damaged, this "product" or "light" must be discarded.

info@imagilights.com

www.imagilights.com

### IMPORTANT NOTICE

- It is recommended to empty (discharge) the full capacity of the battery, before recharging fully.
- Once fully loaded and a GREEN luminous indicator on the induction charger plate is shown, please remove the unit from the plate.
- Do not leave the unit too long in the water, to avoid dirty water markings on the level of the waterline.
- The light automatically turns off when placed on the induction charger plate, this to protect the long life of the battery and to assure that charging and discharging is not done simultaneously.

### Legal information

IMAGILIGHTS® Cordless Lamps are covered by Design Registration, Copyright and Patent Pending. All rights reserved. All shapes and models are registered. Patented LED module.

Patented wireless induction charger. Any tampering with or repairing the unit voids the warranty. (the unit is equipped with special labels to avoid tampering).

WWW.IMAGILIGHTS.COM