

USB Storage Media**Operating Instructions****USM512EX/1GEX/2GEX**

© 2005 Sony Corporation Printed in Malaysia

C N50**English****WARNING**

Keep away from children. If swallowed, promptly see a doctor.
To prevent fire or shock hazard, do not expose the unit to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Owner's Record

The model number and serial number are located on the side of the product. Record the serial number in the space provided here. Refer to the model and serial number when you call the Sony Customer Information Center.

Model No. USM512EX, USM1GEX, USM2GEX

Serial No. 1-800-942-SONY(7669). The number below is for the FCC related matters only.

Regulatory Information:

Declaration of Conformity
Trade Name : SONY
Model : USM512E, USM1GEX, USM2GE
Responsible Party : Sony Electronics Inc.
Address : 1640 W. Bernardo Dr., San Diego, CA 92127 U.S.A.
Telephone Number : 858-942-2230

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION:

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Resettling or reseating the existing antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Contact your telephone company or experienced radio/TV technician for help.

The shielded interface cables and connectors must be used in order to comply with the limits for digital device pursuant to Subpart B of Part 15 of FCC Rules.

For Customers in CANADA

This Class B digital apparatus complies with Canadian ICES-003.

For Customers in Europe

This product conforms to the following European Directives,

93/68/EEC (CE Marking Directive).

This product complies with EN55022 Class B and EN55024 for use in the following areas: residential, commercial, and light-industrial.

When Using USB Storage Media for the First Time (Installing the Device Driver)

Ordinarily, the device driver is installed automatically when you connect the Micro Vault. However, with some USB 2.0 cards or boards, you may need to initiate installation manually. Follow the instructions displayed on the screen to search for a suitable driver.

Note: Windows 98 and Windows 98SE are not supported.

Basic Operation**Note:**

Please remove the Micro Vault properly following the procedure described in this manual. Otherwise, data may not be recorded correctly.

If the USB port connector is not easily accessible, you can use a USB hub to attach the Micro Vault to the USB port connector on your computer.

When using a hub, make sure it is fully powered.

Remove the cap from the Micro Vault and connect it to a USB port on the computer.

When running Windows Me, Windows 2000, or Windows XP

Once the Micro Vault is connected to the computer, the drive icon for the Micro Vault device appears. (The drive name varies, depending on your computer system.)

You now copy and save data on the Micro Vault by dragging files and folders on the drive icon, just as you would when copying data to a hard disk or to a floppy disk.

When running Mac OS 9.0 and higher

The Micro Vault icon is the Trash. After confirming that the Micro Vault is in standby mode, disconnect the Micro Vault device.

You can now copy and save data on the Micro Vault by dragging files and folders on the drive icon, just as you would when copying data to a hard disk or to a floppy disk.

Meanings of the Indicator Light

When the Micro Vault is in use, the indicator light indicates its status as follows.

Indicator Light Status	Meaning
Off	Standby
On	Data transfer in progress (Do not remove the Micro Vault while the indicator light is flashing.)

Disconnection

When running Windows Me or Windows 2000

In the Windows taskbar, click the Start button in the lower right portion of the screen. In the window that appears, select the name of the device that is to be removed, then click the Stop button. When the Stop a Hardware Device screen appears, make sure that the correct information is displayed, and then click the OK button. When the "Safe to Remove Hardware" message appears, disconnect the Micro Vault.

When running Mac OS 9.0 and higher

Drag the Micro Vault icon to the Trash. After confirming that the Micro Vault is in standby mode, disconnect the Micro Vault.

About Software Applications

You can download useful software applications from the URL below. Because the software is compressed, you must extract it and copy each folder to the Micro Vault device in order to use it.

<http://www.sony.net/Products/Media/Microvault/>

Notes on Use

If the software becomes unstable during use, visit the following URL to download and install the latest version of the software.

<http://www.sony.net/Products/Media/Microvault/>

• When formating the device, use the format software which you can download from the website. To avoid any changes of the specifications, do not format the device in any other way.

• The Micro Vault may not function correctly if it is connected to the computer when the power cord is not connected. Please connect the power cord before connecting the Micro Vault from the computer before performing any of these operations.

• The edge of the Micro Vault cap has a hole for a strap or a ring. Be careful if you let the Micro Vault hang from a strap or ring while you are using it, because there is a chance that the Micro Vault could fall from the cap and become lost.

• Do not place unit in locations that are:

- extremely hot or cold
- very humid
- exposed to vibration
- exposed to corrosive gases
- exposed to direct sunlight
- cleaning

Clean the unit with a soft, dry cloth or a soft cloth lightly moistened with a mild detergent solution.

• Do not use type of solvent, such as alcohol or benzene, which may damage the finish.

• The Micro Vault is made of Sony Corporation.

• Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and other countries.

• Mac and Macintosh are trademarks of Apple Computer, Inc., registered in the United States and other countries.

• Other system names and product names that appear in this manual are registered trademarks or trademarks of their respective owners. Note that the ® and ™ symbols are not used in this manual.

• Our products work best when connected to a USB storage media itself, when in normal condition in accordance with the operating instructions and with the accessories that were included with this unit in the specified or recommended system environment. Services provided by the Company, such as user support, are also subject to these restrictions.

• The Company cannot accept liability for damage or loss resulting from the use of this unit, or for any claim from a third party.

• The Company cannot accept liability for damage or loss resulting from the use of hardware, software, or peripherals; operating conflicts with other installed software; data loss; or other accidental or unavoidable damages.

• The Company cannot accept any liability for financial damages, lost profits, claims from third parties, etc., arising from the use of the software provided with this unit.

• The software specifications may be subject to change without notice.

Frans**AVERTISSEMENT**

Tenir hors de portée des enfants. En cas d'ingestion, consulter un médecin ou un centre médical.

Afin d'éviter tout risque d'incendie ou d'électrocution, ne pas exposer cet appareil à la pluie ou à l'humidité.

Pour éviter toute électrocution, ne pas ouvrir le boîtier. Confier l'entretien à un technicien qualifié uniquement.

Informations client

La référence du modèle et le numéro de série sont indiqués sur le côté du produit. Noter le numéro de série dans l'espace ci-dessous pour être prêt à cet effet. Indiquez la référence du modèle et le numéro de série lorsque vous contactez le Centre d'information client Sony.

Référence du modèle USM512EX, USM1GEX, USM2GEX
Numéro de série _____

Pour les utilisateurs au Canada

Cet appareil conforme à la norme de la classe B est conforme à la norme NMB-003 du Canada.

Pour les clients en Europe

Cette unité est conforme aux directives européennes suivantes :

93/36/EEC (directive CE-маркировка)

Ce produit est conforme aux normes de classification EN 55022 Classe B et EN 55024 pour une utilisation dans les environnements suivants : zones résidentielles, commerciales et d'industrie légère.

Lors de la première mise en service du support d'enregistrement USB (Installation du pilote du périphérique)

Normalement, le pilote de l'appareil est installé automatiquement lors du raccordement du Micro Vault.

Cependant, le lancement manuel de l'installation peut être nécessaire avec certaines cartes USB 2.0.

Suivez les instructions qui s'affichent à l'écran pour rechercher le pilote approprié.

Remarque: Windows 98 & Windows 98SE ne sont pas pris en charge.

Fonctionnement de base

Remarque: Veuillez suivre la procédure décrite dans ce mode d'emploi pour retirer correctement le Micro Vault, sinon, il est possible que les données ne soient pas enregistrées correctement.

• Si le port USB de votre ordinateur est difficile d'accès, vous pouvez utiliser un concentrateur USB (hub) pour raccorder le Micro Vault au port USB de votre ordinateur.

• Lorsque vous utilisez un concentrateur, veillez à ce qu'il soit bien branché.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

• Utilisez toujours une alimentation stable pour le Micro Vault.

