

Belkin® USB Sync Charger for iPAQ™ H3800 series User Instructions:

Charging your iPAQ handheld through a powered USB port:

- 1 Plug the Sync Charger's USB connector into an available USB port on a desktop or laptop computer.
- 2 Slide the cables switch to the Charge position (fig. 1)
- 3 Plug the other end of the Sync Charger cable into the sync connector at the base of the iPAQ handheld. The iPAQ's charging indicator will flash while charging.
- 4 To remove the cable from the iPAQ's connector, depress both release levers located on either side of the Sync Charger's connector and gently slide out.

Charging your iPAQ handheld through an automobile cigarette lighter socket:


- 1 Plug the USB cigarette lighter adapter into the car's cigarette lighter socket
- 2 Slide the cables switch to the Charge position (fig. 1.)
- 3 Plug the Sync Charger's USB connector into the USB receptacle located in the tip of the cigarette lighter adapter.
- 4 Plug the other end of the Sync Charger cable into the sync connector at the base of the iPAQ handheld. The iPAQ's charging indicator will flash while charging.

Length of charge times will vary. A fully discharged iPAQ handheld should charge completely with 2.5 hours if not operated during the charge cycle.

Synchronizing your iPAQ series handheld:

Note: To enable the synchronization function, ActiveSync® Desktop software must be previously installed on the host computer using a Microsoft® Windows operating system with USB support.

- 1 Plug the Sync Charger's USB connector into an available USB port on a desktop or laptop computer.
- 2 Slide the cables switch to the Sync position (fig. 2)
- 3 With the iPAQ handheld powered on, plug the Sync Charger's connector into the sync connector at the base of the iPAQ handheld.
- 4 If ActiveSync doesn't automatically synchronize, select ActiveSync from the Start Menu, select tools, and then select options.
- 5 Click "Enable synchronization when cradled using:" and select "USB". Click OK and Exit. ActiveSync should begin to synchronize your iPAQ with your PC.



Belkin Components, Ltd.
Unit 13 • Gatelodge Close • Round Spinney
Northampton • NN3 8RX • United Kingdom
Tel: +44 (0) 1604678300
Fax: +44 (0) 1604678330

Belkin Components
501 West Walnut Street
Compton • CA • 90220 • USA
Tel: 310.898.1100
Fax: 310.898.1111

Belkin Components, Ltd.
7 Bowen Crescent • West Gosford
NSW 2250 • Australia
Tel: +61 (2) 4372 8600
Fax: +61 (2) 4325 4277

© 2002 Belkin Components. All rights reserved. All trade names are registered trademarks of respective manufacturers listed. **P73998**