




HDD Docking RX-DU100/RX-DUS100 USER'S Manual



*Thank you for purchasing a quality Rosewill Product.
Please register your product at : www.rosewill.com
for complete warranty information and future support for your product.*

RX-DU100

Specification

- Size : 2.5" & 3.5"
- Internal Interface : SATA
- External Interface : USB 2.0
- Dimensions :
130(L) X 94(W) X 68(H) mm

Features

- Plug and play
- Support up to 2TB HDD
- Supports transfer rates up to 480 Mbps with USB 2.0
- Hot-Swap capability for rapid multi HDDs
- LED indicator for power on and HDD access

Package Contents

- HDD Docking
- USB Cable
- Power Adapter

RX-DUS100

Specification

- Size : 2.5" & 3.5"
- Internal Interface : SATA
- External Interface : USB 2.0 & eSATA
- Dimensions :
130(L) X 94(W) X 68(H) mm

Features


- Plug and play
- Support up to 2TB HDD
- Supports transfer rates up to 480 Mbps with USB 2.0
- Supports transfer rates up to 3 Gbps with eSATA
- Hot-Swap capability for rapid multi HDDs
- LED indicator for power on and HDD access

Package Contents

- HDD Docking
- USB Cable
- eSATA Cable
- Power Adapter


Hardware Installation

Top



1. Push button to release HDD from docking
2. For 2.5" HDD
3. For 3.5" HDD
4. Power and Access LED

Back RX-DU100



RX-DUS100

