

## **Wireless Camera System - Get Started Quickly!**





Unpack these items.



Connect the camera to its power supply and plug it into a wall outlet.




Connect the wireless video receiver to power and plug it into a wall outlet.



Connect the video receiver to your TV.







Select your TV's video input (or try channel 0 and then Channel Down). The camera's picture should appear.

**GUIDE:** 

