

nextar 

See Things Differently™

3.5 INCH DIGITAL PHOTO FRAME



 **M1** my first
DIGITAL PICTURE FRAME

INSTRUCTION MANUAL

Item#N3-504

TABLE OF CONTENTS

Safety precautions.....	2
Introduction.....	2
1. Features.....	4
2. Packaging Check List.....	4
3. Product Diagram.....	5
A. Top View.....	5
B. Front View.....	5
C. Side View.....	6
D. Bottom View.....	6
Using Your Digital Photo Frame.....	7
Technical Notes.....	8
Question/Troubleshooting Guide.....	9
Specifications.....	10
FCC Compliance.....	11

Safety precautions

- 1) Use only the supplied Input 100-240V, Output 5V adapter.
- 2) Turn off power before cleaning. Use only a soft cloth to clean the unit. Do not use liquid cleaners.
- 3) Avoid exposing the unit to extreme heat.
- 4) Disassembling the Digital Photo Frame may result in electric shock and will void your warranty.

Introduction

Your new Digital Photo Frame is a convenient and innovative way to display your digital photos. With it, you can easily view digital photos directly from your camera's memory card; no computer or printer required.

It supports all of the most popular memory card types on the market, including SD, MMC and MS. The Digital Photo Frame is light and portable; take it with you anywhere to share photos with family and friends.

This Digital Photo Frame is a step beyond the traditional photo frame. View and keep on display tens or even hundreds of digital photos without the need to pay for printing.

1. Features


- Shows sharp photos on a 3.5 inch LCD display
- Supports SD, MMC MS memory card formats
- Displays photos from memory cards
- Renders in a smooth and clear resolution of 320X240 pixels
- Offers a variety of display features, including a slide show mode

2. Packaging Check List


- Digital Photo Frame
- User Manual
- Quick Start Guide
- Power Adaptor
- USB Cable
- Magnetic Stand

3. Product Diagram

A. Top View



B. Front View



A. **MODE:** Press once to start slide show. Press and hold to turn off the screen.

B. **DOWN:** Moves the cursor down

C. **UP:** Moves the cursor up.


D. **ESC:** Return to the previous screen.

E. **ENTER:** Confirm selection/rotate/zoom


F. **LCD Display**

3. Product Diagram

C. Side View



D. Bottom View



G. USB Port: Connects to a computer through a USB cable or to an electronic socket through the power adaptor

H. Magnetic Stand: This adjustable arm supports the unit on a table top or other flat surface.

I. Memory Card Slot: Used for inserting an SD/MMC/MS card.

Using Your Digital Photo Frame

View photos from memory cards

Step 1: Install the magnetic stand for tabletop display or prepare a mount on the wall.

Step 2: Power on the unit by either:

- 1: Connecting it to an electronic socket through the provided power adapter.
- 2: Connecting it to a computer through the provided USB cable.

Step 3: Insert a memory card into the card slot at the bottom of the unit (with the card's electrical contacts facing the front of the unit.).

Step 4: Press the **UP** or **DOWN** button to select "PHOTO" on the main menu, and press the **ENTER** button to enter the photo viewer mode.

Step 5: You will see thumbnails of all of the photos on the card.

- Press the **MODE**, **UP**, and **DOWN** buttons to select a thumbnail. Press the **ENTER** button to confirm the selection and enlarge the selected photo to fill the screen.

Step 6: In full-screen mode (Single Show Mode):

- Press the **MODE** button to start the automated slide show. In slide show mode, you can press the **MODE** button repeatedly to set the time interval between slides. Press the **ESC** button to stop slide show and return to the menu.

Using Your Digital Photo Frame

- Press the **UP** and **DOWN** buttons to display the Previous/Next photo.
- Press and hold the **ENTER** button to rotate the photo 90° counter-clockwise.
- Press the **ENTER** button once to zoom. When the photo is zoomed in, you can roam on the photo by pressing the **UP**, **DOWN**, **MODE**, and **ESC** button.
- Press the **ESC** button to return to thumbnail mode.
- Press and hold the **MODE** button to enter power saving mode with the screen off.

Technical Notes

1. Your Digital Photo Frame is a sophisticated electronic unit. Do not drop or subject the unit to jarring or strong vibrations.
2. Avoid placing the Digital Photo Frame in areas of high humidity or where it might be exposed to liquids.
3. The panel is made of plastic and is susceptible to damage. Avoid using sharp objects nearby.
4. Use only a soft, dry cloth to clean the screen.

Question/Trouble-shooting Guide

This chapter presents some suggestions to trouble-shoot any problems you may encounter while using the unit. Even if the following guide fails to solve your problem, please do not disassemble the unit; just refer the problem to our professional staff. Please see below for contact details.

1. Question: What kind of photos does this unit support?

Answer: The Frame will display digital photos that are stored in the JPEG format, which is the standard format for nearly all digital cameras. Some cameras allow photos to be stored as TIFF or RAW files as well as JPEG, but only the JPEG format is compatible with the Frame.

2. Question: What should I do if the system does not respond when the unit is turned on?

Answer: Please make sure the unit is properly connected to a power source. If so, turn the unit off, reconnect the power and turn it on again.

3. Question: Why is the memory card not recognized?

Answer: The memory card might be inserted improperly or not pushed in all the way. If the card is inserted in the right direction and is still not recognized, turn off the unit, remove and reinsert the card, and start again.

Specifications

Panel Size	3.5 inches TFT
Resolution	320 x 240
File Format Type	JPEG
Max. Photo Size	16 megapixels
Power Requirement	5V DC
Operating Temperature	-10~55°C, 14~131°F
Storage Temperature	-20~55°C, -4~131°F

This manual was correct and complete at the time of printing. However, specifications and updates can occur at any time without prior notice. No part of this manual may be copied, republished, reproduced, transmitted, or distributed in any way without the prior written consent of Nextar, Inc. Any unauthorized distribution of this manual is expressly forbidden.

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with limits for Class B digital devices, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference through one or more of the following measures:

1. Reorient or relocate the receiving antenna. 2. Increase the separation between the equipment and the receiver. Connect the equipment to an outlet on a circuit different from that to which the receiver is connected. 3. Consult the dealer or an experienced radio/TV technician for help.

Nextar™ is a trademark of Nextar (Hong Kong) Limited.

Nextar may find it necessary to modify, amend or otherwise change or update this manual. We reserve the right to do this at any time, without any prior notice. All specifications and features are subject to change without notice. All screen shots shown are simulated and may not represent the actual screen on production units sold to consumers.

For instruction manuals, updated drivers or other information, be sure to visit our website at:

www.nextar.com

Or write to us at:

© NEXTAR, INC. AND ITS AFFILIATES

1661 FAIRPLEX DRIVE

LA VERNE, CA 91750. USA

All products distributed by Nextar, Inc. unless otherwise indicated

Made in China

© 2005 Nextar (Hong Kong) Limited. Nextar (Hong Kong) Limited claims trademark rights in Nextar™. All other brand names, product names and trademarks are the property of their registered owners.