

# Owner's Manual

MOON Classic Series


i-3 *SE*

*Integrated Amplifier*




M O O N

### Important Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves or another apparatus that produces heat.
9. Do not defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for safety. If the provided plug does not fit into the outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments and accessories specified by the manufacturer.
12.  Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when the power cord or plug has been damaged; liquid has been spilled or objects have fallen into the apparatus; or the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. No naked flame sources, such as candles, should be placed on the apparatus.

**WARNING:** TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK,  
DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.



## MOON i-3 SE Integrated Amplifier

---

### Important Safety Instructions (cont'd)



The lightning flash with the arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



Marking by the "CE" symbol (shown left) indicates compliance of this device with the EMC (Electromagnetic Compatibility) and LVD (Low Voltage Directive) standards of the European Community

***Please read all instructions and precautions carefully and completely before operating your Simaudio MOON i-3 SE Integrated Amplifier.***

1. **ALWAYS** disconnect your entire system from the AC mains before connecting or disconnecting any cables, or when cleaning any component.
  2. The MOON i-3 SE must be terminated with a three-conductor AC mains power cord which includes an earth ground connection. To prevent shock hazard, all three connections must **ALWAYS** be used. Connect the MOON i-3 SE only to an AC source of the proper voltage; Both the shipping box and rear panel serial number label will indicate the correct voltage. Use of any other voltage will likely damage the unit and void the warranty
  3. AC extension cords are **NOT** recommended for use with this product.
  4. **NEVER** use flammable or combustible chemicals for cleaning audio components.
  5. **NEVER** operate the MOON i-3 SE with any covers removed. There are no user-serviceable parts inside. An open unit, especially if it is still connected to an AC source, presents a potentially lethal shock hazard. Refer all questions to authorized service personnel only.
  6. **NEVER** wet the inside of the MOON i-3 SE with any liquid. If a liquid substance does enter your MOON i-3 SE, immediately disconnect it from the AC mains and take it to your MOON dealer for a complete check-up.
  7. **NEVER** spill or pour liquids directly onto the MOON i-3 SE.
  8. **NEVER** block air flow through ventilation slots or heatsinks.
  9. **NEVER** bypass any fuse.
  10. **NEVER** replace any fuse with a value or type other than those specified
  11. **NEVER** attempt to repair the MOON i-3 SE. If a problem occurs contact your MOON dealer.
  12. **NEVER** expose the MOON i-3 SE to extremely high or low temperatures.
  13. **NEVER** operate the MOON i-3 SE in an explosive atmosphere.
  14. **ALWAYS** keep electrical equipment out of reach of children.
  15. **ALWAYS** unplug sensitive electronic equipment during lightning storms.
-

## Table of Contents

Congratulations .....	5
Unpacking and Warnings .....	5
Introduction .....	6
Installation & Placement .....	6
Front Panel Controls .....	7
Rear Panel Connections .....	8
Operating the i-3 <i>SE</i> .....	9
Remote Control Operation .....	10
Specifications .....	11

[www.simaudio.com](http://www.simaudio.com)

---

## MOON i-3 SE Integrated Amplifier

---

### Congratulations!

Thank you for selecting the **MOON i-3 SE** Integrated Amplifier as a part of your music/cinema system. This component has been designed to offer state-of-the-art high-end performance in an elegant package, while retaining all the sonic hallmarks on which Simaudio has made its reputation. We have spared no effort to ensure that it is amongst *the finest* two-channel Integrated Amplifiers available. We have been building high-performance audio equipment for over 25 years, and the know-how gained through our cumulative experience is an important reason why **MOON** integrated amplifiers are so musically satisfying.

The performance of your **i-3 SE** will continue to improve during the first 400 hours of listening. This is the result of a “break-in” period required for the numerous high quality electronic parts used throughout this integrated amplifier.

Before setting up your new **MOON i-3 SE**, we encourage you to please read this manual thoroughly to properly acquaint yourself with its features. We hope you enjoy listening to the **MOON i-3 SE** Integrated Amplifier as much as the pride we have taken in creating this fine audio product. We understand the power and emotion of music and build our products with the goal of faithfully capturing these elusive qualities.

*The information contained in this manual is subject to change without notice. The most current version of this manual is available on our official website at <http://www.simaudio.com/manuals.htm>*

### Unpacking

The **MOON i-3 SE** Integrated Amplifier should be removed from its box with care.

The following accessories should be included inside the box with your Integrated Amplifier:

- ✓ *AC power cable*
- ✓ *'SRM' remote control with two 'AA' batteries (USA and Canada only)*
- ✓ *This owner's manual*
- ✓ *Warranty and product registration information (USA and Canada only)*

As soon as the integrated amplifier is safely removed from its box and placed down, perform a thorough physical inspection and report any physical damage to your dealer immediately. We suggest that you keep all of the original packaging, storing it in a safe, dry place in the event that you're required to transport the integrated amplifier. The customized packaging is specially designed to protect the **MOON i-3 SE** Integrated Amplifier from potential damage that may occur during shipping.

Please write the serial number of your new Simaudio **MOON i-3 SE** in the space provided below for future reference.

Serial No.: \_\_\_\_\_

# MOON i-3 SE Integrated Amplifier

---

## Introduction

Your **MOON i-3 SE** integrated amplifier incorporates many significant design features to achieve its “world class” level of performance. This is an abbreviated list of the more important features:

Proprietary “**Advanced Renaissance**” Technology which eliminates feedback. The results are as follows: Real-time amplification is achieved since interactions from the speaker back to the amplifier are virtually eliminated; More accurate musical reproduction with respect to tonality; Virtually non-existent transient intermodulation distortion (which is far more degrading to sonic performance than harmonic distortion); The elimination of common phase errors resulting from feedback.

An **oversized** power supply using a custom **proprietary toroidal transformer design** with lower magnetic, electrical and thermal loss, yielding an improved transfer and lower regulation factor, resulting in increased current speed and better dynamics.

An **extremely short capacitor-free signal path** measuring less than nineteen inches in length, from input RCA connectors to output binding posts, for a faster transient response.

A gain section that uses a Crystal microprocessor functioning as a “**shunt to ground**” that doesn't degrade sonic performance regardless of the selected setting.

**J-FET input devices** in the preamplifier section. Precision matched **Bipolar output devices** in the amplifier section, which offer superb linearity throughout the entire audio frequency spectrum.

One single-ended audio input which functions as a “**pass-through**”, bypassing the gain stage to accommodate a component such as a home-theater processor, whose own volume control is used instead.

**Class A output** to 5 watts for greater efficiency.

A **symmetrical** circuit design with **accurate matching** of the very finest high quality electronic components.

**Heavy duty gold-plated** output binding posts.

**Pure copper circuit board tracings** with extremely low impedance characteristics.

Designed to be **powered up at all times** for optimal performance.

**Low operating temperature** for a longer than normal life expectancy.

## Installation & Placement

The **MOON i-3 SE** requires reasonable ventilation to maintain an optimum and consistent operating temperature. As a result, it should be placed in a location with empty space around it for proper heat dissipation. As well, it should be placed on a solid level surface. You should avoid placing it near a heat source or inside a closed cabinet that is not well ventilated as this could compromise the integrated amplifier's performance and reliability. The **i-3 SE** uses a toroidal transformer; even though it is well shielded, you should not place the Integrated Amplifier too close to source components sensitive to EMI, such as turntables and phono preamplifiers. *You should never place another component directly on top of this integrated amplifier.*

Since household dust is an excellent insulator of heat, we suggest that you clean both of the curved side-mounted heat sinks on a regular basis. A smooth nylon brush with long bristles (ie. paint brush) is recommended for this task. Finally, you should make all of your audio signal connections prior to making the AC connection between the **i-3 SE** and the AC wall outlet.

## MOON i-3 SE Integrated Amplifier

---

### Front Panel Controls




Figure 1: MOON i-3 SE Front panel

The front panel will look similar to Figure 1 (above). The large digital display window indicates the relative gain setting (from '0' to '50') for both the left and right channels. As well, whenever you change the selected input source, it's number will appear in the window for 3 seconds before reverting back to the gain setting.

The "Stand by/On" button disengages the input section from the rest of the **i-3 SE**'s circuitry and turns off the digital display. However, when in "Stand by" mode all audio circuitry remains powered up to help maintain optimal performance. When switching back from "Stand by" to the "on" mode, both the 'input' and gain level settings will be memorized from the previous listening session. The blue pilot LED will not be illuminated when the **i-3 SE** is in "Stand by" mode.

When the i-3 is operational, holding down the "Stand by/On" for two (2) seconds will turn off the front panel digital display. Repeating this procedure will turn the front panel digital display back on. The sonic performance of the **MOON i-3 SE** may improve slightly when the display is turned off.

The "Input" selector button allows you to choose which input source you wish to listen to. The **MOON i-3 SE** integrated amplifier has six (6) inputs. The A4 input can be configured as a 'pass-through' which bypasses the **i-3**'s gain control section, allowing you to control the gain setting via the connected source component's own volume control – a home theater processor for example. In 'pass-through' mode, adjusting the volume on the **i-3 SE** will have no effect whatsoever when the A4 input is selected. To put the A4 input into 'pass-through' mode, simply press and hold down the "Input" selector button for approximately 5 seconds; you don't have to be on the A4 setting to do this. To reconfigure the A4 input to function like the five (5) other inputs, repeat the aforementioned procedure. As well, powering down the **i-3 SE** via the rear panel rocker switch will reset the the A4 to the factory default 'normal' mode.

Pressing the "Input" selector button allows you to sequentially cascade through each of the possible inputs in the following order: CD, A1, A2, A3, A4 and A5. Holding down the "Input" will allow only a single change of the selected input. You must press the button again to select the next input.

The "Vol Up" and "Vol Down" buttons control the gain setting, which ranges from '0' (no output) to '50' (full output). This control doesn't function like a typical volume: When you press either of these volume control buttons, you're selecting a specific gain setting on a shunt-to-ground based microprocessor circuit. This gain circuit, known as **RGB-cs**, doesn't degrade the audio signal regardless of the setting, unlike all potentiometer based circuits.

The range of fifty (50) unique gain settings is based on neither a linear nor logarithmic scale. Instead, we decided on relatively small variations for each of the lower position settings from '1' to '35'. The variations are somewhat larger from positions '36' through '50'.

# MOON i-3 SE Integrated Amplifier

---

## Rear Panel Connections




Figure 2: MOON i-3 SE Rear panel

The rear panel will look similar to Figure 2 (above). There are five (5) pairs of single-ended inputs on RCA connectors labeled CD, A1, A2, A3, A4 and A5. The left channel inputs are located on top and the corresponding right channel inputs are located directly below. The A4 input, as previously mentioned, bypasses the gain stage and is intended to be used with a component, such as a home theater processor, that has its own volume/gain control.

The **MOON i-3 SE** integrated amplifier has two pairs of non-amplified outputs; One single-ended pair of RCA connectors labeled 'Pre Out', located next to the A4 input, is designated for output to a power amplifier with single-ended RCA inputs in the event that you wish to use your **MOON i-3 SE** as a preamplifier only. The output level of the 'Pre Out' is dependant on the volume control setting. A second single-ended pair of RCA connectors labeled 'Tape Out', located next to the 'Pre Out' connectors, is intended as an input to a recording device such as a cassette tape deck or CD-Recordable Player. Keep in mind that the output level on the 'Tape Out' is fixed and cannot be adjusted by the **i-3's** volume control. All RCA input and output connectors on the rear panel have been color coded: 'white' for the left channel and 'red' for the right channel.

On each side of the group of RCA connectors, there is a pair of gold-plated binding posts. Connect your loudspeakers, with the cables of your choice, to these binding posts. Take care to respect the polarity ("+" , "-" ) of the output.

Don't hesitate to use high quality interconnects and speaker cables. Poor quality cables can degrade the overall sonic performance of your system.

Finally on the right side is the main power switch ("0"=off, "1"=on), the "AC Fuse" socket cover, and the IEC receptacle for the included AC power cord. Alternatively, you may use a dedicated high-performance AC power cord designed for power amplifiers.

All rear panel connectors have been chosen because they provide the best possible connections for your unit. A poor contact will degrade the signal substantially, and plugs and sockets should all look clean and free of dirt and corrosion. The easiest way to clean them is to remove the cables from their sockets and push them back in again. This procedure requires that your Integrated Amplifier and the rest of your components be completely turned off. Not heeding this warning may result in serious damage to your equipment. Special contact cleaning fluids and enhancers should not be used, as they deposit a difficult to remove residue which degrades the performance of your components.



## MOON i-3 SE Integrated Amplifier

---

### Operating the i-3

We recommend that you leave your **MOON i-3 SE** Integrated Amplifier powered up at all times to maintain optimal performance. In the event that you plan to be away from your home for a few days, powering off the Integrated Amplifier may not be a bad idea. Once fully “broken-in”, please keep in mind that your **i-3 SE** will require several hours of playing time before it reaches its peak performance after you’ve powered it up again.

#### **Making the AC Connection**

Connect the supplied AC power cable to the IEC receptacle, located on the rear panel of the integrated amplifier’s chassis. Ensure that the AC wall outlet you use has a functioning ground. For the best sonic performance, it is preferable that you plug your **MOON i-3 SE** directly into a dedicated AC outlet and avoid using an extension cord.

In order to obtain the maximum performance from your audio system, we strongly recommend that the detachable power cord not come into physical contact with any of the interconnect and speaker cables running to and from your **i-3**. In the event that this can’t be avoided, you should ensure that any cables coming into contact with each other are crossed at ninety degree angle to minimize the contact area.

#### **Turning on your MOON i-3 for the first time**

Prior to turning the integrated amplifier on for the first time, make sure that every cable is properly connected to avoid any problems. Then turn on your integrated amplifier in the following manner:

- 1) Flick the main rocker switch labeled “POWER” to the ‘1’ (on) position on the rear of the **i-3 SE**.
- 2) Press the push button labeled “Stand by/On” on the **i-3 SE**. The blue LED will illuminate and the digital display will indicate a gain setting of ‘0’ and the ‘CD’ as the default input.

#### **On and Off Sequence**

To avoid having any annoying noises (ie. “thumps” and “pops”) emanate from your speakers when powering your **i-3 SE** on or off, you should

- 1) Always power up your **i-3 SE** integrated amplifier after powering up your source component(s).
- 2) Always power down your **i-3 SE** before powering down your source component(s).

### Remote Control Operation



Figure 3: CRM Remote Control

The **MOON i-3 SE** Integrated Amplifier uses the '**CRM**' full-function remote control (figure 3). It operates on the Philips RC-5 communication protocol and is can be used with other Simaudio MOON components.

The '**CRM**' remote uses two AA batteries (included). To install them, simply slide the back plate off in the direction of the arrow; insert the batteries in the correct direction and then replace the back plate.

To engage the CRM remote for use with the **MOON i-3 SE** Integrated Amplifier, you must first press the button labeled **AMP**.

The **POWER** button located on the upper left will switch the integrated amplifier to either 'Stand by' or 'On' mode.

The 2 buttons labelled **◀ INPUT ▶** allow you to sequentially scroll, either backwards or forwards, through all six (6) available inputs. For example, to switch from the "CD" to the "A3" input you may press either **◀ INPUT** three (3) times or **INPUT ▶** three (3) times. Pressing and holding down either of these buttons results in only a single change to the selected input.

The 2 buttons labelled **◀ BAL ▶** allow you to control the channel balance. Pressing **◀ BAL** results in a decrease in the volume level of the right channel; Pressing **BAL ▶** results in a decrease in the volume level of the left channel. You may either press and hold these buttons down or press them briefly to make channel balance adjustments.

The 2 buttons labelled **▼ VOL ▲** allow you to control the volume level. Pressing **▼ VOL** results in a decrease in the volume level; Pressing **VOL ▲** results in an increase in the volume level. You may either press and hold these buttons down or press them briefly to make volume adjustments.

The **MUTE** button triggers a decrease in the output gain setting to a factor of 10% of the current setting. For example, if your current setting was '30' and you pressed the "Mute" button, the gain setting will drop to '3'. Pressing the "Mute" button a second time will reinstate the output gain level back to '30'.

# MOON i-3 SE Integrated Amplifier

---

## Specifications

Configuration .....	Stereo
Power Supply Transformer .....	0.6kVA
Power Supply Capacitance .....	40,000 $\mu$ F
Class Of Operation - Preamplifier .....	Class A
Class Of Operation - Amplifier .....	Class A/B
Single-ended inputs .....	6 (RCA)
Input Device Type - Preamplifier .....	J-FET
Input Sensitivity .....	400mV – 3.0V RMS
Input Impedance .....	12,000 $\Omega$
Tape Output .....	1 (RCA)
Preamplifier output .....	1 (RCA)
Output Device Type.....	Bipolars – 4 per channel
Output Binding Posts .....	Gold-Plated - 1 set per channel
Output Power @ 8 $\Omega$ .....	100 Watts per channel
Output Power @ 4 $\Omega$ .....	160 Watts per channel
Output Power @ 2 $\Omega$ .....	200 Watts per channel
Output Impedance .....	0.04 $\Omega$
Damping Factor .....	> 200
Gain Control .....	RGB cs – “Shunt-To-Ground”
Gain .....	37dB
Dynamic Headroom .....	6dB
Signal-to-noise Ratio .....	100dB @ full power
Maximum Output Voltage .....	30 Volts
Slew Rate .....	20V/ $\mu$ s
Maximum Current – Peak .....	22 amperes
Maximum Current – Continuous .....	12 amperes
Frequency Response .....	10Hz - 80kHz +0/-3dB
Crosstalk @ 1kHz .....	-65dB
Intermodulation Distortion .....	Unmeasurable
THD (20Hz - 20kHz @ 1 watt) .....	< 0.1%
THD (20Hz - 20kHz @ 100 watts) .....	< 0.15%
Remote Control .....	All Aluminum Simple-Function
AC Power Requirements .....	120V / 60Hz or 240V / 50Hz
Shipping Weight .....	23 lbs / 10 Kgs
Dimensions (W x H x D, inches) .....	17 x 3 x 15.5



Fuse Replacement: For the 120V version use a 4A fast blow (3AG size).  
For the 230V version use a 2A fast blow (3AG size).