

OPTIMUSS

Twin tuner HD satellite receiver

OS 2



Quick Start Guide

OPTIMUSS **OS 2**


- HD DVB-S / DVB-S2 Satellite Tuner
- MPEG-4, H.264 & MPEG-2 Compliant
- 405MHz Dual Core Broadcom MIPS Processor
- 256 MB NAND Flash /
8MB NOR Flash / 384 MB RAM
- Advanced Linux Operating System
- 10/100 Mbps Full Duplex Ethernet Interface
- 1 Common Interface & 1 Smart Card Reader
- 3 USB 2.0 Port (1 x in Front & 2 x Rear)
- Support Internal 2.5" SATA HDD
- HDMI & Component Output(YPbPr)
- 12 character VFD display with scrolling for local time or channel name
- Unlimited Channel Memory
- Super Sensitive Tuner
- Dolby Digital Plus, Dolby True HD supported
- S/PDIF Output for Digital Audio and Dolby AC-3 Bit Stream Output
- Firmware/ Software Upgrade: Through (Ethernet, USB Memory Stick)
- Multi-Language OSD Menus
- User Friendly EPG (Electronic Program Guide)
- External Power Supply
- Very Low stand-by Power Consumption (<0.5W)



OPTIMUSS
OS 2

ACCESSORIES

Please check that the following contents are enclosed :



Quick Start Guide




Remote control unit



Power Supply



AAA X 2 BATTERIES



SATA Cable

VIEWS

Front view



1 Power Button

Switch between operation and standby modes.

2 Display (VFD)

Display current menu information and channel name etc.

3 Program Up/Down Button

Navigates through the scanned channel list.

4 Volume Up/Down Button

Increase/Decrease the volume (Volume up/down).

5 USB


Connect to the External HDD or USB storage with USB cable. (Max. 500mA)

6 Smart card reader


To insert smart card

7 Common Interface Slot

A slot for one CI module with a Smartcard.



Rear view



1 LNB1 INPUT

1st Satellite tuner input from the LNB on a dish antenna.
Turn the receiver OFF first before connecting.

2 LNB2 INPUT

2nd satellite tuner input from the LNB on a dish antenna.
Turn the receiver OFF first before connecting.

3 S/PDIF

Connect with an appropriate optical cable to your HiFi system.

4 Audio / Video Output

Connect to TV using RCA cable.

5 Component (YPbPr)

Connect to TV using Component cable.

6 HDMI

To connect HDMI cable for your HD TV.

7 Ethernet

Communication port via HTTP, FTP, NFS, Telnet and Samba to access your Hard Drive or to upload channel lists. This is also used to update OPTIMUSS OS 2's software.

8 2x USB

Connect to the External HDD or USB storage with USB cable (Max. 500mA).

9 RS232

RS232C serial data port.

10 External Power Supply

Connect the power Supply (12V / 3A).

11 Power Switch

Turn AC Power On/Off.

12 Cooling Fan

with speed control function

INSTALLATION

1. Please refer to the Safety Instruction before powering on the device.
2. Connect OPTIMUSS OS 2 to your TV set using HDMI cable or a RCA cable, etc.



Note

Use an HDMI or Component cable in order to view HD.



HDMI



RCA

3. Connect the coaxial cable (from the satellite dish) to the LNB INPUT of OPTIMUSS OS 2.
4. Power on the OPTIMUSS OS 2.
5. After booting up, Initial setup menu comes up for the installation according to your TV settings and Antenna settings.

REMOTE CONTROL UNIT

MUTE : Mutes or unmutes the audio temporarily.

POWER : Switches between operation and standby.

HELP : This provides users with a quick guide of using OPTIMUSS OS 2.

HOME : Instantly moves to the top of the menu list.

END : Instantly moves to the bottom of the menu list.

TELETEXT : Switch between the teletext and TV modes.

SUBTITLE : Display the subtitle language list.

Zoom : To zoom the screen In/Out.

LIST: Open recorded file menu.

MEDIA : Open media file list.

TIMER : Start timer function.

VOL. +/- : Increase/Decrease the volume (Volume up/down).

EPG : Displays the Electronic Program Guide (EPG) information if provided.

AUDIO : select an audio track and a sound mode.

PROGRAM +/- : Navigates through the scanned channel list.

MENU : Open main menu & select sub menu using by navigation buttons.

EXIT : Close and return to the previous menu and screen.

Navigation Keys : Navigates up/down and left/right on the menu options. Up/down keys are used to call up the channel list.

OK : Select a menu, or confirms the selected operation. Also displays the channel list while watching a programme.

SAT : Open channel list according to satellite.

INFO : Displays the Electronic Program Guide (EPG) information if provided.

NUMERIC KEY (0~9) : Control the numerical operation and change the Channel/Service number directly.

PREV (<) : Return to the previous channel/service or move to the end of the Service List or the Play List.

NEXT (>) : Go to the next channel/service or move to the beginning of the Service List or the Play List.

COLOR BUTTONS : Activates certain menu functions. Usage instructions are shown in each OSD menu.

PVR FUNCTIONS : Control the PVR functions in PVR Mode.

TV : Switch to TV mode.

RADIO : Switch to Radio mode.



SAFETY INSTRUCTIONS

Please read the safety instructions carefully before using the OPTIMUSS OS 2.

The manufacturer takes no responsibility for incorrect handling of the OPTIMUSS OS 2.

- * For sufficient ventilation, leave enough space.
- * If unused for a prolonged amount of time, turn the power OFF.
- * Do not cover the OPTIMUSS OS 2's ventilation openings with items such as newspapers, tablecloths, curtains etc.
- * Do not expose the OPTIMUSS OS 2 to liquid, moisture, direct sunlight and extreme weather.
- * Do not place open flame sources, such as lighted candles, near or on the OPTIMUSS OS 2.
- * Do not place any containers with liquid, such as vases, on the OPTIMUSS OS 2.
- * Do not connect or modify cables while the OPTIMUSS OS 2 is connected to the power.
- * Do not remove the cover. Risk of electric shock!
- * Do not touch the OPTIMUSS OS 2 with wet hands. Risk of electric shock!
- * Do not put any metal items into the slots or ventilation openings.
- * Please disconnect your OPTIMUSS OS 2 from the main power during thunder or heavy storms.
- * Disconnect the main power cable if the power cord is damaged.
- * Cleaning : Disconnect the main power cord before cleaning the cover. Use a slightly damp cloth without cleaning agents.
- * Connect the OPTIMUSS OS 2 only to suitable sockets. Do not allow overloads to occur.
- * The socket-outlet shall be installed near the equipment and shall be easily accessible.

WARNING!

- * Modifications and changes to the OPTIMUSS OS 2 lead to loss of warranty.
- * Incorrect software installation leads to loss of warranty.
- * This instruction might be modified without prior notice.

DISPOSAL INSTRUCTIONS



1. When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.
2. All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
3. The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
4. For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.