# BATRIBIKE® ELECTRIC BICYCLES



Thank you for purchasing a BATRIBIKE Electric Bicycle from Fallowgate Limited.

With care and correct usage your bicycle will give many years of service.

Please read the manual fully before use.

#### MODEL:-





#### SERIAL NUMBER:-

PURCHASE DATE:- DAY MONTH							YEAR			
		1			/					

# IMPORTANT PLEASE READ THIS MANUAL FULLY PRIOR TO ASSEMBLY AND USE

For your safety & to ensure a long & trouble free life of your bicycle check the operation of brakes, lights, tyre pressures, horn & gears also check all fasteners including quick release mechanisms before every ride

#### Maximum permissible load including rider is 100Kg

# Service & Spares

Cables may stretch a little during the first few uses. Brakes and gears may need to be adjusted after the first few rides to ensure correct operation. If you return the bicycle to us ( please contact us first) we will be pleased to check & adjust accordingly within the first 6 weeks of purchase free of charge, if it is more convenient for you a local cycle shop could carry out this operation at your expense.

Your **BATRIBIKE** bicycle uses standard cycle parts wherever possible. Items such as tyres, tubes, lights, brake pads/blocks and cables may be obtained direct from us or your local cycle shop or retailer.

Specialist parts such as the motor, battery, & electrical parts or frame components are only available from Fallowgate Limited

#### **PACKAGE CONTENTS**

- 1 ASSEMBLED BICYCLE
- 1 BATTERY
- 1 BATTERY CHARGER
- 1 MANUAL

# Unpacking

- 1 Open box and lift out loose packaging, lift out bicycle, assistance will be required to remove from the box.
- 2 Remove the large rubber strap. Take care as the strap is under tension.

3 Cut the cable tie holding handlebars down, fold the handlebars into

position and lock with the quick release mechanism \*

4 Unfold the frame & lock with the quick release mechanism\*

- 5 Raise the handle bars to the desired height, taking note of the minimum insertion mark and lock with the quick release mechanism.\*
- 6 Unfold the pedals.\*
- 7 Remove all packaging.
- 8 Charge battery.\*
- 9 Check tightness of all fasteners. Check function of lights and brakes. Check tyre pressures. When the battery is charged your bicycle is ready for use.



<sup>\*</sup> See user guide on page 5 for full instructions

#### User Guide

#### **Folding**

1 Fold pedals by squeezing in as per photo and turning through 90 degrees.





- 2 Put up the side stand.
- 3 Release the handlebar folding quick release mechanism as follows:-



Lift Lever



Fold Lever



Press Button to Release



Fold Handlebars

4 Release frame folding quick release mechanism as follows:-





Lift Lever



Turn Out 90 degrees



Lift to Release Pin from Locating Hole in Frame

- 5 Fold frame in half front to back
- 6 To return to riding position reverse procedure

# Riding

- 1 Make sure the red button is in the power off position Turn on the battery with the key
- 2 Make sure to put up the side stand before mounting the cycle

With the red button in the off position you can ride the breeze as a normal cycle.



With the red button in the on position the power will cut in as you pedal and the throttle will also work.
When using throttle alone the speed is regulated by rotating the throttle.
Full power is achieved by twisting the throttle towards you.



- 3 To stop, release the throttle and pull brake levers towards you.
- When the battery is turned on the front light monitors the light level & comes on automatically as required.
- 5 The rear light requires two AA batteries.

#### **IMPORTANT**

Before dismounting make sure the red button is in the off position.



# Tyre Pressure

The tyres should be pumped up to within the range stated on the sidewall. This should be regularly checked as running with the correct pressures will ensure maximum range from the battery.

# **Battery Charging**

The battery can be charged either on or off the bicycle but must be charged inside in dry conditions to avoid the risk of electrical shock.

Only use the charger supplied with the bicycle.

- 1) Slide the charger socket cover on the battery to one side.
- 2) Ensure the power is turned off on the battery.
- 3) Insert charger lead into socket on battery casing taking care to get the plug in the correct position as the pins are off set.
- 4) Insert 3 pin mains plug into mains socket and switch on at wall.
- 5) There is an indicator light on the charger
  - CHARGE—Glows red when charging and green when charge complete.
- 6) When battery is charged firstly turn off the mains supply, unplug and then remove the charging plug from the battery.

To ensure maximum battery life charge your battery after each ride & DO NOT leave fully discharged.

If your BATRIBIKE Breeze is not in use for an extended period, charge the battery once a month to prevent deterioration

# Quick release fittings

#### for seat & handle bar height adjustment



With the locking lever in the loose position, tighten the nut until finger tight.

The final tightening is done by moving the lever to the locked position. To undo move lever to loose position to enable height adjustment.



#### www.batribike.com



### Warranty

Please retain your receipt as this is your proof of purchase and entitlement to Warranty.

- Your new BATRIBIKE<sup>®</sup> Breeze is guaranteed for 1 year from date of purchase.
- The battery is covered for 6 months as battery life is determined by User care

In the event of warranty repairs becoming necessary you should return your bicycle to Batribike at the address below, delivery & collection charges are not redeemable under warranty.

Brake blocks/pads, tyres, lights and cables etc. are considered as consumables and replacements are available from BATRIBIKE or may be obtained from your local cycle shop.

BATRIBIKE® Electric Bicycles are exclusive to:-

Fallowgate Limited Kellaway House Marton Road Sturton-by-Stow Lincoln LN1 2AH

Phone: 01427-787774

E-mail: support@batribike.com

