

Air Purifier

INSTRUCTION MANUAL

MODEL # EE-7772





PLEASE READ AND SAVE ALL INSTRUCTIONS TO ENSURE THE SAFE AND EFFECTIVE USE OF THIS APPLIANCE.

TABLE OF CONTENTS	
Table of Contents	P.1
Important Safety Instructions	P. 2,3
General Safety Instructions	P. 4
List of Main Parts, Tech. Specifications, Contents of Packaging	P.5
Operation and Use, Replacing HEPA TYPE Filter	P.6
Maintenance, Troubleshooting	P.7
Service Center	P.8
Limited Warranty	P.9
Warranty Card	P.10



IMPORTANT SAFETY INSTRUCTIONS

INTRODUCTION

Thank you for purchasing our CRANE Air Purifier. Each unit has been manufactured to ensure safety and reliability. Before using for the first time, please read the instructions carefully, and keep them for further reference.

WARNING! READ AND SAVE THESE INSTRUCTIONS. Failure to follow all the instructions listed below may result in electric shock, fire and/or serious personal injury.

- 1. To avoid fire and shock hazard, plug the appliance directly into a 120V AC electrical outlet
- 2. Never operate the unit with a damaged cord or plug. Return appliance to manufacturer for examination, electrical or mechanical adjustment or repair.
- 3. Keep cord out of heavy traffic areas. To avoid fire hazard NEVER put the cord under rugs, near heat registers, radiators, stoves, or heaters.
- 4. Always place the air purifier where it is not easily knocked over by persons in household.
- 5. To protect against electrical hazards DO NOT immerse in water or other liquids. Do not use near water.
- 6. Never touch the air purifier with wet hands. **ALWAYS plug and unplug unit with dry hands.**
- 7. Do not operate the product in any greasy environment such as a kitchen. This product is not intended to filter oil or grease from air.
- 8. Do not use air purifier in bathrooms or other humid environments, near fireplaces or in areas where flammable or combustible vapors or products may exist.
- 9. Always unplug the power cord from electrical outlet when the air purifier is not in use, before cleaning, inserting or removing parts or before moving to another location.
- 10. NEVER run air purifier until it is fully assembled.
- 11. To reduce the risk of electrical shock, this product has a polarized plug (one blade is wider than the other). This plug will fit into a polarized outlet only one way. Do not alter the plug in any way.
- 12. NEVER drop or insert any object into any openings.
- 13. Use appliance only for the intended household use as described in this manual.

 Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons.
- 14. Do not use outdoors.

SAVE THESE INSTRUCTIONS!

- 15. Never use the power cord to pick up, carry, drag, pull, or lift the air purifier. Do not pull the cord against or around sharp corners or edges. This could result in injury to the user and/or damage the cord.
- 16. Never pull on the cord itself to unplug from power outlet.
- 17. ALWAYS turn unit off before unplugging.
- 18. Never block the air openings, or place on soft surface, such as a bed or sofa, as this could cause the unit to tip over thus blocking the air intake opening.
- 19. DO NOT place anything on top of unit.
- 20. NEVER use detergents, gasoline, glass cleaner, paint thinner or other household solvents to clean any part of the unit.
- 21. Always place the unit on a smooth, flat, level surface, and away from direct sunlight. Keep the cord away from heated surfaces and areas where it could be walked on or tripped over. Unplug the unit when not in use and whenever you clean or move the unit.

TO REDUCE THE RISK OF FIRE OR ELECTRICAL SHOCK, DO NOT USE THIS AIR PURIFIER WITH ANY SOLID STATE SPEED CONTROL DEVICE.

SAVE THESE INSTRUCTIONS!

GENERAL SAFETY INSTRUCTIONS





WARNING! Read and understand all instructions. Failure to follow all instructions listed below may result in electric shock, fire or serious personal injury. The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are a factor which cannot be built into this product, but must be supplied by the operator.

THIS AIR PURIFIER IS NOT A TOY!

Do not let your child play with this appliance. Serious injury and electrocution might be possible. This appliance has to be operated by an adult only. Children should be supervised to ensure that they do not play with the air purifier.

SAVE ALL INSTRUCTIONS!

CAUTION: A short power supply cord is provided to reduce the risk of personal injury resulting from becoming entangled in or tripping over a longer cord. Extension cords are available from local hardware stores and may be used if care is exercised in their use. If an extension cord is required, special care and caution is necessary. Also the cord must be: (1) marked with an electrical rating of 125 V and at least 13 A., 1625 W., and (2) the cord must be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over accidentally.

ELECTRIC POWER

If electric circuit is overloaded with other appliances, your appliances may not operate properly. The appliances should be operated on a separate electrical circuit from other operating appliances.

POLARIZED PLUG

This appliance has a polarized plug (one blade is wider than the other). As a safety feature to reduce the risk of electrical shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.





SAFETY WARNING

Although your appliance is easy to operate, for your safety, the below warnings must be followed:

- 1. Do not place the appliance near a heat source.
- 2. Never leave the appliance unattended while connected to the electrical outlet.
- 3. To avoid any accidents, never cover air grilles when the appliance is in operation.
- 4. Use the appliance on a stable surface away from water.
- 5. Do not unplug from the wall socket by pulling on the supply cord.
- 6. The appliance must be unplugged:
 - A. Before any cleaning or maintenance
 - B. After use
 - C. If it appears to be faulty

THIS PRODUCT IS INTENDED FOR HOUSEHOLD USE ONLY.

LIST OF MAIN PARTS



Fig. 2

- 1. Outlet Grill
- 2. Rear Door Latch
- 3. Intake Grill

- 4. Central Body
- 5. Air Purifier Power Indicator Light
- 6. Control Knob

TECHNICAL SPECIFICATIONS

Rating Voltage	120V-60Hz
Power Supply	88W
Weight	4Lbs
HEPA TYPE	HS-3508

CONTENTS OF PACKAGING

NOTE: The air purifier is pre-assembled and ready for use.

- a. Central Body
- b. HEPA TYPE Filter with Carbon Filter (assembled)
- c. Washable Particle Filter
- d. Instruction Manual

NOTE: Replacement HEPA TYPE Filter Set (*set includes HEPA TYPE filter with carbon filter and washable particle filter*) can be purchased at the same retailer the Crane Air Purifier was purchased.

If any of the above items are missing, please contact our service department at 1-888-599-0992 (http://www.crane-usa.com) for replacement parts. Business hours Mon-Fri 9:00am - 4:00pm CT

OPERATION AND USE

Before Use Instructions

- 1. Select a firm, level and flat surface to place the air purifier. For proper air flow, locate the unit at least 3 feet from any wall or furniture.
- 2. Do not place unit in close proximity to electronic devices that are sensitive to electrical fields.
- 3. Do not place unit on metal shelving. Air purifier may be placed on floor, nightstand, table or desk. Make sure that the outlet grille faces away from the nearest wall or furniture.
- 4. Make sure that the intake and outlet grilles are not blocked.
- 5. Plug into a grounded 120V outlet. See manual SAFETY INSTRUCTIONS.
- 6. Turn control knob to desired setting 1, 2, 3

Operating Instructions

- 1. Turn control knob to desired setting.
- 2. Select setting 1 for guieter operation or use in the bedroom.
- 3. Select setting 2 to operate the air purifier on a continuous use.
- 4. Select setting 3 when high levels of air pollutants are present to quickly circulate and filter the room air.
- 5. The Air Purifier Power Light will illuminate when power is ON.

REPLACING THE HEPA TYPE FILTER

On an average the HEPA TYPE Filter needs to be replaced every 3-6 months. Filter life will depend on air quality and usage.

- 1. ALWAYS turn off and unplug air purifier from power outlet before replacing the filter.
- 2. Remove the filters from the unit by pulling gently toward vou.
- **3.** To replace the HEPA TYPE filter, discard the old filter. DO NOT ATTEMPT to clean the HEPA TYPE filter. Only the particle filter can be washed (see cleaning instructions). Place the washable particle filter back on the new HEPA TYPE Filter. Insert the new HEPA TYPE filter into the unit by sliding it into place.
- 4. To close the rear door, place bottom rear door tab into tab slot and close door. DO NOT FORCE DOOR TO CLOSE! PLEASE NOTE that if there is any uneven closure at the bottom of the rear door the door is not closed securely. You will need to insert bottom tab again into slot and close door again. The rear door must be evenly flush with the air purifier body

MAINTENANCE



CAUTION:

Always be sure that the appliance is unplugged and switched OFF before cleaning, removing filters or attempting to store the item. **NEVER PLUG OR UNPLUG UNIT WITH WET HANDS.**

Cleaning the Washable Particle Filter

- 1. Remove the foam particle filter by pulling out of the unit gently.
- 2. Rinse the particle filter by hand with warm water. DO NOT place in dishwasher. DO NOT use hard solvents or detergents. Warm water only.
- 3. Particle filter MUST be thoroughly dry before replacing back into the air purifier.

Cleaning the Air Purifier

NOTE: NO PART of the air purifier should be placed in the dishwasher.

- 1. Always unplug the unit before cleaning.
- Once unplugged the exterior of the unit may be cleaned by wiping with a lightly damp cloth. Caution: DO NOT ALLOW WATER TO GET INTO THE INTAKE AND OUTLET GRILLS. NEVER USE GASOLINE, POLISH OR ANY CHEMICAL SOLUTION TO CLEAN AIR PURIFIER.
- 3. The intake grill and outlet grill can be cleaned of dust with a small soft brush.
- 4. If you wish to lightly clean the inside of the air purifier, please remove filters and ONLY use a dry, soft cloth to lightly wipe down.

STORING YOUR AIR PURIFIER

Store the appliance in a dry location. Do not place any heavy items on top of appliance during storage as this may result in possible damage of the appliance. Store the cord in a clean, dry location away from metal objects. Always check the plug before use to assure metal items have not become attached.

TROUBLE SHOOTING

CAUTION: DO NOT attempt to service the air purifier yourself. If the air purifier continues to not operate please call our service center (see toll free number).

Problem	Solution
The air purifier does not operate.	 Make sure the air purifier control knob is at 1, 2, or 3. Make sure the power cord is plugged into power outlet. If the above solutions do not work please contact Crane's service center.
Reduced air flow.	 Make sure that the intake and outlet grills are not blocked. If the above solutions do not work please contact Crane's service center.

SERVICE CENTER

If you have any question in regards to the operation of this appliance or are in need of a spare part please contact our service center at:

Crane USA

Tel: 1-888-599-0992 (Business Hours Mon-Fri 9:00am-4:00 pm Ct)

E-Mail: customer-service@crane-usa.com

Website: http://www.crane-usa.com

621 IL. Route 83, Ste 202 Bensenville, Illinois 60106

ENVIRONMENTAL PROTECTION



If the appliance should no longer work at all, please make sure that it is disposed in an environmentally friendly way, by handing it into a public collection point. Please do not put it with your household waste.

LIMITED WARRANTY

Thank you for purchasing a top quality **Crane** product. This Air Purifier was tested and meets our stringent quality standards. This product is warranted to be free from manufacturing defects under normal use and conditions for 1 year.

In case you find this product to have a manufacturing defect please proceed as follows:

- A. Within 90 days of purchase: return the product to your retailer for a replacement or a refund.
- B. After 90 days and within the warranty period: send the product and all of it's accessories to our service center. The consumer will be responsible for all shipping costs to the Crane Service Center. Crane will not assume responsibility for loss or damages to the product being returned to us. To avoid transport damages carefully package the product and insure it with the carrier. Be sure to fill out the warranty card and include it with a copy of the dated sales receipt. In return you will receive your repaired item, or a new product at the service center's discretion.

WARRANTY IS ONLY VALID WITH A DATED PROOF OF PURCHASE.

The warranty is void if the defect is due to accidental damage, misuse, abuse, neglect, improper repair or alteration by unauthorized persons or failure to follow operation instructions provided with the product. This warranty does not apply to normal wear and tear, as well as commercial use.

The warranty is non-transferable and applies only to the original purchase and does not extend to subsequent owners of the product. Liability under this warranty is limited to repair, or replacement. In no event shall liability exceed the purchase price paid by the purchaser of the product. Under no circumstances shall there be liability for any loss, direct, indirect, incidental, special or consequential damage arising out of in connection with use of this product.

This warranty is only valid in the 48 contiguous states plus the District of Columbia. Excluding Alaska, Hawaii, Puerto Rico, and the Virgin Islands. This warranty is effective only if the product is purchase and operated in the United States of America.

This Warranty gives you specific legal rights. However you may have other rights that vary from state to state. Some states do not allow limitation on implied warranties or exclusion of consequential damages therefore these restrictions may not apply to you.

Any instruction or warranty included in this manual may be subject to change with out notice. For the most up to date set of instructions and warranty please contact us or visit our web site.

Crane USA Inc.

Tel: 1-888-599-0992 (Business Hours Mon-Fri 9:00am-4:00 pm CT)

E-Mail: customer-service@crane-usa.com Website: http://www.crane-usa.com

621 IL. Route 83, Ste 202 Bensenville, Illinois 60106

WARRANTY CARD



Air Purifier

In case you find this product to be defective please proceed as follows:

- A. Within 90 days of purchase: return the product to your retailer for a replacement or a refund.
- B. After 90 days and within the warranty period: send the product and all of it's accessories to our service center. The consumer will be responsible for all shipping costs to the Crane Service Center. Crane will not assume responsibility for loss or damages to the product being returned to us. To avoid transport damages carefully package the product and insure it with the carrier. Be sure to fill out the warranty card and include it with a copy of the dated sales receipt. In return you will receive your repaired item, or a new product at the service center's discretion.

This Air Purifier was tested and meets our stringent quality standards. This product is warranted to be free from manufacturing defects in original materials, including original parts, and workmanship for 1 year with dated proof of purchase.

Please print clearly and fill in your details below. Send it together with the product and purchase receipt. Please read the Limited Warranty conditions mentioned in this instruction manual.

Customer Name	
Street	
City	
State	
ZIP Code	
Phone #	
Model #/Style	
Purchase Date	
Description of Defect :	



PLEASE DETACH THIS SECTION AND RETURN IT WITH YOUR PRODUCT

Service Center Address:

Crane USA Inc.

621 IL Route, Ste 202, Bensenville, Illinois 60106

Tel: 1-888-599-0992 Hours Mon-Fri 9:00am-4:00 pm CT)

http://www.crane-usa.com E-Mail: customer-service@crane-usa.com