



MobiShow

User's Manual

(Model Name: MS-200)



Version: 1.0


Date: December 5, 2008

1) Package Contents


- | MobiShow Box
- | Power Adapter (DC +5V, 2.5A)
- | CD-ROM with Smartphone & PC utilities and User's Manual inside.
- | Quick Installation Guide
- | Warranty Card
- | Carry Bag

2) Physical Details

- | Front Panel



- | Rear Panel



① Power Switch

④ Audio

② Power Jack


⑤ RJ-45

③ VGA Connector


⑥ Reset

3) Hardware Installation

- 1) Connect power adapter DC plug to MobiShow DC jack.



- 2) Connect Projector's VGA cable to MobiShow VGA connector on the rear panel.



- 3) Turn on projector.
- 4) Turn on MobiShow box
 - ◆ After system ready, the "POWER" LED and "WLAN" LED will be yellow color. The "LAN" LED will be off.
 - ◆ When LAN connection is established, then "LAN" LED will be yellow color and blinking while data transmission.
- 5) When MobiShow is ready, the following screen is shown.



4) Software Installation

4.1 Download from MobiShow box


- 1) Turn on WiFi on your phone.
- 2) Connect your phone to MobiShow wireless network. The SSID is displayed on screen (default SSID is MobiShow).
- 3) Open the browser on your phone and enter the IP address of the MobiShow box.
 - ◆ The default IP address is 192.168.100.10.
 - ◆ Or, refer to the IP address which shown on the projector screen.



- 4) The following web page will be shown on your browser.



- 5) Select “Download” to enter the software download page.




- 6) Click the “Download” button to download the software installer (in CAB format) to your phone.
- 7) Open Explorer on your phone and find the CAB file.
- 8) Double click on the CAB file to start installation.
- 9) Follow on-screen instructions to finish installation.

4.2 Install from CD


- 1) Connect your Windows Mobile phone to PC. Make sure it is connected in ActiveSync.
- 2) Insert MobiShow Setup CD to PC.
- 3) The AutoRun program will automatically bring up the Setup page. If the system asks you what to do on CD insertion, please select “Launch MobiShow Setup CD”.
- 4) On the Setup page, select “Install to Phone”.
- 5) Follow the on-screen instructions to install software to PC.
- 6) When prompted, check the screen of your phone to finish installation on your phone.

7) Using MobiShow with a Smartphone

- 1) Open “Programs” on your phone and find “MobiShow” application.
- 2) Select “MobiShow” icon  to launch the client software.
- 3) MobiShow client will search for MobiShow box automatically. When a box is found, it will automatically login and the following main menu is shown on your phone.




- I If more than one MobiShow is found, the following list is displayed for you to select the one to use.



- 4) Select which feature to use. To project the screen of your phone, click on the “Screen” icon. To do a PC-less presentation with Presentation-to-Go (PtG), select the “PtG” icon. To play a video or MP3 from your phone, select the “Media” icon.

I Screen Projection:



MobiShow will project anything displayed on your screen. You may launch another application (such PowerPoint Viewer) or open any file (such as Word document or JPG image) and it will be projected to the projector.

Note: Do not exit MobiShow application while opening other application to keep screen projected.

Click the “Stop” icon to stop projection.

Click the “Pause” icon to pause projection. Click “Pause” again to resume projection.

Click the “Zoom” icon to zoom the projected screen to extend the longest side of your screen to fill the screen.

Click the “Play” icon to start projection again if it is stopped.

Click the “OK” button or “Back” to return to main menu.

I Wireless PtG:

When you select PtG function, MobiShow client will automatically open Explorer for you to select a PtG file. Select the file to open for your presentation. When the file is open, the PtG slides will be projected, and the following screen is displayed on your phone for you to control your PtG presentation.



Click “Prev” or “Next” to go to the previous or next item in the slide.

Click “PgUp” or “PgDn” to go to previous or next slide.

Click “Stop” to stop projecting the file. The icon will become “Play” if the file is not played. Click “Play” again to play the file if it is stopped.

Click “Home” to go to the first slide.

Click “Jump” and MobiShow client will show every slide on the phone. You can select any page to go to.

Click “Open” to select another PtG file.

I Media Sender:

When you select Media Sender function, MobiShow client will automatically open Explorer for you to select a media file. Select a file (videos in mpeg or wmv9 format, or MP3 music files) to play. When the file is open, the media will be projected, and the following screen is displayed on the phone for you to control your media playback.



Click “FR” or “FF” to seek backward or forward.

Click “Vol-“ or “Vol+” to adjust volume for playback.

Click “Stop” to stop playing the file. The icon will become “Play” if the file is not played. Click “Play” again to play the file if it is stopped.

Click “Mute” to mute the audio. Click “Mute” again to bring audio back.

Click “Open” to select another media file.

- 5) When you are in the main menu, click the “OK” button or “Back” again to close the application.

8) Using MobiShow with a PC

Besides Smartphones, you may also use MobiShow with one PC. To use MobiShow with your PC, follow the steps to install MobiShow client to your PC and use MobiShow.

- 1) Insert the MobiShow Setup CD to your PC.
- 2) The AutoRun program will automatically bring up the Setup page. If the system asks you what to do on CD insertion, please select "Launch MobiShow Setup CD".
- 3) On the Setup page, select "Install PC Utilities".
- 4) Follow the on-screen instructions to install software to PC.
- 5) After installation, the following shortcuts will be placed on the Desktop.





MobiShow PC Projector







MobiShow PtG Converter


- 6) Make sure your personal firewall allows MobiShow software to pass through.
- 7) When installation is completed, this program will launch automatically and search for MobiShow boxes. When a MobiShow box is found, the software will automatically login if no other PC is using it.



- 8) The following control panel is displayed on your Desktop if it login successfully.








Click the “ Play” button to start projection. Click the “ Pause” icon to pause projection. The icon will become “ Play” if projection is paused. Click “ Play” again to resume projection.

Click “ Stop” to stop projection.

- 9) You may switch to “Video” pane to stream videos from your PC.



Click the “ Play” button to start playing. Click “ Pause” to pause the streaming. The icon will become “ Play” if the file is paused. Click “ Play” again to resume streaming.

Click “ Stop” to stop playing the file.

Click “ Open” to select another media file.


Click “ Mute” to mute the audio. Click “ Mute” again to bring audio back.




Use the volume slider to adjust volume for playback.

9) Using PtG Converter

Open “MobiShow PtG Converter” in “MobiShow\MobiShow PtG Converter” folder from “Programs” in the Start menu. The following control panel is displayed on your Desktop when it is launched.



Click the “ Convert” button to select a PowerPoint PPT file and start conversion. PtG Converter will open the PowerPoint file and convert it to PtG format. You can see the conversion process on your Desktop.

Click the “ Preview” button to expand or collapse the preview pane. Click “ Play” to playback selected PtG file, or click “ Open” to select a PtG file.


10) Web Management

n Home Page

- ◆ Make sure your PC connect to MobiShow box successfully.
- ◆ Open your browser, and enter the IP address of your MobiShow on the browser.
- ◆ The IP address is displayed on the bottom of the projector screen.
- ◆ The default IP is 192.168.100.10




n Login Web Admin



- ◆ Click [Admin] and then enter password to login web page.
- ◆ The password default value is "admin".

n System Status



*** Click [System Status], shows current system status.

Model Name: Product model name

Versions:

- ◆ Firmware version no.: Product firmware version number.
- ◆ Software version no.: Windows client utility version number.

Network Status:


- ◆ IP address : IP address of MobiShow device.
- ◆ Subnet Mask : subnet mask
- ◆ Default Gateway : default gateway
- ◆ Wireless MAC address : wireless MAC address
- ◆ Wire MAC address : wire MAC address

Connection Status:

- ◆ Projecting status: which is "Waiting for projecting" or "Projecting"
- ◆ Total Users: It shows how many users login into MobiShow box.

n Network Setup

There are many kinds of operating configurations as below.



MobiShow

MobiShow > Administration > Network Setup Logout >>

System Status
Network Setup
Projection Setup
Change Passwords
Reset to Default
Firmware Upgrade
Reboot System

IP Setup

Obtain an IP address automatically Use the following IP address

IP Address: 192 . 168 . 100 . 10
Subnet Mask: 255 . 255 . 255 . 0
Default Gateway: 192 . 168 . 100 . 10
DNS Server: 192 . 168 . 100 . 10

DHCP Server Setup

Auto Disable

Start IP: 192 . 168 . 100 . 11
End IP: 192 . 168 . 100 . 254
Subnet Mask: 255 . 255 . 255 . 0
Default Gateway: 192 . 168 . 100 . 10
DNS Server: 192 . 168 . 100 . 10

Wireless Setup

Wireless LAN: Enable Disable
Region: --- WORLDWIDE ---
SSID: MobiShow jjjj
SSID Broadcast: Enable Disable
Channel: 2
WEP: 64bit (ASCII:5 chars)
Key:

Apply Cancel

Copyright © 2008 Awind Inc. All rights reserved.

< Auto-Configuration Network Setup>

The default setting of the MobiShow box is DHCP client. When the MobiShow box is connected to a LAN that already has a DHCP server present, the MobiShow box takes an IP address assigned to it by the server. When the MobiShow box is connected to a LAN that does not have a DHCP server, the MobiShow box becomes the DHCP server in the network.

< IP Setup>

You can select “obtain IP address automatically” or “Use the following IP address”

- ◆ IP Address: The default value is 192.168.100.10.
- ◆ Subnet Mask: The default value is 255.255.255.0
- ◆ Default Gateway: The default value is 192.168.100.10

<DHCP Server Setup>

You can select "Auto" or "Disable". When "Auto" is selected, it will automatically disable DHCP on MobiShow if another DHCP server is detected, otherwise it will enable its DHCP service.

- ◆ Start IP: The start IP address of DHCP Server.
- ◆ End IP: The end IP address of DHCP Server.

< Wireless Setup>


- ◆ Wireless LAN: you can select "Enable" or "Disable"
- ◆ Region: default value is "Worldwide".
- ◆ SSID: SSID string, max. Length is 32 bytes.
- ◆ SSID Broadcast: you can select "Enable" or "Disable"
- ◆ Channel: to set fixed channel or Auto. The "Auto" means after power on iShow, it will scan all of wireless channel and select clear one channel automatically.
- ◆ WEP: you can Disable WEP key or select one of 64bit or 128bit in ASCII or HEX string.
- ◆ Key: If WEP is enabled, you have to set key value according to WEP mode you selected.

<Apply >: press button to select this mode

<Cancel>: press button to abort action.

<Back>: Back to Operating mode main menu

n Projection Setup



*** Click [Projection Setup] button

<Resolution>: XGA (1024X768) or SVGA (800X600).

<Screen Refresh Rate>: This is VGA output refresh rate, provides 60 Hz and 75Hz to suit for different kinds of projectors.

<Apply> : Confirmation and Save modifications

<Cancel>: Cancel all the modifications

n Change Passwords

The screenshot shows the MobiShow Administration interface. The breadcrumb trail is "MobiShow > Administration > User Settings". The left sidebar contains a menu with the following items: System Status, Network Setup, Projection Setup, Change Passwords (highlighted), Reset to Default, Firmware Upgrade, and Reboot System. The main content area is titled "Admin" and contains two input fields: "Enter New Password" and "Confirm New Password", both with empty text boxes. An "Apply" button is positioned to the right of the second input field. At the bottom of the page, there is a copyright notice: "Copyright © 2008 Awind Inc. All rights reserved."

*** Click [Change Password] button, to change password value.

<Enter New Password>: enter new password you want to change for each category.

<Confirm New Password>: double confirm new password.

<Apply>: Confirmation and Save modifications.


n Reset to Default

The screenshot shows the MobiShow Administration interface. The breadcrumb trail is "MobiShow > Administration > Reset to Default". The left sidebar contains a menu with the following items: System Status, Network Setup, Projection Setup, Change Passwords, Reset to Default (highlighted), Firmware Upgrade, and Reboot System. The main content area features a yellow warning triangle icon, the heading "Reset to Default", and the text "This will restore the device to the factory default settings." Below this text is an "Apply" button. At the bottom of the page, there is a copyright notice: "Copyright © 2008 Awind Inc. All rights reserved."


*** Click [Reset to Default] button to restore factory default settings.

<Apply>: Confirmation and action.

n Firmware Upgrade



MobiShow Administration > Firmware Upgrade Logout >>

System Status	Firmware Version	1.0.0.0
Network Setup	Release Date	20081205
Projection Setup	After you apply "Upgrade" button, projecting function will be terminated.	
Change Passwords	File Name	<input type="text"/> <input type="button" value="Browse..."/>
Reset to Default	<input type="button" value="Upgrade"/>	
Firmware Upgrade		
 Reboot System		

Copyright © 2008 Awind Inc. All rights reserved.

*** Click [Firmware Upgrade] button to upgrade firmware.


- ◆ Firstly, you have to get latest firmware image file from your vendor.
- ◆ Click <Browse> to specify file name you want to upgrade.
- ◆ Click <Upgrade> to start.

When upgrade in process, the LED turns to red. The upgrade process takes about 7 minutes to complete. It will reboot once firmware upgrade is finished. If for some reason it does not reboot after 15 minutes, please manually turn off the device and turn on again.



Warning: Don't power off MobiShow while firmware upgrade in progress, otherwise will cause your Box doesn't work and have to return device to your vendor for fixing.

n Reboot System



*** Click [Reboot System] button, to restart system

<Reboot>: reboot system automatically.