

DCT-24 USB DAC with Headphone Amplifier

OPERATION MANUAL





DISCLAIMERS

The information in this manual has been carefully checked and is believed to be accurate. Cypress Technology assumes no responsibility for any infringements of patents or other rights of third parties which may result from its use.

Cypress Technology assumes no responsibility for any inaccuracies that may be contained in this document. Cypress also makes no commitment to update or to keep current the information contained in this document.

Cypress Technology reserves the right to make improvements to this document and/or product at any time and without notice.

COPYRIGHT NOTICE

No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or any of its part translated into any language or computer file, in any form or by any means—electronic, mechanical, magnetic, optical, chemical, manual, or otherwise—without express written permission and consent from Cypress Technology.

© Copyright 2011 by Cypress Technology. All Rights Reserved. Version 1.0 September 2011

TRADEMARK ACKNOWLEDGMENTS

All products or service names mentioned in this document may be trademarks of the companies with which they are associated.

SAFETY PRECAUTIONS

Please read all instructions before attempting to unpack, install or operate this equipment and before connecting the power supply.

Please keep the following in mind as you unpack and install this equipment:

- Always follow basic safety precautions to reduce the risk of fire, electrical shock and injury to persons.
- To prevent fire or shock hazard, do not expose the unit to rain, moisture or install this product near water.
- Never spill liquid of any kind on or into this product.
- Never push an object of any kind into this product through any openings or empty slots in the unit, as you may damage parts inside the unit.
- Do not attach the power supply cabling to building surfaces.
- Use only the supplied power supply unit (PSU). Do not use the PSU if it is damaged.
- Do not allow anything to rest on the power cabling or allow any weight to be placed upon it or any person walk on it.
- To protect the unit from overheating, do not block any vents or openings in the unit housing that provide ventilation and allow for sufficient space for air to circulate around the unit.

REVISION HISTORY

VERSION NO.	DATE DD/MM/YY	SUMMARY OF CHANGE
RDV1	27/02/13	Preliminary Release

CONTENTS

1. Introduction	1
2. Applications	1
4. System Requirements	1
5. Features	2
6. Operation Controls and Functions	3
6.1 Front Panel	3
6.2 Rear Panel	4
7. RS-232 control	5
7.1 RS-232 Protocol	5
7.2 RS-232 Command	6
8. Connection Diagram	8
9. Specifications	9

1. INTRODUCTION

The Audio Center is designed to allow multiple audio sources to be controlled, switched and output to a variety of audio equipment. With its 3 audio inputs and 2 audio outputs (including a 6.3mm headphone output) you can integrate and convert USB/Line in audio source to LPCM 2CH output synchronously to Line out and 6.3mm headphone.

2. APPLICATIONS

- Multiple input/output Audio Center
- PC/Mac USB audio input support
- Show event audio set up
- Home theater
- Educational/Lecture presentation

3. PACKAGE CONTENTS

- 1 x Audio Center
- 1 x 5V DC Power Adaptor
- 1 x 6.3mm to 3.5mm Jack
- 1 x 3.5mm to D-sub 9 pin cable
- Operational Manual

4. SYSTEM REQUIREMENTS


Input audio source equipment such as PC (USB), DVD player, MP3 and ...etc. with output active speakers, amplifier or headphones.

5. FEATURES

- Supports Digital to Analog audio Conversion (DAC)
- Supports USB sampling rate up to 192kHz
- Synchronous output sound on both Line out and 6.3mm headphone
- Supports RS-232 controls
- Elegant design and easy to install/using
- Total Harmonic Distortion (THD): Less than 100dB (-20dBFs)
- Volume contol of analog and headphone outputs
- Direct power and mute button on unit
- Headphone output fades in after system is muted
- 6.3mm headphone output (3.5mm mini-jack adaptor supplied)

6. OPERATION CONTROLS AND FUNCTIONS

6.1 Front Panel



1 POWER/SOURCE Select:

Press the wheel to turn on the device or to set it to standby mode. Turn the wheel Left/Right to select input audio source (3.5mm Linelevel/ Line in/ USB), the LED will illuminate accordingly with selected input audio source.

6.3mm HEADPHONE Output:

Connect to 6.3mm professional headphone set for user to enjoy the individual professinal audio sound.

3 3.5mm Line-level input:

Connect 3.5mm mini-jack cable to any audio equipment for stereo input audio signal.

4 Power LED:

LED will illuminate when the Power is switched ON.


5 Input LED indicator:

The LED will illuminate according with selected input source.

6 Mute/Volume control:

Turn the wheel to adjust the volume levels. Press the wheel to Mute the audio, all the input audio LED indicator will turn off automatically. Turn the wheel Left/Right to un-mute the audio, input audio LED indicator will illuminate to the last selection.

6.2 Rear Panel



1 DC 5V:

Plug the 5V DC power supply into the unit and connect the adaptor to an AC outlet.

2 RS-232:

Connect 3.5mm D-Sub 9 pin adaptor cable to PC/Notebook for RS-232 control.

3 USB IN:

Connect to a PC/MAC source for USB audio signal input or firmware update.

4 Line IN:

Connect the L/R IN to an analog stereo input source such as CD player or media player.

5 Line OUT:

Connect the L/R OUT to amplifier or active speakers with RCA jack cables.

7. RS-232 CONTROL

7.1 RS-232 Protocol

DCT-24		
PIN	Assignment	
1	NC	
2	Tx	
3	Rx	
4	NC	
5	GND	
6	NC	
7	NC	
8	NC	
9	NC	

Remote Control		
PIN	Assignment	
1	NC	
2	Rx	
3	Tx	
4	NC	
5	GND	
6	NC	
7	NC	
8	NC	
9	NC	

Baud Rate: 19200 bps


Data bit: 8-bits Parity: None Stop Bit: 1

7.2 RS-232 Command

Command	Description
PORT 00	Switch Front In
PORT 01	Switch Line In
PORT 02	Switch USB In
VOL 00	Volume controller
VOL -(01160)	Volume controller
POWER 00	Power off
POWER 01	Power on
MUTE 00	Mute off
MUTE 01	Mute on
FIX 00	LINE Out volume levels
FIX 01	LINE Out fix level
ME 03	Reset to default
HPR (0005)	HPR 00: 16Ω
	HPR 01: 32Ω
	HPR 02: 64Ω
	HPR 03: 200Ω
	HPR 04: 300Ω
	HPR 05: 600Ω

?	Display all available commands
	Ext:
	Support UART commands as list
	commands : Description
	PORT 00: Front In
	PORT 01: Line In
	PORT 02: USB In
	POWER 00: POWER OFF
	POWER 01: POWER ON
	MUTE 00: MUTE OFF
	MUTE 01: MUTE ON
	FIX 00: FIX OFF
	FIX 01: FIX ON
	HPR 00: 16_OHM
	HPR 01: 32_OHM
	HPR 02: 64_OHM
	HPR 03: 200_OHM
	HPR 04: 300_OHM
	HPR 05: 600_OHM
	VOL 00: VOL xxdB
	VOL -(01160): VOL -xxdB
	ME 03: Reset to default
	INFO: Display the current status and F/W
	version
	? : Display all available commands
INFO	Display the current status and F/W version

8. CONNECTION DIAGRAM



9. SPECIFICATIONS

Input port 1 x 3.5Ø Line in, 1 x R/L RCA, 1 x USB (Type B),

1 x 3.5mm 9pin (RS-232),

Output port 1 x L/R (Analog Stereo 2RCA), 1 x 6.3mm

Headphone

Audio Input/Output LPCM 2CH

Stereo Input/Output Level 2 Vrms ± 0.2

ESD Protection Human body model:

±8kV (air-gap discharge) ±4kV (contact discharge)

Power Supply 5V/ 2.6A DC (US/EU standards, CE/FCC/UL

certified)

Dimensions $145 \text{mm}(W) \times 113 \text{mm}(D) \times 30 \text{mm}(H)$

Weight g

Chassis Material Aluminum

Silkscreen Color Black

Operating Temperature $0^{\circ}\text{C} \sim 40^{\circ}\text{C}$

Storage Temperature $-20^{\circ}\text{C} \sim 60^{\circ}\text{C} / -4^{\circ}\text{F} \sim 140^{\circ}\text{F}$

Relative Humidity 20 ~ 90% RH (non-condensing)

Power Consumption 8.5W





www.cypeurope.com