

Preventing the fan from cooling the lamp may shorten the lamp life or cause malfunctions.

- Do not unplug the power cord without turning the power off.
- Do not unplug the power cord while the LAMP indicator is blinking.
- You cannot turn the power on or off while the LAMP indicator is blinking.