

instruction manual

AXC-MIDI MIDI Interface Card









Axcess Control Cards

AMX Limited Warranty and Disclaimer

AMX Corporation warrants its products to be free of defects in material and workmanship under normal use for three (3) years from the date of purchase from AMX Corporation, with the following exceptions:

- Electroluminescent and LCD Control Panels are warranted for three (3) years, except for the display and touch overlay components that are warranted for a period of one (1) year.
- Disk drive mechanisms, pan/tilt heads, power supplies, MX Series products, and KC Series products are warranted for a period of one (1) year.
- Unless otherwise specified, OEM and custom products are warranted for a period of one (1) year.
- Software is warranted for a period of ninety (90) days.
- Batteries and incandescent lamps are not covered under the warranty.

This warranty extends only to products purchased directly from AMX Corporation or an Authorized AMX Dealer.

AMX Corporation is not liable for any damages caused by its products or for the failure of its products to perform. This includes any lost profits, lost savings, incidental damages, or consequential damages. AMX Corporation is not liable for any claim made by a third party or by an AMX Dealer for a third party.

This limitation of liability applies whether damages are sought, or a claim is made, under this warranty or as a tort claim (including negligence and strict product liability), a contract claim, or any other claim. This limitation of liability cannot be waived or amended by any person. This limitation of liability will be effective even if AMX Corporation or an authorized representative of AMX Corporation has been advised of the possibility of any such damages. This limitation of liability, however, will not apply to claims for personal injury.

Some states do not allow a limitation of how long an implied warranty last. Some states do not allow the limitation or exclusion of incidental or consequential damages for consumer products. In such states, the limitation or exclusion of the Limited Warranty may not apply. This Limited Warranty gives the owner specific legal rights. The owner may also have other rights that vary from state to state. The owner is advised to consult applicable state laws for full determination of rights.

EXCEPT AS EXPRESSLY SET FORTH IN THIS WARRANTY, AMX CORPORATION MAKES NO OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. AMX CORPORATION EXPRESSLY DISCLAIMS ALL WARRANTIES NOT STATED IN THIS LIMITED WARRANTY. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED TO THE TERMS OF THIS LIMITED WARRANTY.

i

Table of Contents

Product Information1			
Specifications	1		
Connections	1		
Programming	3		
Send_Commands	3		

Product Information

The AXC-MIDI MIDI (Musical Instrument Digital Interface) Interface Card provides control to the following devices for integration with other studio devices such as lights, volume, and non-MIDI devices:

- Music keyboards
- MixersEqualizers
- Electronic instruments
- Routing switchers
- Computers
- Recording/reproducing decks
- Control systems

Specifications

Specifications	
Power Requirement	20 mA @ 12 VDC
Signal Capability	In, Out, and Thru
LEDs	CR1: data is being transmitted
	CR2: data is being received and passed Thru

Connections

FIG. 1 shows the connections for the AXC-MIDI.

1	•) IN +	To DIN pin 4
2 3	•) IN -	To DIN pin 5
3	•) OUT +	To DIN pin 4
4	•) OUT -	To DIN pin 5
4 5 6	•) Thru +	To DIN pin 4
6	•) Thru -	To DIN pin 5
7	•)	
8	•)	
9	·)	
10	•)	
11	•)	
12	·)	
13	·)	
14	•)	
15	•)	
16	$\left \cdot \right $	

FIG. 1 Connections

Programming

The AXC-MIDI uses the Axcess programming language. For more information, refer to the *Axcess Language* instruction manual.

Send_Commands

The following table lists the Send_Command functions for the AXC-MIDI.

Send_Commands		
RXON	Enables card to send incoming characters to the Master Card; this command is automatically sent to the Master Card when a buffer is created for the corresponding device.	
RXOFF	Disables the card's ability to send incoming characters to the Master Card; when the card is given power, it will initially perform this command automati- cally.	
RXCLR	Any characters waiting in a buffer to be sent to the Master Card will be erased.	
TXCLR	Any characters waiting in a buffer to be sent to a card will be erased and trans- mission to the buffer will stop.	
OUT=IN	Card will automatically transmit any characters Out received from In.	
OUT<>IN	Card will not automatically transmit Out any characters from In (default).	



AMX reserves the right to alter specifications without notice at any time.

brussels • dallas • los angeles • mexico city • philadelphia • shanghai • singapore • tampa • toronto • york 3000 research drive, richardson, TX 75082 USA • 469.624.8000 • 800.222.0193 • fax 469.624.7153 • technical support 800.932.6993