

# Wireless keyboard setup guide

Gateway

## 1 Turn on your Gateway Profile™ 5


## 2 Install the batteries

Open the mouse and keyboard's battery bay covers, then insert two AA batteries into each battery bay. Make sure that the + and – signs on the batteries match the + and – signs in the battery bay. Replace the covers.



## 3 Synchronize the keyboard and mouse


**A** Press the **KB/Mouse Connect** button on your Gateway Profile 5.




**B** Press the **Connect** button on the bottom of your wireless keyboard.



**C** Press the **KB/Mouse Connect** button on your Gateway Profile 5 again.





**D** Press the **Connect** button on the bottom of your wireless mouse.



Your wireless keyboard and mouse are now ready to use.  
You do not need to press the connection buttons each time you turn on your computer.

## The wireless keyboard



## Troubleshooting

- Make sure that the batteries have been installed correctly.
- Repeat the procedure for “Synchronize the keyboard and mouse” on the previous page.
- Make sure that you are not using the wireless keyboard or mouse on a metallic surface. Metallic surfaces can diminish the strength of the wireless signals.

