




COOKTOP PARTS

For Models: GY398LXPB03, GY398LXPQ03, GY398LXPS03
(Black) (White) (Stainless)

30" Slide-In
ELECTRIC OVEN
SELF CLEAN




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9762035	Literature Parts Installation Instructions	6	3196537	Trim, Cooktop Right	14	3196537	Screw
	9762257	Use & Care Guide		341196	Black	15	341196	Thermostat
	9761389	Tech Sheet		9759530BL	White	16	3196160	Screw
	9757680	Anti-Tip Instructions		9759530WH	Stainless	17	9758799	Bracket, Indicator Lamp
	3191638	Safe Cooking Tips		9759530SS	Black	18	9760520BL	Trim, Extension Black
	9759133	English		9759531BL	White		9760520WH	Trim, Extension White
		French		9759531WH	Stainless		9760520SS	Trim, Extension Stainless
2	9756450	Gasket	8	8523739	Light, Indicator	19	9759094	Spring, Locator
3	4454023	Bracket, Mounting	9	9759944	Thermostat	20	9759963	Bracket, Rear Support
4	9762069BL	Cooktop Black	10	9756821	Support, Wiring Element, Surface	21	8285962	Rail, Element (2)
	9756788WH	White		8523698	1200W LR,RF	22	246119	Screw
	4453764	Clip, Ceran (2)		8523696	1800W RR	23	9759628	Cover, Cooktop Rear
				8523692	2500W LF			
5			13	9757800	Bracket, Front Support			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: GY398LXPB03, GY398LXPQ03, GY398LXPS03
(Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Control Panel
	W10036010	Black
	W10036000	White
	W10035980	Stainless
2		Switch, Infinite
	9750638	LR, RF
	9750639	RR
	9750641	LF
3	9757475	Control, Migration
4	9757119	Bracket, Console
5	3196068	Lens, Indicator (2)


Illus. No.	Part No.	DESCRIPTION
6	W10036100	Bracket, Oven Control
7	8523265	Housing, Indicator Light (2)
8		Endcap
	9756611BL	Black
	9756611WH	White
	9756614BL	Black
	9756614WH	White

Illus. No.	Part No.	DESCRIPTION
9		Knob
	9756659BL	Black
	9756659WH	White
10	3196537	Screw
11	9780271	Screw
12	311865	Screw
13	W10078540	Membrane, Switch
14	3196172	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: GY396LXPB03, GY396LXPQ03, GY396LXPT03, GY396LXPS03
 (Black) (White) (Biscuit) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: GY398LXPB03, GY398LXPQ03, GY398LXPS03
(Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side Right	19	4451478	Support, Insulation Body, Side	38	4449743	Screw
	9757735BL	Black	20			39	4450118	Nut
	9757735WH	White		9760723PB	Black	40	4448717	Rack, Oven
	9757735SS	Stainless		9760723PW	White	41	9760766	Element, Convention Bake
		Left	21	9757461	Bracket, Side Panel	42	4449868	Block, Terminal
	9757734BL	Black	22	9760888	Latch, Motorized	43	3400080	Screw
	9757734WH	White	23	9759243	Thermostat	44	9757404	Box, Terminal
	9757734SS	Stainless	24	9757811	Brace, Side Panel	45	9757405	Cover, Terminal Box
2	3400832	Screw (2)	25	4455641	Side, Chassis	46	9759721	Insulator, Terminal Box
3		Hinge Receiver	26	4452234	Back, Chassis	47	9761958	Block, Terminal
	4455606	Right	27		Liner, Oven (Not Serviceable)	48	4452226	Fan Blade
	4455605	Left	28	9759890	Clip, Side Panel	49	4452227	Nut
4	W10105790	Bumper, Door (2)	29	4455636	Sensor	50	4451583	Motor, Convection Fan
5	3196537	Screw	30	9757717	Insulation	52	9759722	Insulation, Body Side
6	3196160	Screw	31	3196176	Screw	53	9760481	Washer
7	8303099	Top Chassis	32	9760771	Broil, Element	FOLLOWING PARTS NOT ILLUSTRATED		
8	4449809	Screw	33	9759713	Base, Chassis	INSULATION		
9	4452158	Tube, Vent	34	4448933	Retainer, Gasket		9756817	Insulation, Wrap
10	W10067870	Lens, Light (2)	35	4448444	Grommet, Mounting Rail		9756470	Insulation, Back
11	W10009930	Oven Light, Assembly (2)	36		Vent, Bottom Upper			
12	4452166	Bulb, Light (2)		9756481BL	Black			
13	4449154	Screw		9756481WH	White			
14	9760756	Frame, Front		9756481SS	Stainless			
15	W10074200	Gasket, Door	37		Trim, Bottom Vent			
16	4453951	Deflector, Vent Bottom		9756485BL	Black			
17	4452152	Bracket, Mounting		9756485WH	White			
18	9757685	Guide, Side Panel		9756485SS	Stainless			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: GY398LXPB03, GY398LXPQ03, GY398LXPS03
(Black) (White) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


DOOR PARTS

For Models: GY398LXPB03, GY398LXPQ03, GY398LXPS03
 (Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION
1	9759413	Panel, Door
2	9757706	Glass, Inner
3	4451722	Insulation, Door
4	4457132	Retainer, Glass
5		Hinge, Oven Door Right
	9760571	Black/White
	9760573	Stainless Left
	9760572	Black/White
	9760574	Stainless
6	9759225	Glass, Inner
7	4457114	Shield, Heat Bottom
8	9759229	Bracket, Glass Side
9	4457103	Shield, Heat Top
10	9759225	Glass, Inner Door
11	9759230	Bracket, Central
12	4450813	Bracket, Handle
13		Pad, Handle
	9759638	Right
	9759637	Left
14		Assembly, Door Kit
	9759641	Black
	9759639	White
	9759349	Stainless
15		Handle, Door
	4448854	Black
	4448855	White
16	4451040	Screw
17	4450863	Retainer, Glass Clip
18	9759635	Spacer, Door Glass

DRAWER PARTS

For Models: GY398LXPB03, GY398LXPQ03, GY398LXPS03
(Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Support, Drawer Rail
	9757687	Right
	9757686	Left
2	9763501BL	Support, Front & Rear
3		Brace, Drawer
	4453720	Right
	4453721	Left
4	9759965	Bracket, Base


Illus. No.	Part No.	DESCRIPTION
5		Side, Base
	9759953	Right
	9759954	Left
6	W10058460	Foot
7	9759943	Brace, Front
8	3196037	Foot Assembly
9		Rail, Storage
	9756836	Right
	9756838	Left
10	9757806	Drawer

Illus. No.	Part No.	DESCRIPTION
11		Guide, Roller
		Includes Roller
	9756841	Right
	9756842	Left
12	9760592	Panel, Drawer
13		Front, Drawer
	4453921BL	Black
	4453921WH	White
	4453921SS	Stainless
14		Handle, Drawer
	9756674BL	Black
	9756674WH	White
15	3196537	Screw
16	3400805	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: GY398LXPB03, GY398LXPQ03, GY398LXPS03
 (Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent Top
3	9759320	Blower
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
6	9759938	Bracket, Terminal Box
7	4449809	Screw (2)
8	9757118BL	Vent, Control Panel
9	4450038	Screw
10	4449040	Screw
11	4455352	Bracket, Blower

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: GY398LXPB03, GY398LXPQ03, GY398LXPS03
(Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>			<u>SPLICING WIRES--25FT.</u>			<u>WIRING HARNESS PARTS</u>		
	72017	White	<u>LENGTH</u>				9759538	Harness, Wire (Main)
	261869	Cord Brown	242828	Wire (12 Ga. 150 c Black)		9759702	Harness, Wire (Cooktop Power)	
	72032	Black	242820	Wire (14 Ga. 150 c Black)		9759701	Harness, Wire (Cooktop Left)	
<u>PAINT, SPRAY</u>			242821	Wire (14 Ga. 150 c Blue)		9759703	Harness, Wire (Cooktop Right)	
	350930	White	242822	Wire (14 Ga. 150 c Brown)		9759715	Conduit	
	261900	Citrine White	242830	Wire (14 Ga. 200 c Brown)		313660	Clip, Ground Wire	
	830864	Black	242823	Wire (14 Ga. 150 c Green)		4448664	Clamp	
<u>ADHESIVE</u>			242824	Wire (14 Ga. 150 c Orange)		4449809	Screw	
	591014	Adhesive Loctite (1/3 oz.)	242829	Wire (12 Ga. 150 c Red)		112432	Nut	
	482338	Sealer, Silastic (3 oz.)	242825	Wire (14 Ga. 150 c Red)		4450800	Screw, Ground	
			242831	Wire (14 Ga. 200 c Red)		3400015	Screw, Ground	
			242826	Wire (14 Ga. 150 c White)		<u>Miscellaneous</u>		
			242827	Wire (14 Ga. 150 c Yellow)		9782676	Anti-Tip Assembly Filler, Counter Top	
			242832	Wire (14 Ga. 200 c Yellow)		9757784BL	Black	
						9757784WH	White	
						9757784SS	Stainless	

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST