



AUDIOVOX[®]
ELECTRONICS CORP.

EX50

5.0" LCD MONITOR



Owner's Manual

Important Notice

It is unlawful in most jurisdictions for a person to drive a motor vehicle which is equipped with a television viewer or screen that is located in the motor vehicle at any point forward of the back of the driver's seat, or that is visible, directly or indirectly, to the driver while operating the vehicle. In the interest of safety, the EX50 should never be installed where it will be visible, directly or indirectly, by the operator of the motor vehicle.

Warnings

- Do not use any solvents or cleaning materials when cleaning the video Monitor.
- Do not use any abrasive cleaners, they may scratch the screen. Use only a lightly dampened lint free cloth to wipe the screen if it is dirty.
- Before putting on headphones always adjust the volume setting to the lowest position.
- Do not put pressure on the screen.
- Caution children to avoid touching or scratching the screen, as it may become dirty or damaged.

Table of Contents

A. Introduction.....	2
B. Cautions.....	2
C. Contents.....	3
D. Positioning the Monitor.....	3
E. Controls/Indicators/Connectors.....	4
F. Powering the Unit.....	4
G. Operation	5
H. Using Headphones	6
I. Specifications.....	6
Warranty.....	7

A. Introduction

Thank you for selecting the EX50, 5.0 inch Liquid Crystal Display (LCD) Monitor. It can be used as an additional monitor or used just to replace a lost or damaged monitor. The EX50 utilizes state of the art electronics and is designed for easy portability and is constructed to provide years of reliable, trouble-free service.

Please read this manual entirely prior to operation. This manual will assist you in installing the EX50 properly to obtain the best system performance.

B. Cautions

1. Use only the adapter supplied with this Monitor. When the system is left unattended and unused for long periods for a long periods of time, unplug it from the power source. Always disconnect the when power source first and then the jack from the system.
2. Ensure that the Monitor is installed in accordance with the instructions and illustrations provided in this manual.
3. To prevent fire or electric shock, do not expose this appliance to rain, moisture or long periods of direct sunlight. Keep the unit away from sources of heat. Do not operate or store the unit close to strong magnetic fields. Do not spill or spray liquid of any kind on or in the system (this may result in a fire or electric shock).
4. To ensure proper ventilation, never cover or block the slots and openings with a cloth or other material.
5. To reduce the risk of electric shock do not remove the back cover of the unit. There are no user-serviceable parts inside. Contact qualified service personnel if your system is in need of repair.
6. When cleaning, make sure the system is unplugged from power source.

C. Contents

<u>ITEM</u>	<u>QTY.</u>
1. 5.0" LCD Monitor VBPEX56	1
2. AC to DC Power Adapter	1
3. DC Power Adapter	1
4. 5.0" LCD Monitor Pouch	1
5. 1/8 to RCA A/V Adapter cable	1

D. Positioning the Monitor

Option 1 Vehicle Headrest (Refer to Figure 1)




Figure 1

Slide the Monitor into the pouch, feed the bottom piece of the Monitor into the long slot at the bottom of the pouch and attach the Velcro strap to fasten the Monitor in the pouch. Then loop the strap of the pouch around the headrest in the vehicle and pull the end of the strap while holding the buckle until the pouch is tightly secured.

Option 2 Flat Surface (Refer to Figure 2)



Figure 2

Rotate the base of Monitor backward and place it on a flat surface. Adjust the screen for a proper viewing angle. This can be done with the Monitor inside or outside the pouch.

E. Controls/Indicators/Connectors (Refer to Figure 3)




Figure 3

1. AV In Jack
2. DC 9V Input Jack
3. Power Off/On Switch
4. Power LED Indicator
5. Brightness Up/Down Control
6. Volume Up/Down Control
7. Headphone Jack # 1
8. Headphone Jack # 2

F. Powering the Unit

Option 1 Indoor Power (Refer to Figure 4)




Figure 4

Using the AC/DC adapter supplied with the EX50, plug the connector end into the DC 9V IN jack on the side of the Monitor. Plug the AC/DC adapter into a 110V AC power receptable. This can be done with the Monitor inside or outside the pouch.

Option 2 Vehicle Power (Refer to Figure 5)




Figure 5

Using the DC Power adapter supplied, plug the connector end into the DC 9V IN jack on the side of the Monitor. Plug the DC Power adapter into a vehicle power outlet.

G. Operation (Refer to Figure 3 & Figure 6)

1. Switch the POWER ON/OFF to On and turn the Monitor on. The POWER LED will light.
2. Using the 1/8 to RCA A/V adapter cable connect the signal output from an auxiliary source such as camcorder, Video Game, DVD Player, Video Cassette Player etc. to the AV IN Jack of the EX50.
3. Use the BRIGHTNESS UP/DOWN control to adjust the picture to a desired setting.
4. Use the VOLUME UP/DOWN control to decrease or increase volume level.




Figure 6

H. Using Headphones (Refer to Figure 6)

Optional wired headphones may be used with the EX50. Simply plug in the headset to either Headphone 1 Jack* or Headphone 2 Jack on the right side of the monitor.

***NOTE:** Using Headphone Jack 1 will disconnect the internal speakers.

I. Specifications

Color System:	NTSC/PAL
Screen Size:	5.0 Inches
Power Supply:	DC 9 V
Power Consumption:	5.5W
Operating Temperature:	41~104° F (5~40°C)
Operating Humidity:	10-75%
Storage Temperature:	4~140° F (-20~60°C)
Dimensions (W x D x H):	7.80" x 1.46" x 8.11"
Weight:	0.84 lbs



AUDIOVOX
ELECTRONICS CORP.

90 DAY LIMITED WARRANTY

Applies to Audiovox Video Products

AUDIOVOX ELECTRONICS CORP. (the Company) warrants to the original retail purchaser of this product that should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 90 days from the date of original purchase, such defect(s) will be repaired or replaced with reconditioned product (at the Company's option) without charge for parts and repair labor.

To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of defect(s), transportation prepaid, to the Company at the address shown below.

This Warranty does not extend to the elimination of externally generated static or noise, to correction of antenna problems, to costs incurred for installation, removal or reinstallation of the product, or to damage to tapes, discs, speakers, accessories, or electrical systems.

This Warranty does not apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or by removal or defacement of the factory serial number/bar code label(s). THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN A PERIOD OF 15 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

U.S.A. : AUDIOVOX ELECTRONICS CORPORATION, 150 MARCUS BLVD., HAUPPAUGE, NEW YORK 11788 1-800-645-4994

CANADA : CALL 1-800-645-4994 FOR LOCATION OF WARRANTY STATION SERVING YOUR AREA

128-5556D



For Customer Service
Visit Our Website At

www.audiovox.com
Product Information, Photos,
FAQ's Owner's Manuals