CURTIS



Table of Contents

SAFETY INSTRUCTIONS 1		
ACCESSORIES		
WARNING		6
REMOTE CONTROL		7
CONNECTION		8
CONNECTION EQUIPMENT		
CONNECTION TO TERMINALS 10		
OPERATING		11
SPECIFICATIONS		12

Cleaning Unplug this product fro damp cloth for cleaning



R	Е

1. AUX、Gam
2. Memo 1
3. Memo 2
4. Memo 3
5. Center vo

- 13. Mute 14.St.by

OPERATING

Power-on

(be sure to check the connections before you power on your system) 1.plug the AC cord to AC socket.

2.press **POWER** button on the rear panel

3.5.1 LED lights on.

4.press INPUT button to select the required input sources

Source input

This function could ensure the shift of audio. You may choose each mode of

5.1.S.Vol and 2.1 by pressing 5.1-2.1 Button on the remote control or front panel.

SPECIFICATIONS

Total output power:150W

Impedance :Subwoofer-40HM, Satellite-80HM drive unit : subwoofer: 4" :front : 3" :center : 3" :surround : 3 " frequency response:30Hz-20KHz separation of satellite:45dB :80dB S/N Power supply:AC230v/50Hz

🚵 CE 🍄 💆 🖽

IMPORTANT SAFETY INSTRUCTIONS CAUTION: Please read and observe all warnings and instructions given in this user man the unit. Retain this manual for future reference. This set has been designed personal safety. Improper use can result in electric shock or fire hazard. The this unit will protect you if you observe the following procedures for installatio is fully transistorized and does not contain any parts that can be repaired by t Do not remove the cabinet cover, or you may be exposed to dangerous volta service personnel only. Please read the operating instructions carefully, and follow all the operating **Power sources** This product should be operated only from the type of power source indicat usage of the battery power and other power source, refer to the operating is Ventilation Slots and opening in the cabinet are provided for ventilation and to ensure re¹ and to protect if from overheating, and these openings must not be blocked o not be placed on the bed or sofa. rug or other.

Heat sources The product should be situated away from the heat source such as radiators produce heat. Water and moisture

Do not use this product near water-for example, near a bathtub, wash bowl, basement; or near a swimming pool and the like.

duct from the outlet before cleaning. Do not use liquid clean

```
Over loading
Do not overload wall outlets; extension cords, or integral convenience recept
of fire or electric shock.
```

manual and those marked on ned and manufactured to assure	Lightning In order to prevent from the damage caused by storm or the player isn't used for a long period of time, pull out the plug from the outlet. Never push objects of any kind into this product through openings in order to prevent from a fire or electric
The safeguards incorporated in llation, use and servicing. This unit	shock, Never spill liquid of any kind on the product.
by the user.	Object and liquid entry
oltage, Refer servicing to qualified	Attachments Do not use attachments not recommended by the product manufacturer as they may cause hazards.
ing and other instructions.	Accessories Do not place this product on an unstable cart. The product may fall, causing serious personal damage to the product.
ated on the marking label. For the g instructions.	Servicing Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage
e reliable operating of the product ed or covered. This product should	or other hazards. Refer all servicing to qualified service personnel. Replacement parts When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire,
tors, stoves or other products that	electric shock, or other hazards. Safety check
wl, kitchen sink, or laundry tub; in	Upon completion of any service or repairs to this product, ask the service technician to perform safety check to determine that the product is proper operating condition.
aner or aerosol cleaners. Use a	
ceptacles as this can result in a risk	
1	2

ACCESSORIES

Sub-woofer Center Satellite Link cable for Front Link cable for Center Link cable for Surroun Input cable **Remote Control** 1.5V AAA Battery **Instruction Manual**



CONNECTING EQUIPMENT

Red jacks and plugs: For the right channel of audio signals White jack and plugs: For the left channel of audio signals

NOTE:

other noise interference.

IMPORTANT:

cord.

	1PCS 1PCS 4PCS 2PC(3m) 1PC(3m)
ıd	2PC(8m)
	3PCS
	1PCS
	2PCS
	1PCS

INTRODUCTION

HOME THEATRE SYSTEM

Active Sub- woofer With Satellite Speakers

Operating Manual

Congratulations On Your Purchase!

Your new Home theatre with active Sub-woofer system is designed to deliver maximum enjoyment. Please take a few moments to read this manual thoroughly. It will explain the features and operation of your unit and help ensure a trouble free installation.

Unpacking and installation

Please unpack your unit carefully, We recommend that you save the carton and packing material. they will be helpful if you ever need to move your unit and may be required if you ever need to return it for service. To avoid damage, never place the unit near radiators, in front of heating vents, In direct sun light, in excessively humid or near water.

3 4

