




User's Manual



Before operating the Monitor, please read this manual thoroughly and retain it for future reference.







1.Power Indicate Light 6.MENU

2.R/C Window 7.Positive Increase 3.Power 8.VGA Input

4.V1/V2/VGA Change 9.USB Input for Touch Screen Control

5.Negative Decrease 10.DC IN Jack

CAUTION:

For your safety, please rotate the angle of the display or turn off the display while driving.

SPECIAL STATEMENT:

LCD may have a few bright dots, which is normal for the matrix display technology, and doesn't indicate defects of faults

NOTICE:

- •Please operate instruction manual completely before use;
- •The unit is manufactured with precision elements pay attention to protection against dampness;
- $\ \, \textbf{P} \textbf{r} \textbf{r} \textbf{e} \textbf{m} \textbf{ the hard object from scratching LCD surface;} \\$
- •High voltage inside non-technical authorized person is not allowed to dismantle the unit.



REMOTE CONTROL

1. Power


2. V1/V2/VGA Change

3. Positive Increase

4. Menu

5. Negative Decrease

6. Reset



SPECIFICATIONS:

Display Size: 9.2 inch (16:9) Resolution: 480*R.G.B.* 234

Dual Video Inputs, 1 Audio Input VGA Input System: PAL & NTSC Auto Switching

Power Supply: DC +12V

Built in Speaker

All Functions can be Controlled by Remote Control

Touch Screen Wide View Angle

IF YOUR MONITOR IS WITH TOUCH SCREEN, PLEASE INSTALL THE DRIVER FROM THE DISC BEFORE USING

P.S.: PLEASE DO NOT CONNECT THE USB CABLE TO THE MONITOR BEFORE INSTALLING THE DRIVER.