









Quick Reference Guide

Parts Descriptions



- 1 Handset
- 2 Speaker
- 3 Multi-operation buttons
- 4 Call indicator
- 5 Liquid crystal display
- 6 Voice select button
- 7 One-touch Dial buttons
- 8 Cancel button
- 9 Function button
- 10 Set button
- 11 Redial button (再ダイヤル) )
Phone book button (電話帳) )
Volume control buttons (音量) 
- 12 Antenna
- 13 Auto Answer button & indicator
- 14 Playback/Call Record button
- 15 Flash/Clear button
- 16 Intercom button
- 17 Hold button
- 18 Monitor button
- 19 Numeral/Character buttons
- 20 Tone button (to switch to DTMF tone)



- 1 Earpiece
- 2 Liquid crystal display
- 3 Voice select button
- 4 Send/Answer button & indicator
- 5 Hold/Caller ID button
- 6 Numeral/Character buttons
- 7 Tone button (to switch to DTMF tone)
- 8 Flash button
- 9 Microphone
- 10 Multi-operation buttons
- 11 Off button
- 12 Redial button (再ダイヤル) )
Phone book button (電話帳) )
Volume control button (音量) 
- 13 Intercom/Clear button
- 14 Speakerphone button & indicator
- 15 One-touch Dial button
- 16 Speaker
- 17 Battery cover

本機は日本国内用です。国外での使用に対するサービスは致しかねます。
This product is designed for use in Japan.
Panasonic cannot provide service for this product if used outside Japan.

Base unit (VE-GP01)**To make a call**

Lift the handset. → Dial.

To receive a call

When the phone rings... → Lift the handset.


To place the current call on hold

Press  (17) during a call.




(You can place the handset on the base unit.)

To retrieve the held call

If you have returned the handset on the base unit, lift the handset.


If you have not returned the handset on the base unit, press  again.

To transfer the held call to the personal phone

Press  (16) during a call. → Press  - .


(Intercom No.). → Place the handset on the base unit when the other party answers.


To use TAM (Telephone Answering Machine)


When you leave home, press  (13) to turn on the indicator.

(To deactivate, press  again to turn off the indicator.)


→ When receiving a call while TAM is activated, it answers the call automatically in Japanese, and records the incoming messages.

Then, the  indicator starts flashing.

→ When you return home, press  to play back the messages.

The  indicator turns off and the answering mode is deactivated.

After playing back the messages, press  to erase the messages or press  to keep the messages.

To play back the message while TAM is deactivated, press  (14).

*Up to 50 messages can be recorded for approx. 18 minutes in total.


To hear recorded messages while away from home (Remote control)**Preparation before you leave home**

Store a remote control number.

With the handset placed on the base unit, press

    .

→ Enter the desired 4-digit number. → Press .

When you leave home, press  to turn on the indicator.

To hear messages

Dial your home phone number. → While the outgoing message is played back...



→ Enter your remote control number.

→ Announcement → Press . → You will hear recorded messages if any.



NOTE

This operation can be made only from telephones which can send DTMF signals.



Personal phone (KX-FKN510)**To make a call**

Lift the personal phone from the charger and press  (4). → Dial.....To end the call, place the personal phone on the charger or press  (11).




To receive a call

When the phone rings... → Lift the personal phone from the charger or press . → Talk.....To end the call, place the personal phone on the charger or press .

To make a call using the speakerphone (Hands-free talk)

Press  (14). → Dial. → Talk to the microphone.....To end the call, place the personal phone on the charger or press .

To receive a call with the speakerphone (Hands-free talk)

When the phone rings... → With the personal phone placed on the charger, press  or . → Talk to the microphone.....To end the call, press .




To place the current call on hold

Press  (5) during a call.





To retrieve the held call

Press  or .

To transfer the held call to the base unit

Press  (13) during a call. → Press . Place the personal phone on the charger, or press  when the other party answers.

To transfer the held call to another personal phone

Press  during a call. → Press  -  (Intercom No.). → Place the personal phone on the charger, or press  when the other party answers.

The number after the button shows the location of the button described in the previous page.