




CONVECTION OVEN PARTS

For Models: AMC7159TAB0, AMC7159TAS0
(Black) (Stainless)

CONVECTION
MICROWAVE OVEN



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONVECTION OVEN PARTS

For Models: AMC7159TAB0, AMC7159TAS0

(Black) (Stainless)

| <u>Illus. No.</u> | <u>Part No.</u> | <u>DESCRIPTION</u> |
|-------------------|-----------------|------------------------------|
| 1 | | Literature Parts |
| | W10134751 | U & C Guide |
| | W10153569 | Service Manual |
| | | Cooking Guide |
| | W10134321 | English |
| | W10134324 | Tech Sheet |
| 2 | 8171878 | Sensor |
| 3 | 4358450 | Screw |
| 5 | 8183575 | Bracket, Center |
| 6 | 8183574 | Bracket, Left |
| 7 | 8183576 | Bracket, Lower |
| 9 | W10153234 | Insulator |
| 10 | 8183694 | Thermostat |
| 11 | 8183583 | Thermistor |
| 12 | 8183582 | Fan |
| 13 | 4358460 | Bushing |
| 14 | 8183581 | Convection Element |
| 15 | 8183577 | Clip, Conv Element |
| 16 | 8183567 | Duct, Magnetron |
| 17 | W10153235 | Insulation |
| 18 | 8183566 | Shield, Back Insul |
| 19 | 4358466 | Fan Blade |
| 20 | 4358467 | Bracket, Convection Motor |
| 21 | 8183565 | Convection Motor |
| 22 | 4358192 | Screw |
| 23 | 4358477 | Washer |
| 24 | 4358478 | Washer |
| 25 | 4358362 | Screw |
| 26 | 8183572 | Screw |
| 27 | 4358380 | Screw |
| 28 | 4358476 | Nut |
| 29 | 4358474 | Screw |
| 30 | 8183591 | Harness, Wire |
| 31 | 4358475 | Nut |


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN INTERIOR PARTS

For Models: AMC7159TAB0, AMC7159TAS0

(Black)

(Stainless)



| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-----------------|
| 1 | 8183771 | Filter, Noise |
| 2 | 8183563 | Air Duct |
| 3 | 8183573 | Bracket, Damper |
| 4 | 8183592 | Lamp |
| 5 | 8183586 | Motor, Stirrer |
| 6 | 4158940 | Switch, Micro |
| 7 | 4358188 | Screw |
| 8 | 4358381 | Screw |


| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-----------------|
| 11 | 53001581 | Magnetron |
| 12 | 8183507 | Fuse |
| 13 | 8183584 | Power Cord |
| 14 | 8183569 | Cover, Back |
| 16 | 8183579 | Guide, Suction |
| 18 | 8183585 | Motor, Fan |
| 19 | 53001365 | Capacitor, H.V. |
| 20 | 4359161 | Bracket, H.V.C. |
| 21 | 4358379 | Fan |

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|---------------|
| 22 | 4358192 | Screw |
| 23 | 8171879 | Cable, Diode |
| 24 | 8184815 | Screw |
| 25 | 4359792 | Screw |
| 26 | 4358489 | Screw |
| 27 | 4358357 | Screw |
| 28 | 8206266 | Harness, Main |
| 29 | 8171862 | Screw |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN CAVITY PARTS

For Models: AMC7159TAB0, AMC7159TAS0
(Black) (Stainless)



| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|---------------------|
| 1 | W10153233 | Outer Case Black |
| 2 | 8183557 | Canopy |
| 3 | 8183554 | Motor, Turntable |
| 4 | 8183559 | Glass, Lamp |


| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|------------------|
| 6 | 8171863 | Shaft, Turntable |
| 7 | 8183560 | Ring Assembly |
| 8 | 8172138 | Tray |
| 9 | 8172251 | Rack |
| 10 | 4358192 | Screw |

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
| 11 | 4358829 | Screw |
| 12 | 4358188 | Screw |
| 13 | 4358045 | Screw |
| 14 | 8172250 | Pan, Drip |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BASE PLATE PARTS

For Models: AMC7159TAB0, AMC7159TAS0
(Black) (Stainless)




| Illus. No. | Part No. | DESCRIPTION |
|-------------------|-----------------|--------------------|
| 1 | 8183568 | Plate, Base |
| 2 | 8172082 | Transformer |
| 3 | 8171902 | Cap |
| 4 | 4358192 | Screw |
| 5 | 4358489 | Screw |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LATCH BOARD PARTS

For Models: AMC7159TAB0, AMC7159TAS0
(Black) (Stainless)




| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|--------------------------------------|
| 1 | | Assembly, Latch (Non-Serviceable) |
| 2 | 8183558 | Latch Board |
| 3 | 4158940 | Micro Switch |
| 4 | 4158941 | Micro Switch |
| 5 | 4358795 | Lever, Switch |
| 6 | 4358271 | Screw |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: AMC7159TAB0, AMC7159TAS0

(Black) (Stainless)




| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|-------------------|
| 1 | | Control Panel |
| | W10153229 | Black |
| 2 | | Membrane |
| | W10153227 | Black |
| 3 | W10153231 | Microcomputer |
| 4 | 4358451 | Screw |
| 5 | | Membrane/Panel |
| | W10153243 | (Stnls. Mdl.Only) |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: AMC7159TAB0, AMC7159TAS0
(Black) (Stainless)



| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|---------------------|
| 1 | W10153223 | Door Assembly Black |
| | W10153237 | Stainless |
| 2 | W10153195 | Panel, Door Black |
| | W10153239 | Stainless |

| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|-------------|
| 3 | W10153224 | Glass |
| 4 | 8183543 | Frame, Door |
| 5 | 8183544 | Choke Cover |
| 6 | 8183882 | Spring |
| 7 | 8171850 | Latch |

| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|--------------|
| 8 | 8171798 | Cap |
| 9 | W10153225 | Handle Black |
| | W10153238 | Stainless |
| 10 | W10153236 | Screw |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST