



# KitchenAid® COOKTOP PARTS

For Models: KERA205PWH1, KERA205PBL1, KERA205PBT1, KERA205PSS1  
 (White) (Black) (Biscuit) (Stainless Steel)

30" ELECTRIC CERAN  
 FREE STANDING RANGE  
 CONVECTION OVEN




Illus. No.	Part No.	DESCRIPTION
1	9759923	Literature Parts Installation Instructions
		Anti-Tip Template
	9757142	English/Spanish
	9757143	English/French
	9758363	Use & Care Guide
	9758315	Tech Sheet
	3191638	Safer Cooking Tips
	9757645	Guide, Easy Set
2	3149191	Spring, Locator
3	3196170	Screw
4		Cooktop
	9756979	White
	9758348	Black
	9756980	Biscuit
	9756981	Stainless
5	8523739	Light, Indicator (Hot Surface)
6	8523741	Bracket, Ind Light
7		Element, Surface
	9757027	2500/1000 W - LF
	8273994	1200 W - LR
	8273993	1800 W - RF
	9757031	1800/800 W - RR
	9757028	100 W - CR
9		Bracket, Element
	8272791	(2)
	8273720	(1)
10	3196169	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: KERA205PWH1, KERA205PBL1, KERA205PBT1, KERA205PSS1  
 (White) (Black) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION		
1	9756959	White Left Hand	4	9757030	Switch, Infinite LF (Dual)	12	9761219	Control, Range		
	9756958	White Right Hand		3148953	RF/RR (Green)		13	4449809	Screw	
	9756961	Black Left Hand		3148952	LR (Yellow)		14	9757972	Cover, Box	
	9756960	Black Right Hand		5	8523266		Light, Indicator	15		Switch, Warming
	9756963	Biscuit Left Hand		6	3196068		Lens, Light (2)		9757406WH	White
2	9756962	Biscuit Right Hand	7		Knob (4)		9757406BL	Black		
		Membrane Switch		9756941	White		9757406BT	Biscuit		
	9756538	White		9756943	Black	16	3400882	Screw		
	9756535	Black		9756942	Biscuit		17	9758319	Cover, Rear (Console)	
3	9756536	Biscuit		9756944	Cashmere Metallic	18		Cover, Vent		
	9756537	Stainless Steel	8	9756934	Shield, Heat			9758352	White	
		Panel, Backguard	9	9761078	Membrane Insert			9758354	Black	
	9756730	White	10	9756999	Cover, Rear			9758353	Biscuit	
	9756727	Black	11		Switch, Simmer			9758355	Cashmere Metallic	
	9756728	Biscuit		9758366WH	White					
	9756729	Stainless Steel		9758366BL	Black					
				9758366BT	Biscuit					
				9758366CM	Cashmere Metallic					

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS

For Models: KERA205PWH1, KERA205PBL1, KERA205PBT1, KERA205PSS1  
(White) (Black) (Biscuit) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS


For Models: KERA205PWH1, KERA205PBL1, KERA205PBT1, KERA205PSS1  
 (White) (Black) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2	8273905	Support, Corner LR	25	3195987	Support, Corner RR	47	3196566	Screw
3		Panel, Side (2)	26	3196548	Fuse, Thermal	49	3196169	Screw
	8053830	White-Textured	27	9758525	Element, Convection	50	9758925	Fan Motor, Convection
	8053832	Black-Textured	28	3186116	Support, Oven (2)	51	4452226	Fan Blade
	8272519	Biscuit-Textured	29	3186034	Bracket, Service	52	4452227	Nut
4	9761013	Latch, Door	30	9757136	Block, Terminal	53	9755776	Cover, Convection Fan
5	3196961	Rod, Latch		112432	Nut (3)	54	9759689	Card, Insulator
6	9757241	Latch Asm, Rear	31	9757029	Back, Main	55	9757088	Baffle, Convection
7	3195737	Seal, Oven Flange	32	9755769	Tray, Hidden Bake Element	56	9756518	Transformer
8	9758518	Element, Broil	33	9758221	Vent Tube Asm	57	9761222	Appliance Manager
9	9755770	Element, Bake Hidden	34	3196701	Light Socket Assy	58	9757970	Cover
10	8522416	Seal, Oven Door	35	311255	Bulb, Oven Light	59	9757239	Rod - Dr Switch
11	9758701	Spacer, Door	36	9755771	Cover, Tray	60	9758213	Screen - Catalyst
12	9757262	Switch, Door	38	3196165	Screw	61	3196560	Screw(2)
14	3196037	Foot, Front (2)	39	3196168	Screw	62	8533930	Screw
15	9758224	Frame, Front	40	3196178	Screw	<b>INSULATION</b>		
16	8054068	Tray, Insulation	41	3196174	Screw		8272616	Insulation, Wrap
17	3196576	Clip, Panel (6)	42	3196179	Screw		9755772	Insulation, Back
18	9760314	Rail, Base (2)	43	3196177	Screw		8272613	Insulation, Vent
19	312701	Foot, Rear (2)	44	3196176	Screw		9757974	Insulation, GOC
20	3196091	Shield, Outer (2)	45	3196172	Screw			
21	3196092	Shield, Inner (2)	46	3400016	Screw			
22	8523803	Retainer, Side (2)						
23	8273902	Sensor, Oven						
24	3195736	Support, Front (2)						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Models: KERA205PWH1, KERA205PBL1, KERA205PBT1, KERA205PSS1  
(White) (Black) (Biscuit) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS


For Models: KERA205PWH1, KERA205PBL1, KERA205PBT1, KERA205PSS1  
 (White) (Black) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Trim, Door Top
	9756965	White
	9756967	Black
	9756966	Biscuit
	9756969	Cashmere Metallic
2	8534065	Screw
3		Handle, Door
	9758293	White
	9758294	Black
	9758295	Biscuit
	9782649	Stainless Steel
4	3186292	Liner, Door
5	8522414	Seal, Window
6	9758162	Glass, Inner (2)
7	3186289	Frame, Glass
8	8272618	Insulation, Door
9	3186297	Retainer, Insul.
10		Hinge, Door
	8053807	White, Black And Biscuit Models
	8272822	Stainless Model
11		Glass, Outer Door
	9757039	White
	9757041	Black
	9757040	Biscuit
	9757043	Stainless Steel
12		Trim, Side
	8523172	White Left Hand
	8523166	White Right Hand
	8523171	Black Left Hand
	8523165	Black Right Hand
	8523173	Biscuit Left Hand
	8523167	Biscuit Right Hand
	9758358	Cashmere Metallic, Left Hand
	9758357	Cashmere Metallic, Right Hand
13	3196160	Screw
14		Trim, Lower
	8523175	White
	8523177	Black
	8523178	Biscuit
	8523180	Stainless Steel
15	3196025	Clip, Glass (4)
18	3196161	Screw
19	3196925	Clip, Door Stop
20	3196165	Screw
22	3196794	Bracket, Window(2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DRAWER & BROILER PARTS

For Models: KERA205PWH1, KERA205PBL1, KERA205PBT1, KERA205PSS1  
(White) (Black) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (3)
2	3195996	Grill, Broiler
3	3196076	Pan, Broiler
4	8272605	Drawer, Storage
5	9758200	Bracket, Drawer(2)
6		Rivet, Push (2)
	3196814	White
	3196813	Black
	3196815	Biscuit

Illus. No.	Part No.	DESCRIPTION
7		Panel, Drawer Frnt
	9756325	White
	9756327	Black
	9756326	Biscuit
	9756328	Stainless Steel
8		Handle, Drawer
	9756952WH	White
	9756952BL	Black
	9756952BT	Biscuit
	9756952CM	Cashmere Metallic

Illus. No.	Part No.	DESCRIPTION
9	3181534	Rack, Roasting
10	3196168	Screw
11	8522669	Spacer, Glide
12	9756711	Heat Shield Drawer
13		Rail, Drawer
	8274190	Left Hand
	8274191	Right Hand
14	487939	Nut(2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS

For Models: KERA205PWH1, KERA205PBL1, KERA205PBT1, KERA205PSS1  
 (White) (Black) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Following Parts Not Illustrated

**SPLICING WIRES--25FT.**

**LENGTH**

- 242828 Wire, Black  
12 Ga. 150° c
- 242821 Wire, Blue  
14 Ga. 150°c
- 242822 Wire, Brown  
14 Ga. 150°c
- 242830 Wire, Brown  
14 Ga. 200°c
- 242823 Wire, Green  
14 Ga. 150°c
- 242824 Wire, Orange  
14 Ga. 150°c
- 242825 Wire, Red  
14 Ga. 150°c
- 242831 Wire, Red  
14 Ga. 200°c
- 242827 Wire, Yellow  
14 Ga. 150°c

**REFINISHING MATERIAL**

- 799832 Kit, Porcelain  
Repair (White)
- 242756 Touch-Up  
Self-Clean(1/2 Pt)
- 261582 Grease

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**INSULATION**

- 261514 Insulation,  
Fiberglass (1-1/2"  
x 24" x 120")
- 240132 Insulation,  
Fiberglass (2-1/2"  
x 22" x 120")
- 313660 Clip, Ground Wire  
x 22" x 120")

**PAINT, TOUCH-UP (1/2oz.)**

- 72017 White
- 4392899 Biscuit
- 511873 White Porcelain  
(2 Oz.)

**PAINT, PRESSURIZED SPRAY  
(12 oz.)**

- 350930 White
- 4392901 Biscuit
- 285006 Superior Black
- 206922 Primer (White)

**PAINT, BULK (1 qt.)**

- 799344 White (Uncut)
- 4392900 Biscuit (Uncut)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**ACCESSORY PARTS**

- 241430 Foil, Aluminum  
Oven (18" x 25')
- 4456147 Cleaner, Glass
- 2261590 Cleaner  
(Stainless Steel)

**ANTI-TIP KIT**

- 9757976 Anti-Tip Kit

**WIRING HARNESS PARTS**

- 9758191 Harness,  
(Sensor/Dr Switch)
- 313438 Clip, Wire Harness
- 9756707 Harness, Oven
- 9756745 Harness, Cooktop  
(Left w/Dual)
- 9757332 Harness, Cooktop  
(Right w/ wm)
- 9757315 Harness, Console
- 9756550 Harness, Bake  
Element (Hidden)
- 8524132 Shield, Wiring (2)
- 8523279 Wire, Ground
- 313660 Clip, Ground Wire
- 3196173 Screw
- 3196154 Screw, Ground

**Miscellaneous**

- 3196897 Pin Kit-Dr Removal