




# COOKTOP PARTS

For Models: GR773LXSQ1, GR773LXSS1, GR773LXSB1  
(White) (Stainless Steel) (Black)

30" ELECTRIC CERAN  
FREESTANDING RANGE  
SELF CLEAN CONVECTION OVEN



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	9763001	Owners Manual
	9762982	Tech Sheet
	9762996	Installation Instructions
		Template, Anti-Tip
	9757143	English/French
	9757142	English/Spanish
	9762761	Brochure, Tips Safe Cooking


Illus. No.	Part No.	DESCRIPTION
2	W10035930	Spring, Locator
3	3196170	Screw
4		Cooktop
	9763334	White
	9763336	Black
7		Element, Surface
	9759351	2400/1200 W - LF
	8523698	1200 W - LR
	8523698	1200 W - RR
	9759351	2400/1200 W - RF
	9762851	120 V - CR

Illus. No.	Part No.	DESCRIPTION
8	8524132	Shield, Wiring
9		Bracket, Element
	8272791	(2)
	8273720	(1)
10	3196169	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: GR773LXSQ1, GR773LXSS1, GR773LXSB1  
(White) (Stainless Steel) (Black)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10009040	Endcap White Left Hand	6	3196068	Lens, Light	15	9756366	Cover, Rear (Console)
	W10009050	White Right Hand	7	9757132	Knob, Infinite (4) White	16	3400882	Screw
	W10009080	Black Left Hand		9758129	Black	17	8272820	Switch
	W10009090	Black Right Hand	8	8523280	Shield, Heat	18		Button
2	9762095	Bracket, Console	9	9763550	Glass Switch Membrn White		9757492	White
3	9762585	Panel, Backguard White		9763551	Black		9758491	Black
	9762588	Stainless Steel	10	9756999	Cover, Rear	20	9762426	Cntr Cable, Flex
	9762586	Black	11		Bezel, Keep Warm	21	9757358	Reflector, Light
4		Switch, Infinite		9757489	White	22		Screw
	9758060	Left Front (Dual)		9758489	Black		3196166	White
	3148951	Left Rear	12	9763050	Control, Range		3196168	Black
	3148951	Right Rear	13	3196178	Screw	23	9757490	Support, Glass
	9758060	Right Front (Dual)	14	9757613	Nameplate	24	3196178	Screw
5	8523265	Light, Indicator						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS

For Models: GR773LXSQ1, GR773LXSS1, GR773LXSB1  
(White) (Stainless Steel) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS


For Models: GR773LXSQ1, GR773LXSS1, GR773LXSB1  
(White) (Stainless Steel) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9761300	Vent Tube Asmbly	22	9757029	Back, Main	47	9759689	Card, Insulator
2	8273905	Support, Corner LR	23	9757262	Switch, Door	48	9758525	Element, Convection
3		Panel, Side (2)	24	3196701	Light Socket Assy	49	9758925	Fan Motor, Convection
	8053830	White	25	311255	Bulb, Oven Light			
	8053832	Black	26	9755771	Cover, Tray	50	4452226	Fan Blade
4	W10010350	Seal, Oven Flange	27	8273902	Sensor, Oven	51	4452227	Nut
5	8522416	Seal, Oven Door	28	9757970	Cover	52	9755775	Cover, Fan
6	9757341	Element, Broil	29	3196179	Screw	53	9755776	Bracket, Fan
7	9755770	Element, Bake (Hidden)	30	4449809	Screw	54	9757311	Transformer
8	3195736	Support, Front (2)	31	3400016	Screw	55	8533930	Screw
9	3196548	Fuse, Thermal	33	3196172	Screw	56	9757972	Cover, Box
10	9761909	Appliance Manager	34	W10031780	Screw	57	9761301	Screen – Catalyst
11	3196037	Foot, Front (2)	35	3196566	Screw	58	3196560	Screw (2)
12		Frame, Front (Not Serviced)	36	3196168	Screw	59	3196178	Screw
13	8054068	Tray, Insulation	37	3196174	Screw	60	112432	Nut (3)
14	3196576	Clip, Panel (6)	38	9758238	Retainer, Side (2)	61	9761490	Insulation
15	9760314	Rail, Base (2)	39	9760407	Brkt–Mounting	62	9761512	Clip, Mounting
16	9761935	Foot, Rear (2)	41	9761013	Latch, Door			
17	3195987	Guard, Wire	42	3196961	Rod, Latch			
18	9757239	Rod – Dr Switch	43	9757241	Latch Asy, Rear			
19	3186116	Support, Oven (2)	44	9758701	Spacer, Door			
20	3186034	Bracket, Service	45	3196169	Screw			
21	9761958	Block, Terminal	46	9755769	Tray, Hidden Bake Element			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DRAWER & BROILER PARTS

For Models: GR773LXSQ1, GR773LXSS1, GR773LXSB1  
(White) (Stainless Steel) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DRAWER & BROILER PARTS


For Models: GR773LXSQ1, GR773LXSS1, GR773LXSB1  
 (White) (Stainless Steel) (Black)

Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (2)
2	3195996	Grill, Broiler
3	3196076	Pan, Broiler
4	8272610	Drawer, Warming
5	8272609	Panel, Inner
6		Rivet, Push (2)
	3196814	White
	3196813	Black
7		Panel, Drawer Frnt
	W10010930	White
	W10010950	Black
	W10010870	Stainless Steel
8	3181534	Rack, Roasting
9	3196168	Screw
10	8272977	Heat Shield, Element
11	9758520	Element, Warming
12	8274153	Enclosure, Drawer
13	8274149	Sensor
14	3196427	Screw
15		Slide, Drawer
	9761929	Left Hand
	9761930	Right Hand
16	3196174	Screw
17	3196178	Screw
18	8274021	Rack, Partial
19	8274022	Rack, Insert
21	W10010870	Panel, Drawer SS
22		Handle
	9761978	White
	9761979	Black
	9761981	Stainless Steel
23	8524234	Insulation
24	W10010830	Brkt - Handle
25	W10031780	Screw
26	W10022210	Trim, Drawer SS Model Only
27	9781235	Speed Clip SS Model Only
28	W10031790	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Models: GR773LXSQ1, GR773LXSS1, GR773LXSB1  
(White) (Stainless Steel) (Black)



Illus. No.	Part No.	DESCRIPTION
1	9761975	Trim, Top White
	9761977	Stainless Model
	9762391	Black
2	3196164	Screw
	3	Handle, Door
4	9761978	White
	9761979	Black
	9761981	Stainless Steel
	9761344	Liner, Door
5	8522414	Seal, Window
6	9758162	Glass, Inner (2)
7	3186289	Frame, Glass
8	8272618	Insulation, Door

Illus. No.	Part No.	DESCRIPTION
9	9761357	Retainer, Insul.
10	9761496	Hinge, Door (2)
	11	Glass, Outer
12	W10010660	White
	W10010690	Stainless Steel
	W10010680	Black
13	8523166	White Left Hand
	8523172	White Right Hand
	8523171	Black Left Hand
	8523165	Black Right Hand
	9762249	Unvrsl Slvr LH
	9762250	Unvrsl Slvr RH

Illus. No.	Part No.	DESCRIPTION
13	3196160	Screw
	14	Trim, Lower
15	8523175	White
	8523177	Black
15	3196025	Clip, Glass (4)
16	W10031790	Screw
17	W10031780	Screw
19	9761517	Clip, Dr Mntg (2)
20	3196165	Screw
22	3196794	Bracket, Window(2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS

For Models: GR773LXSQ1, GR773LXSS1, GR773LXSB1  
(White) (Stainless Steel) (Black)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Following Parts Not Illustrated

**SPLICING WIRES--25FT.**

**LENGTH**

- 242828 Wire, Black  
12 Ga. 150° c
- 242821 Wire, Blue  
14 Ga. 150°c
- 242822 Wire, Brown  
14 Ga. 150°c
- 242830 Wire, Brown  
14 Ga. 200°c
- 242823 Wire, Green  
14 Ga. 150°c
- 242824 Wire, Orange  
14 Ga. 150°c
- 242825 Wire, Red  
14 Ga. 150°c
- 242831 Wire, Red  
14 Ga. 200°c
- 242827 Wire, Yellow  
14 Ga. 150°c

**REFINISHING MATERIAL**

- 799832 Kit, Porcelain  
Repair (White)
- 242756 Touch-Up  
Self-Clean(1/2 Pt)
- 261582 Grease

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**INSULATION**

- 261514 Insulation,  
Fiberglass (1-1/2"  
x 24" x 120")
- 240132 Insulation,  
Fiberglass (2-1/2"  
x 22" x 120")

**PAINT, TOUCH-UP (1/2oz.)**

- 72017 White
- 4392899 Biscuit
- 511873 White Porcelain  
(2 Oz.)

**PAINT, PRESSURIZED SPRAY  
(12 oz.)**

- 350930 White
- 4392901 Biscuit
- 285006 Superior Black
- 206922 Primer (White)

**PAINT, BULK (1 qt.)**

- 799344 White (Uncut)
- 4392900 Biscuit (Uncut)

**ACCESSORY PARTS**

- 241430 Foil, Aluminum  
Oven (18" x 25')
- 3184478 Cleaner, Glass

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**ANTI-TIP KIT**

- W10017440 Anti-Tip Kit

**WIRING HARNESS PARTS**

Following Parts Not Illustrated

- 9762815 Harness, Wire  
(Cooktop Left)
- W10044070 Harness, Wire  
(Cooktop Right)
- 9762964 Harness, Wire  
(Console)
- 8273908 Harness, Wire  
(Warming Element)
- 9759000 Harness, Wire  
(Main)
- 9758192 Harness, Wire  
(Sensor/Dr Switch)
- 9756550 Harness, Bake  
Element (Hidden)
- 8523279 Wire, Ground
- 3196154 Screw