Operating Instructions For Item 93983 Non-Contact Pocket Thermometer

Thank you for purchasing our non-contact infrared thermometer. Please remember to keep away from children and don't use it for safety related applications. NOT FOR MEDICAL OR FOOD SAFETY USE.

Specifications:

- ☑ Temperature measurement range: -33 to +110°C (-27~230°F)
- ☑ Operating temperature range: -10 to +50°C (14 to +122°F)
- Resolution: 0.1°C /°F (for thermometer); 0.01sec (for Stopwatch)
- Accuracy (Tamb=23±3°C): +/-2% of reading or +/-2°C(4°F)
- Field of View: 1:1
- Emissivity: 0.95 fixed
- Auto real time clock and Room temperature while power off
- ☑ °C / °F Switch, MIN/MAX/LOCK, Stop Watch function
- Battery Life: 40 hours continuous use (auto power off after 15seconds), The battery life is approximately 6 months.
- Battery: one CR2032 lithium cell battery

Real time clock setting

- 1 Power on: Press the "Meas. key".
- 2 Press the "Mode key" six times and the "Set" icon starts to flash, which indicates the setting screen.
- 3 Press the "Meas. key" to make the "24" icon flash, which indicates the 12/24-hour setting screen. Press the "Meas. key" again to set 12/24-hour Format from 24-hour to 12-hour.
- 4 Press the "Mode key" to move the flashing in the sequence shown below to select other settings. Hour \rightarrow Minutes
- 5 While the hour, minutes setting is flashing, use "Meas. key" to change it. Press "Mode key" when complete.

Use of the thermometer

- 1 Always make sure the probe is clean without any damage.
- 2 Power on: Press the "Meas. key".
- 3 Temperature taking: When you press the "Meas. key", you will get the temperature immediately. If you hold down the "Meas. key", the reading of measurement will be continuously updated.

Note: The Distance:Spot is 1:1. Please make sure the target area is within the field of view. Note: Applications include the Water, Milk, Cloth, Skin, or visit <u>Http://www.ZyTemp.com</u> for further


information.

4 Power off: Device will automatically power off if left idle for more than 15sec to extend battery life.

Use of the Stop Watch

- 1 Power on: Press the "Meas. key".
- 2 Press the "Mode key" four times and the "count" icon starts to flash.
- 3 For start or stop counting, press the "Meas. key". For reset counting, press the "Mode key".
- 4 Press "Mode key" to enter the thermometer function.

CENTECH A new way to measure temperature "3491 Mission Oaks Blvd., Camarillo, CA 93011 Visit our Web site at: <u>http://www.harborfreight.com</u>



238"

C

18:40 🛤

25

00:00 ₀

ΠΠ

Other Functions

continuously updated.

→ Power on and press the "Mode key" once for the Minimum (MIN) or twice for Maximum (MAX) modes. When the MIN or MAX icon flashes, press the "Meas. key" to confirm. Hold down the "Meas. key", the minimum or maximum reading of measurement will be

 \rightarrow Power on and press the "Mode key" three times. When the LOCK

icon flashes, press the "Meas. key" to confirm. This mode is

particularly useful for continuous monitoring of temperatures for up to



[™] 25. **1**°°

^{™ 24} 15:42

75.21

→ Power on and press the "Mode key" five times. When the °C icon flashes, press the "Meas. key" to change the scale to °F. The setting will be reserved even if power off.

60 minutes or until the "Meas, key" is pressed.

Battery replacement



LOCK

Battery is low and no more measurements are possible. The battery should be replaced immediately with a CR2032 lithium cell. The battery is

located under the twist cover at the rear of thermometer. Please remember to power off the unit before replacing the battery.

 \triangle A malfunction may occur if the power is on when the battery is replaced. If a malfunction occurs, restart the device. Keep the battery away from children.

Important notes

Storage & Cleaning: The sensor lens should be kept clean at all times and stored at room temperature.

1. Use only a soft cloth or cotton swab with water or medical alcohol when cleaning the lens. 2. Remember to allow the lens to fully dry before using.

3. The thermometer should be stored at –20 to +65 $^{\circ}\text{C}$ (-4 to 149 $^{\circ}\text{F}).$

EMC/RFI: Readings may be affected if the unit is operated within radio frequency electromagnetic field strength of approximately 3 volts per meter, but the performance of the instrument will not be permanently affected.

Troubleshooting



'Hi' or 'Lo' is displayed when the temperature being measured is outside of the range of the instrument, 'Hi' when higher than +110°C (230°F) and 'Lo' when lower than -33 °C (-27°F). \square Please select target within specifications. If a malfunction still exists, please contact the nearest retailer.



'Er2' is displayed when the thermometer is exposed to rapid changes in the ambient temperature. 'Er3' is displayed when the ambient temperature exceeds $-10 \text{ }^{\circ}\text{C}$ (14°F) or 50°C (122°F). \square The thermometer should be allowed plenty of time (minimum 30 minutes) to stabilize to the working/room temperature.



☑ For all other error messages it is necessary to reset the thermometer. To reset the thermometer, wait for the instrument power off, remove the battery and wait for a minimum of one minute, reinsert the battery and turn on. If the error message remains please contact a qualified service technician.

[™] 18:27 2 38 2 ↔ [™] 18:28

Min:Sec = 00:3.36

(resolution=0.01sec)



00:03 ₀

35

∕∧Œ

Sensor lens

LCD

Meas. key

6:40

25

Mode key