

lenovo

IdeaPad Tablet

A1-07

User Guide v1.1



Please read the
safety precautions and important notes
in the supplied manual before use.



Contents

Chapter 01

Overview of IdeaPad Tablet A1-07

- 1-1 Appearance Description
- 1-2 Buttons Description
- 1-3 Powering IdeaPad Tablet A1-07 On/Off
- 1-4 Turning Screen Backlight On/Off
- 1-5 Screen Lock/Unlock
- 1-6 Navigation Tips
- 1-7 4-Pane Desktop
- 1-8 Home Screen
- 1-9 Switching Home Screen
- 1-10 Status Bar
- 1-11 Recent Apps
- 1-12 Applications Management
- 1-13 Entering Text

Chapter 02

Connecting to the Internet

- 2-1 Browser
- 2-2 Lenovo App Shop

Chapter 03

Applications


- 3-1 Calculator
- 3-2 Calendar
- 3-3 Camera

- 3-4 Clock
- 3-5 Contacts
- 3-6 Email
- 3-7 ES File Explore
- 3-8 Gallery
- 3-9 Music

Chapter 04

Settings

- 4-1 Wireless & Networks
- 4-2 Sound Settings
- 4-3 Display Settings
- 4-4 Location & Security
- 4-5 Applications
- 4-6 Accounts & Sync
- 4-7 Privacy
- 4-8 Storage
- 4-9 Language & Keyboard
- 4-10 Backup
- 4-11 Date & Time
- 4-12 About Tablet



Chapter 01

Overview of IdeaPad Tablet A1-07

*Specific models only

- 1-1 Appearance Description
- 1-2 Buttons Description
- 1-3 Powering IdeaPad Tablet A1-07 On/Off
- 1-4 Turning Screen Backlight On/Off
- 1-5 Screen Lock/Unlock
- 1-6 Navigation Tips
- 1-7 4-Pane Desktop
- 1-8 Home Screen
- 1-9 Switching Home Screen
- 1-10 Status Bar
- 1-11 Recent Apps
- 1-12 Applications Management
- 1-13 Entering Text

1-1 Appearance Description

The picture is for reference purposes only, and may differ from the actual item, which is the standard.

1-2 Buttons Description

Power Button

- While in the shutdown mode, press and hold this button

- (for about 2-3 sec) to power on your IdeaPad Tablet A1-07.
- After your IdeaPad Tablet A1-07 is powered on, press this button to turn off the illuminated screen display. While the screen display is off, press this button again to re-illuminate the screen.
 - After your IdeaPad Tablet A1-07 is powered on, press and hold this button (for about 2-3 sec) to bring up IdeaPad Tablet A1-07 "Tablet options" pop-up box; select "Power off" and press "OK" to shut down IdeaPad Tablet A1-07.
 - After your IdeaPad Tablet A1-07 is powered on, press and hold this button (for about 6 sec) to forced shutdown.

Volume Button

- Adjusts the volume.

Screen Rotation Lock Button

- Toggle the button DOWN to lock the screen orientation, not allowing screen rotation.
- Toggle the button UP to unlock the screen orientation, allowing screen rotation.

*SIM card socket

- The SIM card slot is located on the lower left of the device frame. In the Power off mode, insert the end of a sharp-pointed object into the small hole above the socket until the stopper pin pops out, and then insert the SIM card. To remove the SIM card, in the Power off mode, push the SIM card into the slot until it clicks, then pull it out.

1-3 Powering IdeaPad Tablet A1-07 On/Off

Powering IdeaPad Tablet A1-07 On

Press and hold the "Power" button on the upper right of IdeaPad Tablet A1-07, and the Lenovo and startup screens display in sequence, indicating that IdeaPad Tablet A1-07 has been powered on.

Powering IdeaPad Tablet A1-07 Off

Press and hold the "Power" button on the upper right of IdeaPad Tablet A1-07 until "Tablet options" displays on the screen, select

"Power off " and touch "OK" to power off your IdeaPad Tablet A1-07.

*For the 3G-enabled version, be sure to insert or remove the SIM card in the Power off mode. Doing so when the device is on may damage the SIM card.

1-4 Turning Screen Backlight On/Off

Turning Screen Backlight On

In the standby mode, you can tap the "Power" button on the upper right of the IdeaPad Tablet A1-07 to "wake" the screen up. The device's screen will then light up, indicating that the backlight has been turned on.


Turning Screen Backlight Off


If your IdeaPad Tablet A1-07 is powered on and you do not use it temporarily, you can tap the "Power" button on its upper right to turn off the screen backlight. Your IdeaPad Tablet A1-07 will enter the standby mode to save power.

1-5 Screen Lock/Unlock

Lock Screen

Auto Lock

You can set Screen timeout in <Display> under " Settings". If there is no operation within the preset standby time, then the screen backlight will automatically turn off, and the device will be locked.




Manual Lock

If your IdeaPad Tablet A1-07 is powered on and you do not use it temporarily, you can tap the "Power" button on its upper right to dim the screen display down. The device will then enter the standby mode and become locked.

How to Unlock





Once in the standby mode, tap the "Power" button on the upper right of IdeaPad Tablet A1-07 to brighten the screen display back up to normal level. You can also touch and slide the lock icon to the right, following the on-screen instructions to unlock the screen, as shown in the figure below:





Screen Lock Pattern Settings

You can touch "Set up screen lock" in <Location & security> under "Settings" to set the screen lock pattern. After this function has been enabled, you need to draw your unlock pattern in order to unlock the screen before you can use your device.

1-6 Navigation Tips

- **Lenovo App Shop** : Enter the Lenovo App Shop.
- **Function menu** : Display apps function menu.
- **Applications** : Display all tablet's apps.
- **Home** : Back to the home screen or press the button for 2 sec to display recent apps.

- **Back** : Back to the previous screen.
- **Browser** : Browse the Internet.



- | | |
|---------------------|-------------|
| 1 - Lenovo App Shop | 4 - Home |
| 2 - Function menu | 5 - Back |
| 3 - Applications | 6 - Browser |

1-7 4-Pane Desktop





1-8 Home Screen

This desktop enables you to quickly view and open your most frequently used applications.

In the home screen, you can add widgets or shortcuts, and change your wallpaper as well.

- Touch a blank space for about 2 seconds. "Add to Home screen" pops out, and you can add widgets and shortcuts, and change wallpaper as well. Your desired widgets, shortcuts and other items can be added to the home screen.



- To delete something on the home screen, touch and hold the desired gadget until a Trash Bin icon displays at the bottom of the screen, then drag and drop the gadget icon onto the  Trash Bin icon.

1-9 Switching Home Screen


Your IdeaPad Tablet A1-07 has multiple desktops.


You can slide the screen with your finger to switch the display and move icons among home screens.

1-10 Status Bar

The system message(s), if any, will be displayed on the IdeaPad Tablet A1-07.


You can get the information about Wi-Fi connection status, Signal level, Power level, Charging status and other detailed notifications about your tablet.


Touch the Status bar at the top of the screen and drag it down, the Notification Panel is displayed. Press  button to open detailed settings for Wireless & networks, Sound, Display, Location & security, Applications, etc.




1-11 Recent Apps

Your tablet remembers the apps you used recently.

Touch  for about 2 seconds to open a list of applications you have used recently. Touch an application to open it.



1-12 Applications Management

Tap  on the home screen to open the applications list.

You can enter **Manage applications** in **Applications** under "

 **Settings**".

Uninstall

Tap "Downloaded", the app you desired, then press the **Uninstall** button on the top to uninstall the app.

Stop/change setting

Tap "All" or "Running", the app you desired, then the option you want.

Install

Tap "Lenovo App Shop" in applications list. For details, please refer to "Lenovo App Shop" on "Chapter 2".

Select the appropriate applications to download.

1-13 Entering Text

When using your IdeaPad Tablet A1-07, you can enter text from the virtual keyboard directly onto the touch screen, such as when adding contact information into Contacts or typing and editing SMS messages. You can also directly input Chinese characters, English letters and digit symbols onto the touch screen.




Switch Input Method Editor


Press and hold the input box to display the soft keyboard.

System keyboard




Toggle between letters/numbers

- Touch  /  to toggle between letters and numbers. Touch  to see more special characters.

- Touch , the indicator displays, and you can enter capital letters.

Input options

- Touch  on the keyboard to open **Input languages** menu. You can select Input languages or **Switch Layouts** on this menu.

Voice input

- Touch  on the keyboard to open voice input.

*Specific models only

Chapter 02

Connecting to the Internet

*Specific models only


2-1 **Browser**

2-2 **Lenovo App Shop**

2-1 Browser

Network support is required for accessing the Internet with the web browser. If there are any problems with your network support, please consult your network operator or service provider directly.


The web browser in your IdeaPad Tablet A1-07 can access the Internet via the Wi-Fi network for business and personal use.

Touch " Browser" in the applications list to open the browser.

The browser supports the following functions:

Input web address

Touch the input text box, and input the web address with

the popup soft keyboard. Then touch  on the soft keyboard to open the web page.

Exit

Touch "" on the bottom bar to quit the browser.

Bookmarks

You can save bookmarks to your favorite web pages and

navigate to them in seconds. It contains 3 tabs:

Bookmarks:

Displays a list of the web addresses that you have added. You can also add a bookmark. Press and hold web icons to open the popup window for editing links. You can open, edit, copy, share, delete the selected website, create shortcuts, set as home page and do other operations.

Most visited:

Displays a list of web addresses that you have browsed most recently.

History:

Displays a list of the web addresses that you have browsed recently.

New Window/Window

This function is mainly used to open a new web page window, or to toggle among several previously opened windows.

Additional Functions


Touch  to display more functions.

Refresh: Touch  to manually refresh the web page.

Forward: Touch  to go to the next page.

Bookmarks: Touch  to manage your bookmarks.


Touch  to bookmark a current page.

More: Touch  to display an option list. These options include Add bookmark, Find on page, Select text, Page info, Share page, Downloads and Settings.

Zoom Pages In/Out: You can automatically fit the page to the screen size, and zoom the page in/out by enlarging/reducing the distance between your two fingers while touching the screen.

Back: Touch  to previous page.



Within the applications list, touch "  Lenovo App Shop" to open the Lenovo App Shop interface. NOTE: Network support is required before you can use this application. If there is any problem with your network support, please consult your network operator or service provider.

After entering the <New> page, you can toggle among the upper tabs <All Categories>, <New>, <Bestsellers>, <Recommended> and <All>, <Free> for various content.

If you want to download applications for your IdeaPad Tablet A1-07, you must first register for a Lenovo account. Once you have registered for a Lenovo account, you can use it to log in and download the free applications of your choice onto your IdeaPad Tablet A1-07.

All Categories

Click "All Categories" tab on top of the <Lenovo App Shop> page to enter <Lenovo App Shop> category list.

New

Click to display the latest software applications.

Bestsellers

Click to display the most popular applications.

Recommended

Click to display the recommended applications.

All

Click to display all applications.

Free

Click to display the free applications.


*Specific models only

Chapter 03 Applications


*Specific models only

- 3-1 Calculator
- 3-2 Calendar
- 3-3 Camera
- 3-4 Clock
- 3-5 Contacts
- 3-6 Email
- 3-7 ES File Explore
- 3-8 Gallery
- 3-9 Music

3-1 Calculator

Touch " Calculator" in the applications list to enter the calculator application.


3-2 Calendar

Touch " Calendar" in the applications list to open the calendar page.

New Calendar Item

You can create a new event by touching and holding a time.

Manage Calendar Events


You can switch among the Day view, Week view and Month View by tapping  function menu.

Day view: Touch and hold an event in the day view to create, view, edit or delete that event.

Week view: Touch and hold an event in the week view to create, view, edit or delete that event.

Month view: Touch any date in the month view to enter Day view, then you can manage events in day view.

NOTE: Within any "Calendar" view, you can quickly return to the current day or the current week and month simply by



tapping the , and select "  Today" button on the function menu from any other day, week or month view.

3-3 Camera




Touch " Camera" in the applications list to open the photo taking and video recording preview interface. The found view will display on the screen. From this display, you can perform the following operations:

Switch Cameras


Your pad provides you with two cameras. On cameras interface, tap , function menu appears, and select  switch camera between front and back.


Photos


Taking Photos


In the photo taking preview interface, touch  on the screen to take snapshots.

 Video Recorder: Switches to the video recording mode.

 Exposure, Picture size, Picture quality, Color effect and Camera settings.

 Store location

 White balance



Viewing Photos



In the photo taking preview interface, in the vertical mode, touch Photo Preview on lower right to open the photo preview interface. Here, you can set and play photo slideshows.


Photo Saving Location

Any photos you have taken will be saved in the "Gallery" application. In the applications list, touch "Gallery" to open the list of all the photos you have taken.

Videos

Video Recording

In the video recording preview interface, touch  on the screen to start recording, or touch  to stop recording.

 Camera: Switches to the photo taking mode.

 Color effect, Camera settings

 White balance

Video quality

High (30m)

Low (30m)

MMS (Low, 30s)

YouTube (High, 10m)

High Video quality

Select camera

Back



Front

Select camera


Viewing Videos

In the vertical mode, a thumbnail image of the last previously recorded video will be displayed in the lower right corner of the video recording preview interface. Touch the thumbnail to open the video play interface.

Video Saving Location

Any videos you have recorded will automatically be saved in the " Gallery" application. Touch " Gallery" in the applications list to start the application. You can view the recorded videos in <Gallery>.


3-4 Clock

Touch " Clock" in the applications list to open the Clock view.


To add an alarm, touch  then touch "Add alarm".

When an alarm sounds, touch **Dismiss** to turn it off or **Snooze** to delay for ten minutes.



3-5 Contacts

Touch " Contacts" in the applications list.

Add contact

Within the "Contacts" main page, touch , select the <New contact> on the function menu, and then input the relevant information for that contact. Tap the <Done> button when you have finished.


Edit contact

Within the "Contacts" details page, touch , select the  on the function menu to enter the editing mode, then edit your contacts.


3-6 Email

Network support is required for using your IdeaPad Tablet


A1-07's mailbox. If there are any problems with your network support, please consult your network operator or service provider directly.

Touch " Email" in the application list.



3-7 ES File Explore

Touch " ES File Explore " in the applications list to bring up the file management application, which enables you to browse and manage any and all of the files stored locally on your Pad.



Root




Tap the  button in the upper left corner of the page to quickly return to the root directory for local storage.


New

Tap , select " New" to create a new file or folder and search engine. You can also edit the name of a folder or file. After you touch "OK", the system should inform you that the file has been created successfully.





Operations

Tap , select " Operation" to paste, cut, copy, rename, delete etc.,.

- Copy/Paste: Within the file list, tap , select one or more files, then touch "Copy" under "Operation". Select the location where you want to paste, then touch "Paste".
- Delete: Within the file list, tap , select one or more files, then touch "Delete" under "Operation" to delete the file(s).
- Rename: Within the file list, tap , select one file, then touch "Rename" under "Operation" to rename the file.

For more details, tap , and refer to ES File Explore help instruction.

3-8 Gallery

Touch " Gallery" to start the <Gallery> application. In the picture application homepage, you can slide  in the upper right corner of the screen after touching the album to select display modes:  album or  photo.

On Gallery Page

Gallery and Camera: You can select Gallery or Camera.




Gallery: Switch to Gallery.



Camera: Switch to Camera.



Details: Touch  to select  on the function menu,

then touch  to show detailed information about a selected file.

On Picture List Page

Select a photo, then touch the  button to enter slideshow mode.

3-9 Music



Touch " Music" in the application list to start the music application, then select what you want to play. You can copy music from your computer using the USB cable supplied.

Touch the button on the top of the music page to sort your music files by Artists, Albums, Songs or Playlists.

Music Player Controls

You can press the side volume button of your Pad to adjust volume.



Play/Pause



Previous/Next





Playlists



Shuffle



Repeat


On music player page, touch  can back to home page, then enter other applications, but your music continues to play. To turn off/change music, touch the status bar at the top of the screen, drag it down, then select .

**Specific models only*

Chapter 04 Settings

*Specific models only

- 4-1 Wireless & Networks
- 4-2 Sound Settings
- 4-3 Display Settings
- 4-4 Location & Security
- 4-5 Applications
- 4-6 Accounts & Sync
- 4-7 Privacy
- 4-8 Storage
- 4-9 Language & Keyboard
- 4-10 Backup
- 4-11 Date & Time
- 4-12 About Tablet

Within the applications list, touch " Settings" to enter the Settings interface.

4-1 Wireless & Networks

This setting module includes: Airplane mode, Wi-Fi, Wi-Fi settings, Bluetooth, Bluetooth settings, Tethering & portable hotspot, VPN settings and 3G Mobile Networks (Specific models only).

Airplane Mode


Once the Airplane Mode has been enabled, all of the wireless connections on your IdeaPad Tablet A1-07 will be disabled immediately.


Wi-Fi/Wi-Fi Settings



You can enable/disable Wi-Fi function.



Once the Wi-Fi has been enabled, your IdeaPad Tablet A1-07 will automatically scan for available wireless networks, display them in the Wi-Fi network list.

There is an icon indicating the network status following every

LAN, where  indicates that the network requires no

password, and can be connected directly, and  indicates that the network has been encrypted, and can be connected only after the required password is input.

Touch a desired network from the list to connect. Touch , then select " Advance " to set static IP setting. You can also select <Add Wi-Fi Network> to manually add a network.

- **Wi-Fi:** Wi-Fi function switch.
- **Network notification:** After the switch is turned on, the system will notify the users if there are any open networks.
- **Wi-Fi sleep policy:** Touch  and select "Wi-Fi sleep policy" on the " Advance": **sleep when screen turns off (uses more mobile data), Never when plugged in or Never(uses more battery power).**

Bluetooth/Bluetooth Settings

You can establish a wireless connection with any other Bluetooth compatible devices using Bluetooth technology. Examples of such Bluetooth compatible devices may include stereo earphones, keyboards, etc.

Since a Bluetooth-enabled device communicates with other devices by radio waves, you do not have to pose your IdeaPad Tablet A1-07 to be directly opposite the other device. You simply need to ensure that the maximum distance between the two devices does not exceed 10 m (about 32 feet). However, please note that the Bluetooth connection can sometimes be interfered with by barriers such as walls or other electronic devices.

Your IdeaPad Tablet A1-07 supports V2.0 Bluetooth specification. To ensure the interactive operation between

your IdeaPad Tablet A1-07 and another Bluetooth-enabled device, please use only Lenovo-approved accessories applicable to your IdeaPad Tablet A1-07 model. Or, check with the manufacturer of the other device to determine whether the device is compatible with your IdeaPad Tablet A1-07.

In some cases, the use of Bluetooth may be restricted. For the related information, please consult with your local authorities or service provider.

Using functions requiring Bluetooth technology or running these functions in the background will consume the battery power of your IdeaPad Tablet A1-07 at a faster than average rate, also reduce the service life of your battery. You can perform the following operations in the Bluetooth Settings:

- Bluetooth devices: After Bluetooth has been turned on, your IdeaPad Tablet A1-07 will automatically display a list of any Bluetooth-enabled devices which can be found in the nearby area (i.e. scan devices).

Tethering & Portable Hotspot

You can share your tablet's mobile data connection via USB or as a portable Wi-Fi hotspot.

VPN Settings

These settings allow you to add and set up various types of VPN (Virtual Private Network).

3G Mobile Networks (Specific models only)

You can enable/disable 3G Mobile Networks function. If there are any problems with your network support, please consult your network operator or service provider.

4-2 Sound Settings

Touch this option to enter the "Sound Settings" interface. The setting includes **General (Silent mode, Vibrate, Volume)**, **Notifications (Notifications ringtone)** and **Feedback (Audible touch tones, Audible selection, Screen lock sounds and Haptic feedback)**.

4-3 Display Settings

The display setting options include: Brightness, Auto-rotate screen, Animation and Screen timeout.

Brightness

You can manually adjust the brightness, or select "Automatic brightness", which allows your IdeaPad Tablet A1-07 to adjust the screen brightness automatically according to the current ambient light.

Auto-rotate screen

You can select whether to allow screen horizontal or vertical auto-rotation.

Animation

Once the animation switch has been turned on, your IdeaPad Tablet A1-07 will display animations whenever application windows are opened or closed, thereby enhancing the attractiveness of your experience.

Screen timeout

This option allows you to select how long your IdeaPad Tablet A1-07's screen will remain lit without any activity before it automatically locks the screen to save power. You can set the time period to 15 seconds, 30 seconds, 1 minute, 2 minutes, 10 minutes, 30 minutes and never.

4-4 Location & Security

Within the settings, you will gain access to the following functions:

My Location, Screen Unlock, SIM card lock (Specific models only), Passwords, Device administration and Credential storage.

My Location

You can select whether to use wireless networks or GPS satellites.

Notice on using the GPS feature

- Many factors can interfere with GPS satellite reception. In places with strong interference (such as indoors, in a car, or between buildings) or during bad


weather it is possible that you may either fail to get a signal or find that a longer positioning time will be necessary.

- For your safety, please do not watch or operate the monitor while driving.
- Navdroyd is free navigation software that will enable you to better experience this product's GPS functionality. Please ensure you connect to Wi-Fi download the map by Navdroyd before using the GPS. Be aware that this version is function-limited to maps of only one country or region. Before downloading the maps of another country or region it will be necessary to manually delete the previous set of maps.
- Using a Wi-Fi connection, check for updates online at least once a week to enhance your GPS experience.

Screen Unlock

Using the option, you will be able to unlock the screen in the three ways: Pattern Unlock, PIN Unlock and Password Unlock. You can cancel the screen lock here as well.

Touch <Pattern> and then draw the unlock pattern of your choice (as demonstrated) on the screen with your finger. Once you have set the unlock pattern, you will then be able to turn <Use Visible Pattern> on/off.



Once you have set and activated the Pattern Unlock function, then the Unlock keyboard will be displayed on the screen whenever the screen is unlocked by the slide. Draw your pre-selected pattern on the screen with your finger using the Unlock keyboard. After the preset pattern has been correctly drawn, the screen will become unlocked.

Touch <PIN>. You will need to input at least 4 numbers as the PIN code to unlock the screen.

Touch <Password>. You will need to input at least 4 characters as the password to unlock the screen.

SIM Card Lock Setting (Specific models only)

Passwords

With the <Visible passwords> option, you can decide whether or not your chosen password will be visible as you input it. If the checkbox is checked, then the password will be visible. If it is unchecked, then your password will only be displayed as **** as you input it, thereby making your password more secure.

Device administration

These functions are not available to ordinary users. Only TsingMail users who have previously set up the appropriate security policies within their companies can use these functions.

These features work in conjunction with the Enterprise Policy Center, (Lenovo Enterprise Policy Manager). The Enterprise Policy Center is the executor of the security policy of the Lenovo enterprise platform. Whenever the user enables the Lenovo enterprise mail and service function, the Enterprise policy center will then be enabled automatically. This will allow your IdeaPad Tablet A1-07 to accept the security policy as set forth by the IT department of your company, for example, mandatory screen-savers with increased password strength. Enabling these functions also allows your IdeaPad Tablet A1-07 to accept management instructions from your company's IT department, for example, allowing them to erase data remotely and reset your device.

Credential Storage

This function allows your IdeaPad Tablet A1-07 to access web pages and LANs for which a specific security certificate or other certificate is required. After having set the credential storage password, you can access the web pages or LANs with the appropriate security certificates and other certificates you have stored.

- **Use secure credentials:** This option will be unavailable until the credential storage password has been set.
- **Install from SD card :** You can install certificates from SD card.
- **Set password:** Touch this option to set the credential storage password. After it has been set successfully, the "Use secure credentials " checkbox will be checked, indicating that this option is now available.
- **Clear storage:** Select this option to delete all your currently saved certificates and reset the credential storage password.

4-5 Applications

With these settings include: Unknown sources, Manage applications, Running services, Storage use, Battery use, Development (NOTE: This last function is available for developers only.)

Manage Applications

With this option, you can easily manage and delete applications of your choice.

With the <All> menu, you can filter any running applications or applications provided by the third-party software developer in the applications list.

After selecting an application, you will then be able to see its related information details, and also be able to perform operations such as Uninstall , Clear cache and Clear defaults.

Running Services

With this option, you can end and set some running applications.

Storage Use

With this option, you can view storage used by applications.

Battery Use

With this option, you can see how much the battery has been used.

Unknown Sources

This option allows installation of non-Market applications.

Development

This option is only available for developers. With it, you can set some of the development options available for that application.

- USB debugging: Uses the debugging mode after connecting to USB. You can toggle between on and off.
- Stay awake: The screen will not sleep when the battery is charged. You can toggle between on and

- off.
- Allow mock locations: You can toggle between on and off.

4-6 Accounts & Sync

With the option, you will be able to do general sync settings and manage accounts.

General sync settings enables you to select Background data and Auto-sync.

Via account management settings, you can add accounts, or use existing account. You can log in by using an existing account to view relevant information under your account, and to use some advanced functions and applications of this device.

4-7 Privacy

This option enables you to reset to the factory data.

4-8 Storage

This option enables you to see SD card and internal storage.

4-9 Language & Keyboard

Language Settings

You can select the language you wish to use to operate your IdeaPad Tablet A1-07.

Keyboard Settings

You can select input method and set Keyboard in this setting.

4-10 Backup

This option enables you to back up and restore some data.

4-11 Date & Time

With these settings, you can set a series of time-related options such as the system time.

Date & Time Settings

You can enable the auto time update via network, select the time zone, set the specific date and time, and set the display format of date and time.

4-12 About Tablet

Within this option, you can view System updates, Status, Battery use, Legal information, Model number, Android version, Kernel version and Build number.

**Specific models only*