

ITEM
95159

CENTRAL
PNEUMATIC®

4-PIECE AIR BLOW GUN SET

SPECIFICATIONS

**Air Blow Gun With Standard Nozzle and
Two Extensions**

**Die-cast Aluminum Frame Body; Steel Trigger Level;
Threaded Die-Cast Zinc Tips**

Air Inlet: 1/4" - 18 NPT

Air Discharge: 3/32" Diameter

Maximum PSI: 110 PSI

Overall Dimensions: 4-1/2" L X 5-1/2" H X 7/8" W

WARNING

1. Always wear ANSI-approved safety goggles when working with tools and equipment.
2. Keep out of the reach of children.
3. Store Air Blow Gun Set in a dry and secure location.
4. Do not exceed the maximum air pressure of 110 PSI.
5. Do not modify any part of the Air Blow Gun Set to perform any task for which they were not designed.
6. Never point the Air Blow Gun at peoples or animals.
7. Save these warnings.

OPERATING INSTRUCTIONS

1. Thread the nozzle or the needed extension onto the tip of the Air Blow Gun.
2. Attach the Air Blow Gun to the air source hose. Set the air compressor to 30 - 100 working PSI. Do NOT exceed 110 PSI.
3. Squeeze Air Blow Gun trigger to begin the flow of air.
4. Release Air Blow Gun trigger to stop the flow of air.
5. When finished, turn off the air compressor and then disconnect Air Blow Gun from the air source hose
6. Only use clean and dry compressed air. Never use oxygen, carbon dioxide, combustible gases or any other bottled gas as a power source.



For technical questions and replacement parts, please call Harbor
Freight Tools at 1-800-444-3353