



BCA-4560W/BCC4561B

3CA4560W/BCA4561B Parts and Price List

POS	Part Name	Qty(Pcs)	Part No.
1	Cabinet (BCA4560W)-WHITE	1	4560001
	Cabinet (BCA4561B)-BLACK	1	4561001
2	Door Assembly (BCA4560W)-WHITE	1	4560002
	Door Assembly (BCA4561B)-BLACK	1	4561002
3	Upper hinge	1	4560003
4	Upper hinge cover (BCA4560W)-WHITE	1	4560004
	Upper hinge cover (BCA4561B)-BLACK	1	4561004
5	Wire shelf	2	4560005
6	Crisper Glass cover	1	4560006
7	Crisper	1	4560007
8	Thermostat	1	4560008
9	Thermostat hook	1	4560009
10	Lamp switch	1	4560010
11	Thermostat box ASS'Y	1	4560011
12	Indication piece	1	4560012
13	Thermostat Knob	1	4560013
14	Lamp holder	1	4560014
15	Bulb	1	4560015
16	Lamp cover	1	4560016
17	Fix ring	1	4560017
18	Bottom Hinge	1	4560018
19	Adjustable Foot (BCA4560W)-WHITE	1	4560019
	Adjustable Foot (BCA4561B)-BLACK	1	4561019
20	Compressor plate	1	4560020
21	Compressor cushion	4	4560021
22	Power cord clipper	1	4560022
23	Power cord	1	4560023
24	Compressor Fixing plate	2	4560024
25	Compressor	1	4560025
26	Compressor PTC Starter	1	4560026
27	Compressor Overheat Protector ASS'Y	1	4560027
28	Junction box cover	1	4560028
29	Lock	1	4560029
30	Insulation Board holder	2	4560030
31	Insulation Board	1	4560031
32	Front foot (BCA4560W)-WHITE	1	4560032
	Front foot (BCA4561B)-BLACK	1	4561032