


# KitchenAid® COOKTOP PARTS

For Models: KERA205PWH4, KERA205PBL4, KERA205PBT4, KERA205PSS4

(White) (Black) (Biscuit) (Stainless Steel)

30" ELECTRIC CERAN  
FREE STANDING RANGE  
CONVECTION OVEN




Illus. No.	Part No.	DESCRIPTION
1	9758377	Literature Parts Installation Instructions
	9757142	Anti-Tip Template English/Spanish
	9757143	English/French
	W10017760	Owners Manual
	9758315	Tech Sheet
	9762761	Safer Cooking Tips
	9757645	Guide, Easy Set
2	3149191	Spring, Locator
3	3196170	Screw
4	9756979	Cooktop White
	9758348	Black
	9756980	Biscuit
	9756981	Stainless
5	8523739	Light, Indicator (Hot Surface)
6	8523741	Bracket, Ind Light
7	9757027	Element, Surface 2500/1000 W - LF
	8273994	1200 W - LR
	8273993	1800 W - RF
	9757031	1800/800 W - RR
	9757028	100 W - CR
9		Bracket, Element
	8272791	(2)
	8273720	(1)
10	3196169	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: KERA205PWH2, KERA205PBL2, KERA205PBT2, KERA205PSS2  
 (White) (Black) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1		Endcap
	9756959	White Left Hand
	9756958	White Right Hand
	9756961	Black Left Hand
	9756960	Black Right Hand
	9756963	Biscuit Left Hand
2	9756962	Biscuit Right Hand
		Membrane Switch
	9762104	White
	9762101	Black
3	9762102	Biscuit
	9762103	Stainless Steel
		Panel, Backguard
	9756730	White
	9756727	Black
	9756728	Biscuit
	9756729	Stainless Steel


Illus. No.	Part No.	DESCRIPTION
4		Switch, Infinite
	9757030	LF (Dual)
	3148953	RF/RR (Green)
	3148952	LR (Yellow)
5	8523266	Light, Indicator
6	3196068	Lens, Light (2)
7		Knob (4)
	9756941	White
	9756943	Black
	9756942	Biscuit
8	9756944	Cashmere Metallic
	9756934	Shield, Heat
9	9761078	Membrane Insert
10	9756999	Cover, Rear
	11	Switch, Simmer
	9758366WH	White
	9758366BL	Black
	9758366BT	Biscuit
	9758366CM	Cashmere Metallic

Illus. No.	Part No.	DESCRIPTION
12	9761590	Control, Range
13	4449809	Screw
15		Switch, Warming
	9757406WH	White
	9757406BL	Black
	9757406BT	Biscuit
	9757406CM	Cashmere Metallic
16	3400882	Screw
17	9758319	Cover, Rear (Console)
18		Cover, Vent
	9758352	White
	9758354	Black
	9758353	Biscuit
	9758355	Cashmere Metallic

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS

For Models: KERA205PWH2, KERA205PBL2, KERA205PBT2, KERA205PSS2  
(White) (Black) (Biscuit) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS


For Models: KERA205PWH2, KERA205PBL2, KERA205PBT2, KERA205PSS2  
(White) (Black) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9757972	Cover, Box	23	8273902	Sensor, Oven	46	3400016	Screw
2	8273905	Support, Corner LR	24	3195736	Support, Front (2)	47	3196566	Screw
3		Panel, Side (2)	25	3195987	Support, Corner RR	49	3196169	Screw
	8053830	White-Textured	26	3196548	Fuse, Thermal	50	9758925	Fan Motor, Convection
	8053832	Black-Textured	27	9758525	Element, Convection	51	4452226	Fan Blade
	8272519	Biscuit-Textured	28	3186116	Support, Oven (2)	52	4452227	Nut
4	9761013	Latch, Door	29	3186034	Bracket, Service	53	9755776	Cover, Convection Fan
5	3196961	Rod, Latch	30	9761958	Block, Terminal	54	9759689	Card, Insulator
6	9757241	Latch Asm, Rear		112432	Nut (3)	55	9757088	Baffle, Convection
7	3195737	Seal, Oven Flange	31	9757029	Back, Main	56	9756518	Transformer
8	9758518	Element, Broil	32	9755769	Tray, Hidden Bake Element	57	9761222	Appliance Manager
9	9755770	Element, Bake Hidden	33	9761498	Vent Tube Asm	58	9757970	Cover
10	8522416	Seal, Oven Door	34	3196701	Light Socket Assy	59	9757239	Rod - Dr Switch
11	9758701	Spacer, Door	35	311255	Bulb, Oven Light	60	9761301	Screen - Catalyst
12	9757262	Switch, Door	36	9755771	Cover, Tray	61	3196560	Screw(2)
14	3196037	Foot, Front (2)	38	3196165	Screw	62	8533930	Screw
15	9758224	Frame, Front	39	3196168	Screw	63	4449809	Screw
16	8054068	Tray, Insulation	40	3196178	Screw	<b>INSULATION</b>		
17	3196576	Clip, Panel (6)	41	3196174	Screw		8272616	Insulation, Wrap
18	9760314	Rail, Base (2)	42	3196179	Screw		9755772	Insulation, Back
19	9761935	Foot, Rear (2)	43	3196177	Screw		8272613	Insulation, Vent
20	3196091	Shield, Outer (2)	44	3196176	Screw		9757974	Insulation, GOC
21	3196092	Shield, Inner (2)	45	3196172	Screw			
22	8523803	Retainer, Side (2)						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Models: KERA205PWH2, KERA205PBL2, KERA205PBT2, KERA205PSS2  
(White) (Black) (Biscuit) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS


For Models: KERA205PWH2, KERA205PBL2, KERA205PBT2, KERA205PSS2  
 (White) (Black) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Trim, Door Top
	9756965	White
	9756967	Black
	9756966	Biscuit
	9756969	Cashmere Metallic
2	8534065	Screw
3		Handle, Door
	9758293	White
	9758294	Black
	9758295	Biscuit
	9782649	Stainless Steel
4	3186292	Liner, Door
5	8522414	Seal, Window
6	9758162	Glass, Inner (2)
7	3186289	Frame, Glass
8	8272618	Insulation, Door
9	3186297	Retainer, Insul.
10		Hinge, Door
	8053807	White, Black And Biscuit Models
	8272822	Stainless Model
11		Glass, Outer Door
	9762127	White
	9762129	Black
	9762128	Biscuit
	9756435	Stainless Steel
12		Trim, Side
	8523172	White Left Hand
	8523166	White Right Hand
	8523171	Black Left Hand
	8523165	Black Right Hand
	8523173	Biscuit Left Hand
	8523167	Biscuit Right Hand
	9758358	Cashmere Metallic, Left Hand
	9758357	Cashmere Metallic, Right Hand
	13	3196160
14		Trim, Lower
	8523175	White
	8523177	Black
	8523178	Biscuit
	8523180	Stainless Steel
15	3196025	Clip, Glass (4)
18	3196161	Screw
19	3196925	Clip, Door Stop
20	3196165	Screw
22	3196794	Bracket, Window(2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DRAWER & BROILER PARTS

For Models: KERA205PWH2, KERA205PBL2, KERA205PBT2, KERA205PSS2  
 (White) (Black) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (3)
2	3195996	Grill, Broiler
3	3196076	Pan, Broiler
4	8272605	Drawer, Storage
5	9758200	Bracket, Drawer(2)
6		Rivet, Push (2)
	3196814	White
	3196813	Black
	3196815	Biscuit

Illus. No.	Part No.	DESCRIPTION
7		Panel, Drawer Frnt
	9756325	White
	9756327	Black
	9756326	Biscuit
	9756328	Stainless Steel
8		Handle, Drawer
	9756952WH	White
	9756952BL	Black
	9756952BT	Biscuit
	9756952CM	Cashmere Metalic

Illus. No.	Part No.	DESCRIPTION
9	3181534	Rack, Roasting
10	3196168	Screw
11	8522669	Spacer, Glide
12	9756711	Heat Shield
13		Rail, Drawer
	8274190	Left Hand
	8274191	Right Hand
14	487939	Nut(2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS

For Models: KERA205PWH2, KERA205PBL2, KERA205PBT2, KERA205PSS2  
 (White) (Black) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Following Parts Not Illustrated

**SPLICING WIRES--25FT.**

**LENGTH**

- 242828 Wire, Black  
12 Ga. 150°c
- 242821 Wire, Blue  
14 Ga. 150°c
- 242822 Wire, Brown  
14 Ga. 150°c
- 242830 Wire, Brown  
14 Ga. 200°c
- 242823 Wire, Green  
14 Ga. 150°c
- 242824 Wire, Orange  
14 Ga. 150°c
- 242825 Wire, Red  
14 Ga. 150°c
- 242831 Wire, Red  
14 Ga. 200°c
- 242827 Wire, Yellow  
14 Ga. 150°c

**REFINISHING MATERIAL**

- 799832 Kit, Porcelain  
Repair (White)
- 242756 Touch-Up  
Self-Clean(1/2 Pt)
- 261582 Grease

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**INSULATION**

- 261514 Insulation,  
Fiberglass (1-1/2"  
x 24" x 120")
- 240132 Insulation,  
Fiberglass (2-1/2"  
x 24" x 120")
- 313660 Clip, Ground Wire  
x 22" x 120")

**PAINT, TOUCH-UP (1/2oz.)**

- 72017 White
- 4392899 Biscuit
- 511873 White Porcelain  
(2 Oz.)

**PAINT, PRESSURIZED SPRAY  
(12 oz.)**

- 350930 White
- 4392901 Biscuit
- 285006 Superior Black
- 206922 Primer (White)

**PAINT, BULK (1 qt.)**

- 799344 White (Uncut)
- 4392900 Biscuit (Uncut)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**ACCESSORY PARTS**

- 241430 Foil, Aluminum  
Oven (18" x 25')
- 4456147 Cleaner, Glass
- 2261590 Cleaner  
(Stainless Steel)

**ANTI-TIP KIT**

- 9757976 Anti-Tip Kit

**WIRING HARNESS PARTS**

- 9758191 Harness,  
(Sensor/Dr Switch)
- 9756707 Harness, Oven
- 9761466 Harness, Cooktop  
(Left w/Dual)
- 9761465 Harness, Cooktop  
(Right w/ wm)
- 9757315 Harness, Console
- 9756550 Harness, Bake  
Element (Hidden)
- 8524132 Shield, Wiring (2)
- 8523279 Wire, Ground
- 313660 Clip, Ground Wire
- 3196173 Screw
- 3196154 Screw, Ground

**Miscellaneous**

- 3196897 Pin Kit-Dr Removal