


COOKTOP, BURNER AND GRATE PARTS

For Models: KGCS166GBL0, KGCS166GWH0, KGCS166GAL0, KGCS166GBT0, KGCS166GSS0
(Black) (White) (Almond) (Biscuit) (Stainless Steel)

KitchenAid®

36" GAS COOKTOP



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP, BURNER AND GRATE PARTS


For Models: KGCS166GBL0, KGCS166GWH0, KGCS166GAL0, KGCS166GBT0, KGCS166GSS0

			(Black)	(White)	(Almond)	(Biscuit)	(Stainless Steel)	
Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Cooktop	7		Cap, (CR)	12		Knob, Control (4)
	3191256	White		3191732	White		3191923	White
	3191255	Black		3191731	Black		3191922	Black
	3191257	Almond		3191733	Biscuit		3191924	Almond
	3191295	Biscuit		3192487	Use w/Stainless Steel Model		3191925	Biscuit
	3191258	Stainless Steel				13	3192527	Ignitor
2		Collar, Knob	8		Cap, (RR)	14		Orifice
	3192165	White		3191735	White		3192528	RF - LR
	3192164	Black		3191734	Black		3192523	Center
	3192166	Almond		3191736	Biscuit		3192524	RR
	3192167	Biscuit		3192488	Use w/Stainless Steel Model		3192525	LF
3	3191936	Seal, Foam				15		Holder, Orifice
4		Nameplate	9		Cap, (LF)		3191740	RF - LR
	3191516	White		3191738	White		3191741	LF
	3191514	Black		3191737	Black		3191742	RR
	3191517	Almond		3191739	Biscuit		3191743	Center
	3191920	Biscuit		3192489	Use w/Stainless Steel Model	16		Head, Burner
6		Cap, (RF)(LR)	10		Grate, Burner		9753109	RF - LR
	3191729	White		3191486	White		9753187	LF
	3191728	Black		3191485	Black		9753110	RR
	3191730	Biscuit		3191487	Biscuit		9753111	Center
	3192486	Use w/Stainless Steel Model		3192485	Use w/Stainless Steel Model	18	4449809	Screw
						20	3368921	Screw
			11		Grate, Filler			
				3191281	White			
				3191280	Black			
				3191282	Biscuit			
				3192483	Use w/Stainless Steel Model			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BURNER BOX, GAS VALVES, AND SWITCHES

For Models: KGCS166GBL0, KGCS166GWH0, KGCS166GAL0, KGCS166GBT0, KGCS166GSS0
(Black) (White) (Almond) (Biscuit) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BURNER BOX, GAS VALVES, AND SWITCHES

For Models: KGCS166GBL0, KGCS166GWH0, KGCS166GAL0, KGCS166GBT0, KGCS166GSS0

(Black)

(White)

(Almond)

(Biscuit)

(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3191557	Rail, Burner	14	3191324	Tubing, Gas Burner (RF)	LITERATURE PARTS		
2	3191317	Pipe, Manifold	15	3191326	Tubing, Gas Burner (LF)	LIT3191827		Installation Instructions
3	3191292	Valve, Gas Burner (RF)(LR)	16	3191325	Tubing, Gas Burner (RR)	LIT3191828		Use & Care Guide
4	3191387	Seal, Shaft	17	3191327	Tubing, Gas Burner (LR)	LIT3192099		Wiring Diagram
5	3191293	Valve, Gas Burner (RR & CR)	18	3191462	Shield, Heat (2)	LIT3191638		Tips-Safer Cooking
6	3192157	Valve, Gas Burner (LF)	19	3191332	Tubing, Gas Burner (CR)	LIT3192260		LP Conversion Instructions
7	3192819	Rail, Center	21	3177120	Regulator, Pressure			
8	307630	Bolt, Gas Valve	22	3192498	Burner Box			
9	3177991	Screw	27	3190700	Module Spark			
10	3192491	Bracket, Mainfold						
11	3196160	Screw						
12	3191336	Harness & Switches						

PARTS NOT ILLUSTRATED

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Following Parts Not Illustrated

3192231	Cord, Power
4173634	Bushing
3179557	Screw
3183401	Bracket, Mounting
4167077	Tinnerman Nut

Miscellaneous

3188310	Hardware, Mounting
3192304	Conversion Kit Natural Gas To L.P.

WIRING HARNESS PARTS

3192229	Harness, Ignitor 15" (2)
3191417	Wire, Ground
3192230	Harness, Ignitor 28" (2)