


COOKTOP, BURNER AND GRATE PARTS

For Models: KGCS166GBL1, KGCS166GWH1, KGCS166GAL1, KGCS166GBT1, KGCS166GSS1
(Black) (White) (Almond) (Biscuit) (Stainless Steel)

36" GAS COOKTOP

KitchenAid®



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP, BURNER AND GRATE PARTS

For Models: KGCS166GBL1, KGCS166GWH1, KGCS166GAL1, KGCS166GBT1, KGCS166GSS1


(Black) (White) (Almond) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3191256	Cooktop White	7	3191732	Cap, (CR) White	12		Knob, Control (4) White
	3191255	Black		3191731	Black		3191923	Black
	3191257	Almond		3191733	Biscuit		3191922	Almond
	3191295	Biscuit		3192487	Use w/Stainless Steel Model		3191924	Biscuit
	3191258	Stainless Steel					3191925	Use w/Stainless Steel Model
2		Collar, Knob	8		Cap, (RR)	13	9754215	Ignitor
	3192165	White		3191735	White	14		Orifice
	3192164	Black		3191734	Black		3192528	RF – LR
	3192166	Almond		3191736	Biscuit		3192523	Center
	3192167	Biscuit		3192488	Use w/Stainless Steel Model		3192524	RR
3	3193091	Seal, Foam					3192525	LF
4		Nameplate	9		Cap, (LF)	15		Holder, Orifice
	3191516	White		3191738	White		9754182	RF – LR
	3191514	Black		3191737	Black		9754188	LF
	3191517	Almond		3191739	Biscuit		9754187	RR
	3191920	Biscuit		3192489	Use w/Stainless Steel Model		9754186	Center
6		Cap, (RF)(LR)				16		Head, Burner
	3191729	White	10		Grate, Burner		8273216	RF – LR
	3191728	Black		3191486	White		9754181	LF
	3191730	Biscuit		3191485	Black		8273214	RR
	3192486	Use w/Stainless Steel Model		3191487	Biscuit		8273215	Center
				3192485	Use w/Stainless Steel Model	18	4449809	Screw
						20	3368921	Screw
			11		Grate, Filler			
				3191281	White			
				3191280	Black			
				3191282	Biscuit			
				3192483	Use w/Stainless Steel Model			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BURNER BOX, GAS VALVES, AND SWITCHES

For Models: KGCS166GBL1, KGCS166GWH1, KGCS166GAL1, KGCS166GBT1, KGCS166GSS1
(Black) (White) (Almond) (Biscuit) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BURNER BOX, GAS VALVES, AND SWITCHES

For Models: KGCS166GBL1, KGCS166GWH1, KGCS166GAL1, KGCS166GBT1, KGCS166GSS1
 (Black) (White) (Almond) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3191557	Rail, Burner	11	3196160	Screw	21	3177120	Regulator, Pressure
2	3191317	Pipe, Manifold	12	3191336	Harness & Switches	22	3192498	Burner Box
3	3191292	Valve, Gas Burner Burner, (RF)(LR)	14	3191324	Tubing, Gas Burner (RF)	27	3190700	Module Spark
4	3191387	Seal, Shaft	15	3191326	Tubing, Gas Burner (LF)	<u>LITERATURE PARTS</u>		
5	3191293	Valve, Gas Burner (RR & CR)	16	3191325	Tubing, Gas Burner (RR)		LIT3191827	Installation Instructions
6	3192157	Valve, Gas Burner (LF)	17	3191327	Tubing, Gas Burner (LR)		LIT3193071	Use & Care Guide
7	3192819	Rail, Center	18	3191462	Shield, Heat (2)		LIT3192099	Wiring Diagram
8	307630	Bolt, Gas Valve	19	3191332	Tubing, Gas Burner (CR)		LIT3191638	Tips-Safer Cooking
9	3177991	Screw					LIT3192742	LP Conversion Instructions
10	3192491	Bracket, Mainfold						

PARTS NOT ILLUSTRATED

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Following Parts Not Illustrated

- 3192231 Cord, Power
- 4173634 Bushing
- 3179557 Screw
- 3183401 Bracket, Mounting
- 4167077 Tinnerman Nut

Miscellaneous

- 3188310 Hardware, Mounting
- 3192741 Conversion Kit
Natural Gas To L.P.

WIRING HARNESS PARTS

- 3192229 Harness,
Ignitor 15" (2)
- 3191417 Wire, Ground
- 3192230 Harness,
Ignitor 28" (2)