



# Comfort Economy Task Chair

## Assembly Instructions

For CH277

### PART LIST

KEY	QTY	DESCRIPTION
1	5	Casters
2	1	Base
3	1	Gas Cylinder
4	1	Cylinder Cover
5	1	Seat
6	1	Seat Plate
7	1	Backrest
8	1	Backrest Height Adj. Knob + Washer
9	1	Backrest + Depth Adj. Knob With Washers
10	1	Backrest Post + Plastic Bellow
11	6	Foot Rest Screws
12	1	M5 Size Allen Wrench

### PREVENTIVE MAINTENANCE AND WARNING!

- USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME.
- DO NOT USE THIS CHAIR AS A STEP STOOL / LADDER.
- DO NOT SIT ON ANY PART OF THE CHAIR EXCEPT THE SEAT.
- DO NOT USE CHAIR ON UNEVEN FLOOR SURFACES.
- DO NOT USE CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS ARE TIGHT. AT LEAST EVERY SIX MONTHS, CHECK ALL BOLTS, SCREWS AND KNOBS TO BE SURE THEY ARE TIGHT.
- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USE OF THE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED PARTS.
- DISPOSE OF PACKAGING PROPERLY. PLASTIC BAG IS NOT A TOY. DO NOT USE PLASTIC BAG AS HEAD COVERING - IT MAY CAUSE SUFFOCATION.
- FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.

