


COOKTOP PARTS

For Models: MER7662WW0, MER7662WB0, MER7662WT0, MER7662WS0
 (White) (Black) (Biscuit) (Stainless Steel)

30" ELECTRIC CERAN
 FREESTANDING RANGE
 SELF CLEAN CONVECTION OVEN



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10234644	Owner's Manual
	W10237513	Tech Sheet
	W10196158	Installation Instructions
		Template, Anti-Tip
	9757143	English/French
	9757142	English/Spanish
	9762761	Brochure, Tips Safe Cooking


Illus. No.	Part No.	DESCRIPTION
2		Cooktop
	W10211389	White
	W10211390	Black
	W10211391	Biscuit
3		Element, Surface
	W10173896	2500/1200 W - RF
	W10178016	3000 W - LF
	8273994	1200 W - LR

Illus. No.	Part No.	DESCRIPTION
4	W10170526	Pan, Radiant Elmt
5	3196169	Screw
6	W10162042	Spring, Locator
7	3196170	Screw
8	3195060	Hinge, Pin

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: MER7662WW0, MER7662WB0, MER7662WT0, MER7662WS0
 (White) (Black) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1		Endcap
	W10184433	White Left Hand
	W10184434	White Right Hand
	W10184437	Black Left Hand
	W10184438	Black Right Hand
	W10184435	Biscuit, LH
	W10184436	Biscuit, RH
2	W10182322	Bracket, Console
3		Panel, Control
	W10225535	White
	W10225536	Black
	W10225537	Biscuit
	W10225538	Stainless Steel


Illus. No.	Part No.	DESCRIPTION
4		Switch, Infinite
	W10167742	Left Front
	3148951	Left - Right Rear
	W10149355	Right Front (Dual)
5	3196200	Clip, Spring
6	3196068	Lens, Light
7		Knob, Infinite (4)
	W10211371	White
	W10211372	Black
	W10211373	Biscuit
8	W10134247	Shield, Heat
9	W10138683	Brkt, Mntg EOC

Illus. No.	Part No.	DESCRIPTION
10	8272473	Cover, Rear
11		Control, Range
	W10173513	White
	W10173514	Black
	W10173515	Biscuit
12	3196178	Screw
14	3400882	Screw
15	8273564	Clip, Cover
16		Screw
	3196166	White
	3196168	Black
	8281194	Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: MER7662WW0, MER7662WB0, MER7662WT0, MER7662WS0
(White) (Black) (Biscuit) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: MER7662WW0, MER7662WB0, MER7662WT0, MER7662WS0
 (White) (Black) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10134285	Vent Tube Asmbly	16	W10058460	Foot, Rear (2)	37	9760407	Brkt – Mounting
2	W10182346	Insulation	17	W10196451	Rod, Insul Retainr	38	9761013	Latch, Door
3		Panel, Side (2)	18	9757239	Rod – Dr Switch	39	W10078380	Rod, Latch
	8053830	White	19	3186116	Support, Oven (2)	40	W10107820	Latch Asy, Rear
	8053832	Black	20	3186034	Bracket, Service	41	9758701	Spacer, Door
	8272519	Biscuit	21	9761958	Block, Terminal	42	3196169	Screw
4	9761517	Clip,Door Mntg(2)	22	8274034	Back, Main	43	9758283	Cover, Box
5	8522416	Seal, Oven Door	23	9757262	Switch, Door	44	9761301	Screen – Catalyst
6	9757340	Element, Broil	24	3196701	Light Socket Assy	45	3196560	Screw (2)
7	9755770	Element, Bake (Hidden)	25	311255	Bulb, Oven Light	46	W10183712	Tray–Bake, Hidden
8	7103P027-60	Nut (3)	26	3196165	Screw	47	W10010350	Oven Seal, Flange
9	3196548	Fuse, Thermal	27	W10181986	Sensor, Oven	48	W10183541	Clip, Spring
10	W10114344	Glide, Drwr Top	28	3196179	Screw	49	W10134125	Shield, Heat
11	3196037	Foot, Front (2)	29	3196178	Screw	50	3400968	Nut, Push On
12	3196566	Screw	30	3400016	Screw			
13	W10134121	Tray, Insulation	31	3196172	Screw			
14	W10137382	Clip, Panel (4)	32	W10031780	Screw			
15	9760314	Rail, Base (2)	33	W10067840	Screw			
			34	3196168	Screw			
			35	3196174	Screw			
			36	9758238	Retainer, Side (2)			


INSULATION

W10208653	Insulation, Wrap
W10219986	Insulation, Back
8272613	Insulation, Vent

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRAWER & BROILER PARTS

For Models: MER7662WW0, MER7662WB0, MER7662WT0, MER7662WS0
 (White) (Black) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	W10179196	Rack, Oven (2)
2	9761031	Drawer, Storage
3	W10174396	Brkt-Mntg, Drawer
4		Rivet, Push (2)
	3196814	White
	3196813	Black
5		Panel, Drawer Frnt
	8053339	White
	8053341	Black
	8272501	Biscuit
6	3196168	Screw
7	8053334	Glide, Drawer (2)
8	W10031790	Screw(Stls.Model)
9	9781235	Clip(Stls.Model)
10	W10217860	Panel(Stls.Model)
11	W10197980	Handle(Stls.Model)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: MER7662WW0, MER7662WB0, MER7662WT0, MER7662WS0
 (White) (Black) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	W10144869	Trim, Top White
	W10144870	Black
	W10181675	Biscuit
2	W10168559	Screw
3	W10111309	Handle, Door White
	W10111310	Black
	W10111311	Biscuit
4	9761344	Liner, Door
5	8522414	Seal, Window
6	9758162	Glass, Inner (2)
7	3186289	Frame, Glass

Illus. No.	Part No.	DESCRIPTION
8	8272618	Insulation, Door
9	9761357	Retainer, Insul.
10	9761493	Hinge, Door (2)
11	W10106404	Glass, Outer White
	W10106405	Black
	W10106406	Biscuit
12	8523172	Trim, Side White Left Hand
	8523166	White Right Hand
	8523171	Black Left Hand
	8523165	Black Right Hand
	8523167	Biscuit Left Hand
	8523173	Biscuit Right Hand
	W10113925	Stainless RH
	W10113926	Stainless LH

Illus. No.	Part No.	DESCRIPTION
13	3196160	Screw
14	8523175	Trim, Lower White
	8523177	Black
	8523178	Biscuit
15	W10031790	Screw
16	W10031780	Screw
17	W10200660	Screw
18	W10137382	Clip, Panel Side
19	W10113759	Strap, Door

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: MER7662WW0, MER7662WB0, MER7662WT0, MER7662WS0
 (White) (Black) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
Following Parts Not Illustrated		
<u>REFINISHING MATERIAL</u>		
	242756	Touch-Up Self-Clean(1/2 Pt)
<u>INSULATION</u>		
	240132	Insulation, Fiberglass (2-1/2" x 22" x 120")
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
	72017	White
	4392899	Biscuit
	511873	White Porcelain (2 Oz.)

Illus. No.	Part No.	DESCRIPTION
<u>PAINT, PRESSURIZED SPRAY (12 oz.)</u>		
	350930	White
	4392901	Biscuit
	285006	Superior Black
	206922	Primer (White)
<u>PAINT, BULK (1 qt.)</u>		
	799344	White (Uncut)
	4392900	Biscuit (Uncut)
<u>ACCESSORY PARTS</u>		
	241430	Foil, Aluminum Oven (18" x 25')
	3184478	Cleaner, Glass
<u>ANTI-TIP KIT</u>		
	W10017440	Anti-Tip Kit

Illus. No.	Part No.	DESCRIPTION
<u>WIRING HARNESS PARTS</u>		
Following Parts Not Illustrated		
	W10174426	Harness, Wire (Cooktop Left)
	W10174425	Harness, Wire (Cooktop Right)
	W10233338	Harness, Wire (Main)
	W10084660	Harness, Wire (Sensor/Dr Switch)
	9757339	Harness, Wire (Bake, Hidden)
	W10144763	Tie, Wire
	8523279	Wire, Ground
	313660	Clip, Ground Wire
	3196154	Screw
	3196173	Screw, Grnd Wire

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST