

BM-535


Microcassette Dictating Machine

SONY

▲ **SLIDE SWITCH OPERATION**

- **VOICE OPERATED RECORDING**
- **LED RECORD/BATTERY LEVEL INDICATOR (VOICE MIRROR)**
- **3-DIGIT TAPE COUNTER**
- **AUDIBLE END OF TAPE ALARM**
- **LOCK SWITCH**
- **2-SPEED RECORD/PLAYBACK**
- **SONYMATIC® RECORDING LEVEL CONTROL**
- **EARPHONE JACK**

▲ **STEP-UP FEATURE** ▶ **NEW FEATURE**



features

- **MICROCASSETTE SYSTEM** uses easy to obtain, easy to store microcassettes for recording and playback convenience
- ▲ **SLIDE SWITCH OPERATION** needs only one-finger operation to change the operating mode from Dictate to Stop to Listen to Backspace
- **VOICE OPERATED RECORDING (VOR)** activates the recorder only when audible sound is present, conserving tape and eliminating soundless pauses during playback
- **LED RECORD/BATTERY LEVEL INDICATOR (VOICE MIRROR)** confirms recording status at all times, shows relative battery strength, and indicates when sound is present
- **3-DIGIT TAPE COUNTER** gives a visible indication of tape elapsed for rapid access when editing and shows amount of dictation on the tape
- **AUDIBLE END OF TAPE ALARM** sounds an audible alert when end of tape is reached
- **LOCK SWITCH** locks the controls to prevent accidental activation of any function
- **2-SPEED RECORD/PLAYBACK** gives you the option of using a standard 60-minute microcassette for an extended recording or dictation session lasting as long as 2 hours
- **SONYMATIC® RECORDING LEVEL CONTROL** ensures correct recording levels for the particular situation
- **EARPHONE JACK** for private listening with optional earphone

specifications

RECORDING SYSTEM: 4 Track, 1 Channel monaural microcassette

TAPE SPEED: 2.4 cm/sec, 1.2 cm/sec

FREQUENCY RESPONSE: 300-4000Hz (2.4cm/sec)
300-3000Hz (1.2cm/sec)

SPEAKER: 1" (28mm) Dia.

POWER OUTPUT: 250mW at 10% THD

POWER REQUIREMENTS: DC 3V with "AAA" x 2 batteries
AC 120V, 60Hz with optional AC Adaptor

BATTERY LIFE: Approx. 7 hours with Sony "AAA" alkaline batteries (not incl.)

DIMENSIONS (WHD): 2 ⁵/₃₂" x 4 ³/₄" x 2 ⁹/₃₂" (54.5 x 120 x 22.4mm)

WEIGHT: 5 ³/₄ oz (165g) with batteries

OPTIONAL ACCESSORIES: AC-E30HG AC Adaptor, Microcassettes

©2002 Sony Electronics Inc.

Reproduction in whole or in part without written permission is prohibited. All rights reserved.
Sony and Sonymatic are trademarks of Sony.

Features and specifications are subject to change without notice. Non-metric weights and measures are approximate.