



ASSEMBLY INSTRUCTIONS

Adult Assembly Required.

Save these instructions for future use.

This item is a toy for dolls only.

For children ages three (3) years and older.




MODEL #: 01905
NAME: Round Doll Crib

TOOLS NEEDED: Phillips Screwdriver, Hammer

PARTS INCLUDED:

- (A) 1 - Top Ring
- (B) 4 - Leg Posts
- (C) 4 - Long Screws *(not shown)*
- (D) 15 - Dowels*
- (E) 8 - Short Screws *(not shown)*
- (F) 1 - Bottom Ring
- (G) 4 - Caster Wheels
- (H) 1 - Canopy Pole with Curve/Bend
- (I) 1 - Metal Canopy Frame
- (J) 1 - Fabric Skirt
- (K) 1 - Fabric Sheet
- (L) 1 - Mattress Pad
- (M) 1 - Fabric Canopy

*** IMPORTANT:** 4 of the dowels have holes in both ends, 11 have no holes or a small hole in only one end






**BEFORE
YOU
BEGIN
ASSEMBLY:**

Ensure that all the parts and hardware listed above are included. If anything is missing, please do not return the product to the store. Call or e-mail us for assistance.

Visit us online at www.badgerbasket.com

Toll-Free Customer Service: 1-800-236-1310 (Monday through Thursday 7:30 AM to 4:30 PM CST)
 cs@badgerbasket.com

PLANT AND GENERAL OFFICE: PO Box 227, Edgar, WI 54426-0227 715-352-2311 Fax: 715-352-3163
CORPORATE OFFICE: 111 Lions Dr., Suite 220, Barrington, IL 60010



PICTURE 1

STEP 1: See PICTURE 1. Attach the FOUR LEG POSTS (B) to their designated spots on the TOP RING (A) using the FOUR LONG SCREWS (C).

Attach the FOUR DOWELS WITH TWO HOLES (D) using FOUR SHORT SCREWS (E). The positions of these four dowels may vary from shown in Picture 1.

STEP 2: See PICTURE 2. Turn the crib upside down. Insert the FOUR LEG POSTS (B) through the large holes on the BOTTOM RING (F) and slide the bottom ring down until it rests on the DOWELS WITH TWO HOLES (D).

Be sure screw and dowel holes on the bottom ring are in the right place, and the white side of the bottom platform is facing down (white side will face up when the crib is in the upright position).

Starting at any dowel, work your way around the ring and alternately screw down the FOUR DOWELS WITH TWO HOLES (D) using FOUR SHORT SCREWS (E) and insert the remaining ELEVEN DOWELS (D) sandwiched between the top and bottom rings.

There is one hole for the canopy pole that you will leave open.


STEP 3: See PICTURE 3. Turn the crib right side up. Insert the FOUR CASTER WHEELS (G) into the holes on the bottom of the LEG POSTS (B). Grasp each leg and gently but firmly press each wheel against the floor to snap it into place.



PICTURE 2



PICTURE 3



STEP 4: See PICTURES 4A and 4B. Insert the CANOPY POLE (H) through the hole on the TOP RING (A) and push it down until it rests in the hole on the BOTTOM RING (F). Insert the two free ends of the METAL CANOPY FRAME (I) into the top of the CANOPY POLE (H). You may need to gently tap on the canopy frame with a hammer so that the ends are pushed down into the pole as far as possible (see PICTURE 4B).

Starting by the canopy pole, wrap the FABRIC SKIRT (J) around the BOTTOM RING (F) pressing the grip tape together. When you get back to where you started, press the grip tape on the two ends of the skirt together. Put the FABRIC SHEET (K) on the MATTRESS PAD (L) and place the sheet and pad into the crib.

STEP 5: See PICTURE 5. Position the FABRIC CANOPY (M) over the METAL CANOPY FRAME (I). Secure the grip tape tabs on the fabric canopy around the metal frame. Adjust the canopy so it drapes around the crib.



Your ROUND DOLL CRIB is now ready to enjoy! This beautiful item is suitable for children from three years old and up. Please make sure children know that this furniture is for dolls and stuffed animals only. **It is NEVER to be used with real infants or with pets. Children should NEVER attempt to sit or stand on the crib.**

Care instructions: Wipe crib parts and vinyl pad clean with a damp cloth and mild detergent as needed. Fabric is poly/cotton. For longevity of the product we recommend hand washing the bedding; however it can be machine washed on gentle and air dried or tumble dried on low or no heat. Iron on the lowest setting for poly/cotton.