


1 Grease Clip 1 Grease Can

Hang grease clip from center of grill bottom. Hang grease can from grease clip.


A CAUTION


Failure to install can in clip will cause hot grease to drip from bottom of grill with risk of fire or property damage.



attached.

• Failure to install tank correctly may allow gas hose to be damaged in operation, resulting in the risk of fire.








Thank you for trying 100% Natural Hickory Smoke Flavoring Pellets. Now you can add true wood smoke flavor to your food while cooking with gas!

To use in your Char-Broil[™] Big Easy[™] grill, construct a foil pouch the approximate size of the pellet package. Poke a 1/4" diameter hole into one side of the pouch. Preheat grill to desired temperature. Place the pouch, with the hole facing up, on top of the burner tent inside the grill. Please note, the burner tent should NOT be inverted for use with smoke flavoring pellets. When smoking starts, place food on grill and close lid.



Parts List - Model 4638247

Key	<u>Qty</u>	<u>/. Description</u> <u>Part #</u>	Key Qty. Description Part #
Α	1	Grease Cup4150349	DD 1 Ignitor Knob
В	1	Condiment Wire 4151005	EE 1 Sideburner Valve Cup 4154476
С	3	Tent Frame 4151014	FF 1 Grill Bottom4580387
D	1	Griddle 4152038	GG 3 Burner5068016
Ε	1	Warming Rack 4152043	HH 1 Sideburner Ignitor Wire 5156110
F	1	Cooking Grid, 12" 4152045	II 1 Left Shelf
G	1	Cooking Grid, 15" 4152046	JJ 1 Sideburner Assembly 4520018
Н	1	Handle 4154474	KK 1 Sideburner Burner 5068017 LL 1 Grill top
i.	1	Condiment Tray 4154518	LL 1 Grill top
J	1	Sideburner Tool Holder 4154519	NN 1 Sideburner Knob 4154471
K	1	Sideburner Grate 4156179	OO 1 Logo Plate
L	2	Wheel	1 Hardware, Cart Assy 4254009
M	1	LP Tank4158015	1 Hardware, Shelf 4254011
N	3	Burner Tent	PP 1 Grease Clip 5156607
0	1	Tank Retainer 4503105	
P	1	Tank Support	
' Q	1	Storage Shelf 4503107	
Q R	1	Upper Panel	
S	1	Lower Panel	
T	2	#10x1/2" Screw, Self-tap. 4080043	
U	2	Pivot Pin	
V \\\	3	3/16 Pal Nut 4153096	
W	1	Ignitor Wire 4153184	
X	2	Leg Extender 4154516	
Y	2	Hitch Pin	
Z	2	Carry-over Tube 4500228	
AA 		Right Leg	
BB		Left Leg	
CC	1	Console Assembly 4530040	







4638247 **ASSEMBLY MANUAL**



THIS GRILL IS FOR **OUTDOOR USE ONLY**

CAUTION: Read and follow all safety statements, assembly instructions, and use and care directions before attempting to assemble and cook.

INSTALLER/ASSEMBLER: Leave these instructions with consumer.

CONSUMER: Keep this manual for future reference.

A WARNING

Failure to follow all manufacturer's instructions could result in serious personal injury and/or property damage.

A CAUTION

Some parts may contain sharp edges – especially as noted in the manual! Wear protective gloves if necessary.

If you have any questions or need assistance during assembly, please call **1-800-241-7548**.

Visit us on the web at:

